



# rinstrum

**SMART WEIGHING SOLUTIONS**



## **R300 Series**

**(R320 and R323)**

## **Digital Weighing Indicator Communication Manual**

**Software Version 3.0 and higher**

## Table of Contents

<b>1.</b>	<b>INTRODUCTION .....</b>	<b>4</b>
1.1.	Intended Audience .....	4
1.2.	Scope.....	4
1.3.	The Manuals Set .....	5
1.4.	Document Conventions .....	5
<b>2.</b>	<b>CONNECTING TO THE INSTRUMENT.....</b>	<b>6</b>
2.1.	opto-LINK.....	6
2.1.1.	opto-LINK Activation.....	6
2.1.2.	opto-LINK Communications Settings .....	6
2.2.	RS-232 Connection .....	7
2.2.1.	RS-232 Communications Settings .....	7
2.3.	opto-LINK vs RS-232 .....	10
<b>3.</b>	<b>GETTING STARTED .....</b>	<b>11</b>
3.1.	Using Viewer .....	11
3.2.	COMM Protocol Summary.....	11
3.3.	Reading Gross Weight as Literal Value.....	12
3.4.	Read Gross Weight as Final Value .....	12
3.5.	Setting Values .....	12
3.6.	Remote Key Press .....	12
3.7.	RS-232 Ring Network Enhancement.....	12
3.7.1.	RS-232 Ring Network Example .....	13
<b>4.</b>	<b>PROTOCOL OVERVIEW .....</b>	<b>14</b>
4.1.	COMM Message Structure .....	14
4.1.1.	Address Field .....	15
4.1.2.	Command Field .....	15
4.1.3.	Register Id Field .....	16
4.1.4.	Optional Parameters.....	16
4.1.5.	Return Value .....	16
4.1.6.	RS-232 Ring Network Enhancement .....	16
4.2.	Error Handling .....	17
4.3.	Register Types .....	18
4.4.	Permissions.....	19
4.4.1.	Register Access .....	19
4.4.2.	Calibration and Configuration Counters.....	20
<b>5.</b>	<b>REGISTER OPERATIONS AND PROPERTIES.....</b>	<b>21</b>
5.1.	Register Operations .....	21
5.2.	Common Properties .....	21
5.2.1.	Type .....	21
5.2.2.	Menu Text .....	21
5.2.3.	Permission.....	22
5.3.	Type Specific Properties.....	22
5.3.1.	RangeMin, RangeMax .....	22
5.3.2.	Final Value .....	23
5.3.3.	Literal Value .....	23
5.3.4.	Default Value.....	23
5.3.5.	Execute .....	23
5.3.6.	Read Items.....	24
<b>6.</b>	<b>READING STATUS AND ERROR CODES .....</b>	<b>25</b>
6.1.	REG_SYSTEM_STATUS.....	25
6.2.	REG_SYSTEM_ERROR .....	26
<b>7.</b>	<b>REMOTE KEY INTERFACE .....</b>	<b>27</b>
7.1.	Operation .....	27
7.2.	Key-Codes .....	27
7.2.1.	Physical Codes.....	27
7.2.2.	Example .....	28
7.2.3.	Logical Keys .....	28

**8. EXECUTE FUNCTIONS ..... 29**

8.1. Calibration ..... 29

    8.1.1. Span ..... 30

    8.1.2. Linearisation ..... 31

8.2. Save Settings to EEPROM ..... 31

**9. STREAMING ..... 32**

9.1. Basic Operation ..... 32

9.2. Registers Available to Stream ..... 32

9.3. Example ..... 33

**10. PRINTING ..... 34**

10.1. Basic Operation ..... 34

10.2. Tokens Available for Printing ..... 34

10.3. Examples of Operation ..... 35

**11. ADVANCED TYPE HANDLING (TYPE\_MENU) ..... 36**

**12. APPENDIX – PROGRAM CONSTANTS ..... 37**

12.1. Register Types ..... 37

12.2. Commands ..... 37

12.3. Error Codes ..... 38

12.4. Register Identifiers ..... 38

12.5. Key Codes ..... 41

12.6. Decimal, Binary and Hexadecimal Conversion ..... 42

12.7. Setup and Calibration Errors ..... 43

12.8. Glossary Terms ..... 44

12.9. List of Figures ..... 44

12.10. List of Tables ..... 44

**13. INDEX ..... 46**

## 1. Introduction

This manual details the communications protocol (**COMM**) of the indicator.

This protocol is used by the **Viewer** program to calibrate and configure the instrument. The **Viewer TEST** tab can be used as a convenient terminal to test the instrument communications.

The indicator is fitted with **opto-LINK** communications as standard. This allows a temporary isolated communications link to be established with a PC permitting the instrument software to be upgraded. It also allows the use of computerised setup and calibration via the **Viewer** software. The instrument also has an RS-232 port, which may be used for printing, connection to a remote display or control using **COMM**. The instrument can utilise the protocol to fully control the indicator.



**Figure 1: Weight Indicator**

### 1.1. Intended Audience

This manual is aimed at the designer or installer who is familiar with the operation and setup of the instrument.

### 1.2. Scope

This manual lists the commands and registers for the protocol. In practice, only a small subset of these commands would be used to control operational parameters.

### 1.3. The Manuals Set

This manual is part of a set of manuals covering the setup and operation of the instrument. The set includes the following:

- **Reference Manual** - Contains detailed information on calibration and setup. This manual is intended for use by Scale Technicians who are installing the instrument.
- **Operator Manual** - Aimed at the operation of the instrument, and covers the day-to-day operation of the instrument.
- **Quick Start Manual** - Intended for Scale Technicians who are familiar with the instrument and simply need a quick reference to menu options and connection diagrams, etc.
- **Communications Manual** - Contains details on the extended networking capabilities (communications protocol).

### 1.4. Document Conventions

The following document conventions (typographical) are used throughout this Communications Manual.

<b>Bold Text</b>	Bold text denotes words and phrases to note.
^	This symbol denotes one space (used in Commands)
...	Ellipses indicate an incomplete listing. For space considerations in this Manual complete listings of returned Command responses may not be shown.
1234 <sub>H</sub>	The subscript <sub>H</sub> indicates numerical values expressed in hexadecimal (radix 16).
1010 <sub>b</sub>	The subscript <sub>b</sub> indicates a numerical value expressed in binary (radix 2). Also, typically, spaces are used every 4 bits to break the string up visually, e.g., 1100 1101 <sub>b</sub> .
[...]	Items enclosed in square brackets are optional.
<char>	<char> denotes a special character value. eg. <CR> is carriage return.
↵	This symbol indicates a <CR><LF> pair of characters.
<b>1234</b>	This font indicates message <b>sent</b> to an indicator.
1234	This font indicates a <b>response</b> from an indicator.
"string"	String values are enclosed in double quotes ""
⊗	Items marked with ⊗ indicate that the setting is available only in Full Setup and is trade critical. When trade critical settings are changed the calibration counter will be incremented.
REG_...	Register name. Refer to Register Identifiers page 38

## 2. Connecting to the Instrument

### 2.1. opto-LINK

A temporary infrared communications link can be established between any instrument and a PC using an optional opto-LINK cable. The opto-LINK cable can be used to transfer setup information from a PC and download software upgrades to the instrument. This setup information can be stored for later use and/or transferred to other instruments.



The PC end of the opto-LINK cable is a standard COM port (female DB9) connector. The instrument end of the cable consists of an infrared transceiver, which attaches to the left side of the instrument display. To facilitate a quick and simple connection, the infrared transceiver is secured in place by a permanent magnet located within the head of the opto-LINK.

#### WARNING

**The opto-LINK head contains a strong magnet and care should be taken with its proximity to electronic media (eg. credit cards, floppy disks, etc.) and/or other electronic instrumentation.**

**Note:** The serial connection for the opto-LINK is standard to this instrument.

#### 2.1.1. opto-LINK Activation

This feature is used to temporarily connect a PC to the instrument for calibration and setup purposes.

A long press of the **GROSS/NET** key will toggle the opto-LINK infrared communications On/Off.

When the opto-LINK has been enabled the following will occur:

- The instrument briefly displays the prompt **opto-L**.
- The editing annunciators (ie. GRP, ITM, etc.) will flash while the instrument searches for activity. During this period, the instrument also disables the RS-232 communications.
- **Activity Located:** If the instrument is **successful** in locating activity, the editing annunciators will continue to flash during the entire period of communications.
- **No Activity Located:** If the instrument **fails** to locate activity in five minutes, the opto-LINK will be disabled and the editing annunciators will stop flashing. The instrument will also revert back to the normal RS-232 communications (ie. the SERIAL:TYPE setting will be re-activated).

#### 2.1.2. opto-LINK Communications Settings

The communications settings for opto-LINK are **9600 baud, no parity, 8 data bits and 1 stop bit**. This is often referred to as **9600 N81**.

## 2.2. RS-232 Connection

### 2.2.1. RS-232 Communications Settings

The communications settings for RS-232 are configured using the SERIAL:BAUD and SERIAL:BITS items in the instrument setup menus.

#### Network: One Instrument to PC (RXD, TXD, GND)




Figure 2: RS-232 — One Instrument to PC using COM Port (DB9)




Figure 3: RS-232 – One Instrument to PC using COM Port (DB25)

**Ring Networks: Multiple Instruments to PC (RXD, TXD, GND)**


Instruments with K302 software revision V3.82+ can be configured in a Ring Network. This also requires an enhancement in the PC's software.

The Short Ring Network layout can be used in situations up to a total cable run length of about 150 m (500 ft) at 9600 baud in a clean EMC environment. If there are communications errors, or for longer cable runs, lower the baud rate to 4800 or 2400, and/or use the Long Ring Network in Figure 5 below, which uses a separate return path from the 'Last Instrument' to the PC.

For DB25 connections at the PC connector, refer to Figure 3 above.

- When operating in a Ring Network, the Instruments must have:
- **same** serial port options, i.e., baud, parity, data bits, stop bits;
  - **unique** addresses.

**Short Ring Network: Multiple Instruments to PC (RXD, TXD, GND)**



**Figure 4: RS-232 Short Cable Runs: Ring Network using COM Port (DB9)**



### Long Ring Network: Multiple Instruments to PC (RXD, TXD, GND)

The Long Ring Network layout can be used in situations where each leg of the cable run can be up to about 150 m (500 ft) at 9600 baud. If there are communications errors, lower the baud rate to 4800 or 2400.




Figure 5: RS-232 Long Cable Runs: Ring Network using COM Port (DB9)

2.3. opto-LINK vs RS-232

Table 1 provides a summary of the differences between the two communications links:

	opto-LINK	RS-232
Supports <b>COMM</b> protocol	Yes	Yes
Supported indicators	R300 Series	R320, R323
Permanent connection	No	Yes
Communications settings	9600, N, 8, 1	Configurable via SERIAL:BAUD, SERIAL:BITS
Timeout with no use	5 minutes	None
Software upgrade using FLASH	Yes	No
Remote display (Master)	No	Yes
Printing (Print)	No	Yes
Auto outputs (Auto.1, Auto.2)	No	Yes
Restricted control for OPTION:USE = NTEP <b>COMM</b> permission always PERM_NONE Setup menu mimic operation blocked	No	Yes
NET mode (Network)	When activated as described in Opto-Link Activation page 6.	SERIAL:TYPE Auto switch to NET when command received
Supports <b>Ring Network</b> enhancement	No	Yes: set SERIAL:TYPE to NET

Table 1: opto-LINK vs RS-232 port

### 3. Getting Started

This section gives a brief introduction to using the **COMM** protocol on the instrument. The examples below use the broadcast address and assume that a PC is connected to the RS-232 port as described in RS-232 Connection page 7. The indicator is assumed to be at address **01**.

From K302 software revision V3.82+, the instruments can be installed in a Ring Network, see §3.7 below.

#### 3.1. Using Viewer


- Start **Viewer**.
- Connect to the indicator.
- Select the **Test** page.
- Clear the **Use STX,ETX** box.
- The examples listed in this section may be entered directly in the edit box at the top left of the screen.
- Press the **Send** button or press the **ENTER** key to send a command to the indicator. The command that is sent is shown on the terminal screen after the symbols >>>.

**Note:** The ↵ symbol below indicates <CR><LF>. Using **ViewR300**, this is generated by pressing **Send**.

#### 3.2. COMM Protocol Summary

NOTE: The values used with the Read Final and Write Final commands are hexadecimal. Refer to Table 7: Decimal, Binary and Hexadecimal Conversion page 42 for information on conversions.

Figure 6 lists registers and commands for performing common tasks on the instrument.



**Figure 6: Commonly used Registers and Commands**

### 3.3. Reading Gross Weight as Literal Value

Type the following (without the "" quotes) and then press **Send** (which appends <CR><LF>):

```
"20050026:"
```

The indicator will response with a message like:

```
"81050026:^^10.00^kg^G" (along with a trailing <CR><LF>)
```

### 3.4. Read Gross Weight as Final Value

Type the following and then press **Send**:

```
"20110026:"
```

The indicator will response with a message like:

```
"81110026:000003E8"
```

Where the value after the ":" is the hexadecimal value of the gross weight without any decimal places or units. In decimal, this value is 1000. For conversion between decimal and hexadecimal, refer to Table 7: Decimal, Binary and Hexadecimal Conversion page 42.

### 3.5. Setting Values

For example, change Set Point Target 1 (overweight) to 500 kg in final form for an indicator with units of kg.

Type the following and then press **Send**:

```
"20120171:1F4" (1F4 in hexadecimal = 500 decimal)
```

The indicator will respond with a message like:

```
"81120171:0000"
```

Where the "0000" value after the ":" indicates no errors.

### 3.6. Remote Key Press

For example, remotely press the **TARE** key on an indicator.

Type the following and then press **Send**:

```
"20120008:8003"
```

The indicator will respond with a message like:

```
"81120008:0000"
```

**Note:** For the **ZERO** key type "20120008:8002".


### 3.7. RS-232 Ring Network Enhancement

From K302 software revision V3.82+, the instruments can be installed in a Ring Network. The central computer's software is required to send additional framing characters, 'Echo-On' (= <DC2> =ASCII 12<sub>H</sub>) and 'Echo-Off' (= <DC4> =ASCII 14<sub>H</sub>) around each command.

The responses from the instruments echo the command (which is why <DC2> has been called 'Echo-On'), which is passed by one instrument on to the next.

Each instrument's response is then added to the end of the incoming message ahead of the 'Echo-Off' =<DC4> character.

### 3.7.1. RS-232 Ring Network Example



**Figure 7: RS-232 Ring Network: Example with Two Instruments**

A typical command from a PC, shown as (1) in the example Ring Network in Figure 7 above, might be:

Message (1): 

```
<DC2>20110150:<CR><LF>
<DC4>
```

The first instrument, address 31 in our example, would send the echoed command and add its own following response on to the second instrument (2):

Message (2): 

```
<DC2>20110150:<CR><LF>
9F110150:07/01/2030 17:29<CR><LF>
<DC4>
```

The second instrument, address 30 in our example, would send the echoed command and 31's response and add its own following response on to the PC (3):

Message (3): 

```
<DC2>20110150:<CR><LF>
9F110150:07/01/2030 17:29<CR><LF>
9E110150:07/01/2030 17:30<CR><LF>
<DC4>
```

## 4. Protocol Overview

The instrument contains a number of registers. The indicator is configured by reading and writing the information stored in these registers. Information such as gross weight is obtained by reading these registers. The instrument has registers of different types to hold weights, menu options, etc.

### 4.1. COMM Message Structure

The messages use ASCII characters. Almost all numeric values are transmitted in hexadecimal form using uppercase HEX characters (ie. 0 to 9, A to F).

Commands from a Master (typically a PC) to a Slave (typically an Indicator) are of the form:

Address Field	Command Field	Register Id		[Optional Parameter]	
<b>xx</b>	<b>mm</b>	<b>rrrr</b>	<b>":"</b>	<b>[ppppp]</b>	<b>↵</b>

**Table 2 COMM Command Format**

Responses from Slave to Master are of the form:

Address Field	Command Field	Register Id		Return value	
<b>yy</b>	<b>mm</b>	<b>rrrr</b>	<b>":"</b>	<b>vvvvv</b>	<b>↵</b>

**Table 3 COMM Response Format**

Where:

- xx** is the Address Field sent to the indicator (Response bit = 0).
- yy** is the Address Field in the response from the indicator (Response bit = 1).
- mm** is the Command Field.
- rrrr** is the Register Id Field.
- :"** is the separator between the command header and the parameter or return value.
- ppppp** is the optional parameter value sent to the indicator.
- vvvvv** is the return value from the indicator.
- ↵** is the two characters <CR><LF> (Carriage-Return, Line-Feed).

### 4.1.1. Address Field

The address field is a two character hexadecimal field where:

Bit	Field Name	Description
7	Response	Set by the slave to indicate that this message is a response to a previous command.
6	Error	Set to indicate that the data in this message is an error code and not a normal response. Refer to Error Handling page 17.
5	Reply Required	Set by the master to indicate that a reply to this message is required by any slave to which it is addressed. If not set, the slave should silently perform the command.
4 to 0	Indicator Address	Valid unit addresses are 01 <sub>H</sub> to 1F <sub>H</sub> (1 to 31 in decimal). 00 <sub>H</sub> is the broadcast address. All slaves must process broadcast commands. When replying to a broadcast, slaves replace the broadcast address with their own address in this field. Set in the indicator menus with SERIAL:ADDRES.

### 4.1.2. Command Field

The command field is a two character, hexadecimal field holding the id of command to be performed. The following commands are defined to read register values or properties:

Command	Description
CMD_READ_TYPE	Read Type of register.
CMD_READ_RANGE_MIN	Read Minimum valid register value.
CMD_READ_RANGE_MAX	Read Maximum valid register value.
CMD_READ_LITERAL	Read Literal value of register. Note: Value will be converted to final value as required (eg. 2.000 kg G for gross weight).
CMD_READ_DEFAULT	Read Raw default register value.
CMD_READ_MENU_TEXT	Read Menu Text name shown on indicator display during setup menus.
CMD_READ_ITEM	Return item from list. Only valid for TYPE_MENU, TYPE_OPTION and TYPE_BITFIELD.
CMD_READ_PERMISSION	Read Permission string.
CMD_READ_FINAL	Read Value of register converted to final value.

The following command is defined to write values to registers:

Command	Description
CMD_WRITE_FINAL	Write Final Value to register.

The following command is defined to execute on registers of TYPE\_EXECUTE:

Command	Description
CMD_EXECUTE	Execute the function associated with a register.

### 4.1.3. Register Id Field

This is the four character hexadecimal register identifier. For the list of registers in the instrument refer to Register Identifiers page 38.

### 4.1.4. Optional Parameters

The value here is dependent on the command and register being accessed. Not all commands require a parameter (eg. CMD\_READ\_FINAL). Commands that write to a register have the new value as the parameter.

### 4.1.5. Return Value

The value here is dependent on the command and register being accessed. If a command does not return a value (eg. CMD\_WRITE\_FINAL), then the return value will be an error code (eg. "0000" for no errors).

### 4.1.6. RS-232 Ring Network Enhancement

When the instruments are installed in a Ring Network, the central computer's software is required to send additional framing characters around each command.

Referring to Table 2 COMM Command Format above, the enhanced commands from a Master (typically a PC) to the instruments are of the format:

Echo-On	COMM Message						Echo-Off
<DC2>	Command:						<DC4>
	Address Field	Command Field	Register Id	": "	[Optional Parameter]	↵	
	xx	mm	rrrr	": "	[ppppp]	↵	

**Table 4 COMM Command Format with Ring Network Enhancement**

Where:

<DC2> and <DC4> are the characters ASCII 12<sub>H</sub> and ASCII 14<sub>H</sub> respectively, here called 'Echo-On' and 'Echo-Off'.

Each instrument echoes the command, which is passed on to the next instrument.

If the command's Address Field is addressed to one of the instruments, or is a broadcast (Address Field = 0), then the instrument will append a response ahead of the 'Echo-Off'-<DC4> character.

If the command is broadcast, every instrument will append a response: eg., 7 instruments will generate 7 responses.

Referring to Table 3 COMM Response Format above, the responses from each instrument that are sent onto the next instrument, and so on up to the PC, are of the format:

Echo-On	COMM Message(s)						Echo-Off
<DC2>	Command:						<DC4>
	Address Field	Command Field	Register Id	": "	[Optional Parameter]	↵	
	xx	mm	rrrr	": "	[ppppp]	↵	
	'n' Responses:						
	Address Field	Command Field	Register Id	": "	Return value	↵	
	yy	mm	rrrr	": "	vvvvv	↵	

**Table 5 COMM Response Format with Ring Network Enhancement**



## 4.2. Error Handling

If a command cannot be processed, the indicator returns an error code. Typical errors include:

- Register not implemented on indicator
- Register value out of range
- Command not implemented for register

An error response is indicated by setting the Error bit in the Address Field of the reply.

The message returned by the indicator in response to an error will be of the form:

Address Field	Command Field	Register Id	Error Code	
zz	mm	rrrr	“:”	wwwww ↵

An error code will consist of a hexadecimal value representing the specific error code.

**Note:** When an error occurs, the most significant bit is **1** and other bits indicate the specific problem. More than one error bit may set if more than one error is present.

Refer to Error Codes page 38.

For example, attempting to read the type of the register with Id = 0000<sub>H</sub> (not implemented) will return:

C1010000:A000

which is interpreted as:

C1<sub>H</sub> = 1100 0001<sub>b</sub>

- Response to a command
- Error
- Unit responding is address 01<sub>H</sub>

01<sub>H</sub> = REG\_READ\_TYPE (the command that was sent).

0000<sub>H</sub> = Register Id.

A000<sub>H</sub> = 1010 0000 0000 0000<sub>b</sub> is the error code which is interpreted as

- REG\_ERR\_ERROR = 8000<sub>H</sub> (*most significant bit set*)
- REG\_NOT\_IMPLEMENTED = 4000<sub>H</sub>

### 4.3. Register Types

The following types are defined:

Type	Data Size (bytes)	Minimum Value	Maximum Value	Description
TYPE_BYTE	1	0	$2^8-1$	Small numeric values.
TYPE_OPTION	1	0	$2^8-1$	Lists of strings.
TYPE_USHORT	2	0	$2^{16}-1$	Unsigned numeric values.
TYPE_SHORT	2	$-2^{15}$	$2^{15}-1$	Signed numeric values.
TYPE_LONG	4	$-2^{31}$	$2^{31}-1$	Large numeric values.
TYPE_ULONG	4	0	$2^{32}-1$	Large unsigned numeric values.
TYPE_STRING	--	--	--	<NUL> terminated string.
TYPE_BITFIELD	1, 2 or 4	0	$2^8-1$ , $2^{16}-1$ , or $2^{32}-1$	Composite setting.
TYPE_MENU	1	0	$2^8-1$	Menu structure.
TYPE_BLOB	--	--	--	Binary Large Object. A block of data, interpretation is inferred from Register Id.

## 4.4. Permissions

### 4.4.1. Register Access

Each register has permission levels required for reading, writing and executing. These permission levels can be read using the CMD\_READ\_PERMISSION command. The communications link has a permission level. Changing the current permission level is achieved by writing a passcode to a permission register. If the correct passcode has been given, future messages use that permission level. The passcodes for SAFE and FULL are also used for SPEC:SAFE.PC and SPEC:FULL.PC in the indicator’s setup menus. If more than one passcode register has the correct passcode, the indicator uses the highest level (most powerful). The instrument has the following permission levels:

Permission Level	Description	Passcode Register
None	Lowest level permission. Operation is always available (eg. reading the gross weight).	NONE
Safe	Operation is available if the safe passcode has been given. Used for indicator settings that do not affect trade certification of indicator (eg. baud rate).	REG_ENTER_PASS_SAFE
Full	Operation is available if the FULL passcode has been given. Used for trade critical indicator settings (eg. decimal places).	REG_ENTER_PASS_FULL
Factory	Operation is available only to the indicator’s internal operations (eg. writing to the gross weight).	N/A

If a command cannot be performed because the register needs a higher permission, the command will return an error code of REG\_ERR\_ACCESS\_DENIED.

### 4.4.2. Calibration and Configuration Counters

Within the instrument there are a number of trade critical registers that can affect the calibration and/or legal for trade performance of the instrument. If any of these registers are altered, the trade certification of the scale will be voided.

The instrument provides built-in calibration counters to monitor the number of times the critical registers are altered. The value of the counter is stored within the unit and can only be reset at the factory. Each time a critical register is altered, the counter will increase. Whenever the instrument is powered up, or setup mode is entered/exited, the current value in the counter is displayed briefly (eg. C00010).

**Note:** When the Scale Use is set to NTEP two counters will display. The table below describes when the counter(s) will increment for Industrial, OIML or NTEP modes.

Industrial	OIML	NTEP
<p>The <b>Calibration Counter</b> increments when trade critical settings, marked with ⊗, are changed. An example of the counter is <b>C.00019</b>.</p>	<p>The <b>Calibration Counter</b> increments when trade critical settings, marked with ⊗, are changed. An example of the counter is <b>C.00019</b></p>	<p>The <b>Calibration Counter</b> increments when trade critical settings in the Calibration (<b>CAL</b>) menu, marked with ⊗, are changed. An example of the counter is <b>C.00010</b>.</p> <p>The <b>Configuration Counter</b> increments when other trade critical settings (ie. <b>not</b> in the <b>CAL</b> menu), marked with ⊗, are changed. An example of the counter is <b>F.00009</b>.</p>

Internally, the instrument operates with two counters - the Calibration Counter (REG\_CAL\_COUNT\_NTEP) and the Configuration Counter (REG\_CFG\_COUNT\_NTEP). These correspond directly to the NTEP counters. The Industrial/OIML Calibration Counter (REG\_CAL\_COUNT\_OIML) is the sum of these NTEP counters. Each register has a bit in the Permission property to indicate if a counter will be incremented when the register's value is modified. This counter is incremented even if the values are not saved to EEPROM.

The Calibration counter is incremented for trade critical registers that affect calibration parameters. The Configuration counter is incremented for trade critical registers that affect configuration parameters.

The value(s) of the counter(s) is written on the tamperproof trade label on the front of the indicator for trade-certified applications and functions as an electronic seal. If any legal for trade settings are changed on the instrument, the current value of the calibration counter will be different from the recorded value and the seal is broken. In this manual, items marked with ⊗ indicate that the setting is a legal for trade critical settings.

## 5. Register Operations and Properties

### 5.1. Register Operations

The basic operations that can be performed on values in registers are:

- Read the current value of the register as Final or Literal.
- Write a new value to the register as Final.
- Execute a function associated with a register.

If a command fails, the returned message will have the Error bit set in the Address field to show that the return value is an error code. Not all indicators implement all registers. If an indicator does not support a register or a particular command on a register, it will return an error code of REG\_ERR\_NOT\_IMPLEMENTED. If an attempt is made to write to a register while the indicator is in the setup menu, the indicator will return REG\_ERR\_MENU\_IN\_USE. If an attempt is made to access a register without sufficient permission (refer to Register Access page 19), the indicator will return REG\_ERR\_ACCESS\_DENIED.

### 5.2. Common Properties

Each register stores information about itself. This information is referred to as properties. The register properties differ depending on the type of the register.

Registers implement the following common properties, regardless of the register's type.

#### 5.2.1. Type

Each indicator supports a finite set of register types. It is recommended that this command be performed on a register (to check that it is supported) before performing any other operation.

Command:            CMD\_READ\_TYPE  
 Return:             Register Type as a hexadecimal value    eg. 01 =>  
                       TYPE\_BYTE  
 Error Code:         REG\_ERR\_NOT\_IMPLEMENTED

#### 5.2.2. Menu Text

This property is the text shown on the indicator's display while traversing the menus.

Command:            CMD\_READ\_MENU\_NAME  
 Return:             The indicator will return a string. Some registers may return an empty string in response to this command. The text may contain leading or trailing spaces.

eg. The Menu Text for REG\_DECIMAL\_PLACES is "DP" and when accessed from the **BUILD** menu the display shows **DP**.

### 5.2.3. Permission

Command: CMD\_READ\_PERMISSION  
 Return: This property returns a string of characters, indicating the permission bits for the register. The characters are (in order):

- Read Permission
- Write Permission
- Calibration Counter
- Configuration Counter

Read	Write	Calibration Counter	Configuration Counter
“-“ None (any)	“-“ None (any)	“-“ None	“-“ None
“S” Safe	“S” Safe	“C” Affects	“F” Affects
“F” Full	“F” Full		
“f” Factory (Internal)	“f” Factory (Internal)		

eg. The Permission property of REG\_DECIMAL\_PLACES returns “-F-F” which means:

- Read with any permission (always available).
- Write with Full permission.
- Does not affect Calibration Counter.
- Affects Configuration Counter.

### 5.3. Type Specific Properties

The behaviour of the following properties depends on the type of register.

#### 5.3.1. RangeMin, RangeMax

All Registers have a concept of RangeMin and RangeMax. The register must contain a value that is in the range RangeMin <= Value <= RangeMax.

Command: CMD\_READ\_RANGE\_MIN  
 Return: Hexadecimal

Register Type	RangeMin	RangeMax
TYPE_SHORT, TYPE_USHORT, TYPE_LONG, TYPE_ULONG	Minimum value	Maximum value
TYPE_STRING, TYPE_BLOB	0	(No. of elements -1)
TYPE_OPTION, TYPE_MENU	0	(No. of Elements-1)
TYPE_BITFIELD	0	(No. of character positions – 1)

### 5.3.2. Final Value

The final value is the numeric value converted to user units (eg. weight in kg), but without unit or decimal places.

**Note:** These values are generally the same as the displayed value with the decimal point and units removed.

Command: CMD\_READ\_FINAL  
Return: Hexadecimal value of register without units or decimal points.  
Errors: REG\_ERR\_ACCESS\_DENIED if permission not valid.

Command: CMD\_WRITE\_FINAL  
Parameter: hexadecimal value to write to register without units or decimal points.  
Errors: REG\_ERR\_UNDER\_RANGE if new value < RangeMin.  
REG\_ERR\_OVER\_RANGE if new value > RangeMax.  
REG\_ERR\_ACCESS\_DENIED if permission not valid.  
REG\_ERR\_MENU\_IN\_USE if menu in use and attempting to write.

eg. An indicator displaying 2.345 kg Gross would return “929” when reading REG\_WEIGHT\_GROSS. Converting 929<sub>H</sub> to decimal gives 2345.

### 5.3.3. Literal Value

This is a formatted version of the Final value in a human readable form. It may be the same as the Final Value.

Command: CMD\_READ\_LITERAL

eg. The Literal value of a TYPE\_OPTION register is the string to show the current value.

### 5.3.4. Default Value

Registers can have a factory default value associated with them.

Command: CMD\_READ\_DEFAULT

### 5.3.5. Execute

This command has optional parameters that are specific to each register.

Command: CMD\_EXECUTE  
Return: Dependent on register being executed on.

For more information, refer to Execute Functions page 29.

**5.3.6. Read Items**

This command reads one item from the list for the register. The item to be read is given as a parameter to the command. Each value is returned as a string.

Command: CMD\_READ\_ITEM  
 Valid Types: TYPE\_OPTION, TYPE\_MENU, TYPE\_BITFIELD  
 Parameter: RangeMin ≤ parameter ≤ RangeMax  
 Return: String value  
 Error Code: If no parameter is present, the indicator returns ERR\_BAD\_PARAMETER.

eg. Read items 0 and 1 from REG\_DECIMAL\_PLACES

Read item 0           **200D0128:0**↵  
 Response           810D0128:000000↵  
 Read item 1           **200D0128:1**↵  
 Response           810D0128:00000.0↵



## 6. Reading Status and Error Codes

### 6.1. REG\_SYSTEM\_STATUS

This register contains status information about the indicator.

Bit(s)	Field	Description
31 to 18, 8, 5, 4	RESERVED	Reserved for future use.
17	OverLoad	The weight is above the maximum allowable weight reading.
16	UnderLoad	The weight is below the minimum allowable weight reading.
15	Error	Diagnostic error. Check REG_SYSTEM_ERROR.
14	MenuActive	Setup menus are active. Registers cannot be written to using <b>COMM</b> .
13	Calibrating	Unit is busy calibrating.
12	Motion	Weight is not stable.
11	isCOZ	The gross reading is within $\pm \frac{1}{4}$ of a division of true zero.
10	isZero	The displayed weight is within the zero 'dead' band setting.
9	DisplayNet	Display is showing NET value.
7	Output1	The setpoint weight is over the setpoint target.
6	Output2	The setpoint weight is under the setpoint target.
3 .. 0	InternalErrorCode	Used for Calibration Errors, etc.

**Table 6: Register REG\_SYSTEM\_STATUS Interpretation**

The following table lists the values that the InternalErrorCode field may take. It lists the error message that would be displayed on the indicator's display if the operation was being performed using the setup menus.

Display Message	Code Value	Description
no error	00	Last operation was successful.
(SPAN) (LO)	01	The load cell signal range (span) is too small for these settings.
(SPAN) (HI)	02	The load cell signal range (span) is too large for these settings.
(RES) (LO)	03	The scale build is configured for less than 100 graduations.
(RES) (HIGH)	04	The scale build is configured for more than 30,000 graduations.
(PT.TOO) (CLOSE)	05	An attempt has been made to place a calibration point too close to an existing calibration point.
	06	The calibration (linearisation) point does not exist.
(LIN.PT) (LO)	07	An attempt has been made to place a linearisation point below zero.
(LIN.PT) (HI)	08	An attempt has been made to place a linearisation point above fullscale.
(RES) (LO)		The scale build is configured for less than 100 graduations.
(RES) (HIGH)		The scale build is configured for more than 30,000 graduations.

Display Message	Code Value	Description
(ZERO) (LO)		An attempt has been made to calibrate zero below -2mV/V.
(ZERO) (HI)		An attempt has been made to calibrate zero above +2mV/V.

## 6.2. REG\_SYSTEM\_ERROR

This register contains the error codes as displayed on the indicator’s LCD display.

The instrument continually monitors the condition of the internal circuits. Any faults or out-of-tolerance conditions are shown on the display as an **E** type error message.

In the table below the following terms are used:

- Check: This item can be checked on site by service personnel.
- Return for Service: The instrument must be returned to the manufacturer for factory service.

Error	Description	Resolution
(E0001)	The power supply voltage is too low.	Check supply
(E0002)	The power supply voltage is too high.	Check scale / cables
(E0010)	The temperature is outside of allowable limits.	Check location
(E0020)	Scale build is incorrect. The number of graduations has been set too low or too high.	Fix up scale build
(E0100)	The digital setup information has been lost.	Re-enter setup
(E0200)	The calibration information has been lost.	Re-calibrate
(E0300)	All setup information has been lost	Enter setup and calibrate
(E0400)	The factory information has been lost.	Return for Service
(E0800)	The EEPROM memory storage chip has failed	Return for Service
(E2000)	ADC Out of Range Error. This may be caused from a broken load cell cable.	Check BUILD:CABLE setting. Check load cell cable, wiring, etc.
(E4000)	The battery backed RAM data has lost data.	Re-enter setup
(E8000)	The FLASH program memory is incorrect	Return for Service

The **E** type error messages are additive. For example if instrument is running off batteries and the temperature drops, the battery voltage may be too low. The resulting error messages will be **E 0011** (0001 + 0010). The numbers add in hexadecimal as follows:

**1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - A - B - C - D - E - F**  
 (For example, 2 + 4 = 6, or 4 + 8 = C)

## 7. Remote Key Interface

### 7.1. Operation

The indicator polls the `REG_KEYBOARD` register looking for new key presses to act upon. No new key press is indicated by a value of `KEY_NONE` in this register. After reading the value, the unit sets `REG_KEYBOARD` to its default value (`KEY_NONE`). Remote control of the indicator is achieved by writing to this register with the new key-code. Priority is given to the local keyboard and the external key-code is lost.

### 7.2. Key-Codes

Key-codes are divided into physical, logical and ASCII codes and are represented by an unsigned 16-bit value:

Code Type	RangeMin	RangeMax	Notes
ASCII	0000 <sub>H</sub>	007F <sub>H</sub>	Normal ASCII characters including <NUL> 00 <sub>H</sub>
<b>Reserved</b>	<b>0080<sub>H</sub></b>	<b>6FFF<sub>H</sub></b>	<b>Reserved for future use.</b>
Logical	7000 <sub>H</sub>	7FFF <sub>H</sub>	
Physical	8000 <sub>H</sub>	FFFF <sub>H</sub>	

Physical codes represent the physical keys on an indicator. Logical codes represent an indicator function. ASCII codes are used to enter data using device independent codes (eg. a numeric keypad could generate ASCII codes). Logical characters can be considered to include the ASCII characters as a subset. Refer to Key Codes page 41 for the list of codes.

#### 7.2.1. Physical Codes

Physical keys are numbered from 1 to 63.

Physical codes are interpreted by the indicator in a **device dependent manner**.

Physical keys consist of the `KEY_PHYSICAL` bit **ORed** with the numeric value of the key (1 to 63).

eg.  $(KEY\_PHYSICAL + 1) = 1^{st}$  physical key,  $(KEY\_PHYSICAL + 5) = 5^{th}$  physical key.

A long press is indicated by the `KEY_PHYSICAL_LONG` bit being set. If not set, it is a short press.

To handle two simultaneous physical keys being pressed (to increase the number of keys available), one key number is **ORed** into the upper byte of the keycode and the other into the lower byte. The lower numbered key is shifted into the MSByte.

eg. Physical key 1 and Physical key 2:  $(KEY\_PHYSICAL | (1 << 8) | (2))$

### 7.2.2. Example

Tare an indicator by remotely sending the **TARE** key

Command Field	12 <sub>H</sub>	<i>CMD_WRITE_FINAL</i>
Parameter Field	8003 <sub>H</sub>	<i>KEY_PHYSICAL_3</i>
Register Field	0008 <sub>H</sub>	<i>REG_KEYBOARD</i>
Complete Message	20120008:8003↵	
Sample Response	81120008:0000↵	

### 7.2.3. Logical Keys

Logical codes maintain their meaning across a range of indicators.

eg. KEY\_SETUP\_FULL

## 8. Execute Functions

Registers that respond to CMD\_EXECUTE may use the optional parameter field depending on the function involved. Execute functions are used to perform actions (eg. calibration) within the indicator, as opposed to register values that can simply be read or written (eg. changing the full-scale value).

### 8.1. Calibration

Calibration functions may take a number of seconds to complete. During this period the indicator will display a message to show that it is calibrating. When the calibration is complete, the indicator's display will return to displaying the current weight. To determine the progress of the calibration, read REG\_SYSTEM\_STATUS until the Calibrating bit is 0 (refer to REG\_SYSTEM\_STATUS page 25). Then check the InternalErrorCode field. A value of 0 indicates no errors with the last calibration. Non-zero values indicate various errors such as span high or low, etc.

Zero calibration is performed using REG\_CALIBRATE\_ZERO as shown in the table below.

Type of Calibration	Parameter	Other Registers
Zero Calibration using Test Weights	none	none
Direct mV/V Zero Calibration	(mV/V * 10,000) as hexadecimal value	none

eg. Execute a Zero calibration using test weights.

Command = 10<sub>H</sub> CMD\_EXECUTE  
 Register Id = 0102<sub>H</sub> REG\_CALIBRATE\_ZERO

Parameter Field = "" none

Remove all weight from scale

Complete Message 20100102 : ← Indicator shows "Z. in P"

Sample Response 81100102:0000 ←

Check Status by reading REG\_SYSTEM\_STATUS

Complete Message 20040021 : ←

Sample Response while calibrating 81040021:00002000 ← Indicator is Calibrating

Sample Response when complete 81040021:00000C00 ← Calibration finished, no errors

The return value of 0C00<sub>H</sub> from REG\_SYSTEM\_STATUS is described in REG\_SYSTEM\_STATUS page 25. In binary this value is 0000 1100 0000 0000<sub>b</sub> which has isCOZ=1 and isZero=1 showing that the indicator has been zeroed. InternalErrorCode field = 0 showing that the calibration was successful.

### 8.1.1. Span

Span calibration is performed using REG\_CALIBRATE\_SPAN as shown in the table below.

Type of Calibration	Parameter	Other Registers
Span Calibration using test weights	none	REG_WEIGHT_CALIBRATION
Direct mV/V Span Calibration	(mV/V * 10,000) as hexadecimal value	REG_FULLSCALE

eg. Execute a Span calibration using a scale base of 2500 g. Assume that the indicator has Units = g, Decimal Places = "000000".

```

Command      = 10H          CMD_EXECUTE
Register Id   = 0103H     REG_CALIBRATE_SPAN

Set span weight          20120100:9C4          REG_WEIGHT_CALIBRATION
Add test weights
Execute                 20100103:↵          REG_CALIBRATE_SPAN
Sample Response         81100103:0000↵      Indicator shows "S. in P"

Check Status by reading 20040021:↵
Sample Response while   81040021:00002000↵    Indicator is Calibrating
calibrating
Sample Response when complete 81040021:00000000↵ Calibration finished, no errors
    
```

InternalErrorCode field = 0 showing that the calibration was successful.

eg. Execute a Direct Span calibration at 3.0 mV/V. Assume that REG\_FULLSCALE already contains 3000 decimal.

```

Command      = 10H          CMD_EXECUTE
Register Id   = 0103H     REG_CALIBRATE_SPAN

Parameter Field = 7530H (3.0 * 10000 = 30000 decimal)

Execute with direct mV/V 20100103:7530↵      REG_CALIBRATE_SPAN
Sample Response         81100103:0000↵
Check Status            20040021:↵          REG_SYSTEM_STATUS
Sample Response         81040021:00000C00↵
    
```

InternalErrorCode field = 0 showing that the calibration was successful.

### 8.1.2. Linearisation

Adding linearisation points is similar to span calibration using test weights.

The desired weight value is written to REG\_WEIGHT\_CALIBRATION. To delete a point, set this value to zero.

Place the test weight on the scale.

Execute REG\_CALIBRATE\_LIN $x$  to add the point “ $x$ ” to the calibration points ( $1 \leq x \leq 5$ ).

Check REG\_SYSTEM\_STATUS for any errors.

eg. Assume an indicator that has been calibrated for zero and span at 3000 g. Add a linearisation point L1 at 1000g.

Write calibration weight	<b>20120100 : 3E8</b> ↵	<i>REG_WEIGHT_CALIBRATION</i>
	81060100 : 0000	
Add calibration weight		
Execute linearisation L1	<b>20040021 : </b> ↵	<i>REG_CALIBRATION_LIN1</i>
	81100104 : 0000	<i>Unit shows “L. in P”</i>
Check status	<b>20040021 : </b> ↵	
	81040021 : 00002000	<i>Busy Calibrating</i>
	<b>20040021 : </b> ↵	
	81040021 : 00000000	<i>Completed successfully</i>

eg. Deleting Linearisation point L1.

Write calibration weight	<b>20120100 : 0</b> ↵	<i>REG_WEIGHT_CALIBRATION</i>
	81060100 : 0000	
Execute linearisation L1	<b>20040021 : </b> ↵	<i>REG_CALIBRATION_LIN1</i>
	81100104 : 0000	
Check status	<b>20040021 : </b> ↵	
	81040021 : 00000000	<i>Completed successfully</i>

### 8.2. Save Settings to EEPROM

When an indicator is switched on, it retrieves the last saved settings from EEPROM. When settings are modified by writing to or executing a register, the value is not automatically saved to EEPROM. If the unit is switched off or power is interrupted, the new setting will be lost. Executing REG\_SAVE\_SETTINGS will save the current settings to EEPROM.

eg. Save settings to EEPROM.

Save Settings	<b>20100010 : </b> ↵	<i>REG_SAVE_SETTINGS</i>
	81100010 : 0000	

## 9. Streaming

### 9.1. Basic Operation

The streaming facility in the instrument allows a master (PC) to quickly read a number of registers (up to three) from a slave (indicator) with one command. REG\_STREAM\_DATA contains the **final** value for the three registers. When new weight data is available, REG\_STREAM\_DATA is updated with the latest **final** values pointed to by REG\_STREAM\_REG1 to 3.

There is a list of registers that may be streamed. REG\_STREAM\_REG1, REG\_STREAM\_REG2 and REG\_STREAM\_REG3 are used to select three registers from this list. The raw value of each REG\_STREAM\_REG1 to 3 is an index into this list.

### 9.2. Registers Available to Stream

The following table lists the registers able to be streamed:

Index into list	Reg Id
0000 <sub>H</sub>	REG_NONE
0001 <sub>H</sub>	REG_ADC_SAMPLE_NUMBER
0002 <sub>H</sub>	REG_SYSTEM_STATUS
0003 <sub>H</sub>	REG_SYSTEM_ERROR
0004 <sub>H</sub>	REG_ABSOLUTE_MVV
0005 <sub>H</sub>	REG_WEIGHT_DISPLAY
0006 <sub>H</sub>	REG_WEIGHT_USER
0007 <sub>H</sub>	REG_WEIGHT_GROSS
0008 <sub>H</sub>	REG_WEIGHT_NET
0009 <sub>H</sub>	REG_WEIGHT_TARE
000A <sub>H</sub>	REG_WEIGHT_PEAK
000B <sub>H</sub>	REG_WEIGHT_HOLD
000C <sub>H</sub>	REG_WEIGHT_TOTAL
000D <sub>H</sub>	REG_WEIGHT_LIVESTOCK
000E <sub>H</sub>	REG_WEIGHT_PT_TARE
000F <sub>H</sub>	REG_FULLSCALE



9.3. Example

Figure 8 below, demonstrates the use of the streaming registers. In this example, REG\_STREAM\_REG1 contains the value 0003<sub>H</sub>. Looking up this index into the list of registers yields REG\_SYSTEM\_ERROR. So the 1<sup>st</sup> position in REG\_STREAM\_DATA is filled in with the contents of REG\_SYSTEM\_ERROR. Similarly, REG\_STREAM\_REG2 contains 0004<sub>H</sub>, which refers to REG\_ABSOLUTE\_MVV. So the 2<sup>nd</sup> position in REG\_STREAM\_DATA is filled in with the contents of REG\_ABSOLUTE\_MVV. The 3<sup>rd</sup> position in REG\_STREAM\_DATA is filled in with the contents of REG\_ADC\_SAMPLE\_NUMBER.




Figure 8: Streaming Registers Example

```

Read Stream Register  20110040: ←
Final
Response             81110040:0000000000000123400000001 ←

Read Stream Register  20050040: ←
Literal
Response             81050040:E0000,0.4660,1 ←
    
```

# 10. Printing

## 10.1. Basic Operation

There are two non-volatile registers available for user programmable print strings. REG\_PROG\_PRINT with a capacity 80 ascii(160 hex) characters including tokens. REG\_PROG\_PRINT\_SUMMARY with a capacity of 20 ascii(40 hex) characters including tokens. The REG\_PROG\_PRINT register is used if SERIAL:FORMAT:CUSTOM is selected. when prints are activated for SERIAL:TYPE settings of AUTO, SINGLE and AUTO.PR.

When SERIAL:TYPE:PRINT is selected a short press of the print key uses REG\_PROG\_PRINT as the source for printing while the REG\_PROG\_PRINT\_SUMMARY register is used when prints are activated by a long press of the print key.

FACTRY:DEFLT resets REG\_PROG\_PRINT to the standard short print press printing, while REG\_PROG\_PRINT\_SUMMARY is reset to the standard long print press printing. Alternatively the standard formats can be set by writing the default print tokens (indicated below) to the registers REG\_PROG\_PRINT and REG\_PROG\_PRINT\_SUMMARY respectively.

## 10.2. Tokens Available for Printing

The following table lists the tokens available for printing:

Token	Corresponding Print Feature
7F <sub>H</sub>	Default Print String (short print press)
8F <sub>H</sub>	Default Print String (long print press)
CF <sub>H</sub>	Gross Weight
D0 <sub>H</sub>	Net Weight
D8 <sub>H</sub>	Tare Weight
D9 <sub>H</sub>	Display Weight
F0 <sub>H</sub>	Count (if counting is turned on)
C0 <sub>H</sub>	Time
BF <sub>H</sub>	Date
DA <sub>H</sub>	Print Identifier
E8 <sub>H</sub>	Streaming Register Literal
E9 <sub>H</sub>	Streaming Register Raw
DB <sub>H</sub>	Total Weight (total of Display Weight)
DD <sub>H</sub>	Total Count (if counting is turned on)
DC <sub>H</sub>	Items (No. of prints since last summary)

### 10.3.Examples of Operation

The following data loaded :

```
20120146:D020617420C0206F6E20BF0D0A↵
```

Would produce the printout below:

```
525 kg N at 11:04 on 03.02.2005<CR><LF>
```

To use the streaming tokens, the streaming register is first set up as described above.

Streaming to print the REG\_SYSTEM\_ERROR, REG\_ABSOLUTE\_MVV, and REG\_ADC\_SAMPLE\_NUMBER registers:

Write Stream Register 1 20120042:03↵

Write Stream Register 2 20120043:04↵

Write Stream Register 3 20120044:01↵

The “Streaming Register Raw” print token when loaded :

```
20120146:E9↵
```

Would produce the printout below on a short press of the print button, auto, single print, or auto print options:

```
000000000000138700024AED<CR><LF>
```

The “Streaming Register Literal” print token when loaded :


```
20120146:E8↵
```

Would produce the printout below on a short press of the print button, auto, single print, or auto print options:

```
E0000,0.4999,148113<CR><LF>
```

# 11. Advanced Type Handling (TYPE\_MENU)

The menu items can be accessed from the **COMM** port. Figure 9 illustrates examples of the menu levels.



**Figure 9: TYPE\_MENU Example**

## 12. Appendix – Program Constants

### 12.1. Register Types

Type	Code	Description
TYPE_CHAR	00 <sub>H</sub>	8-bit signed value (typically used for ASCII characters)
TYPE_UCHAR	01 <sub>H</sub>	8-bit unsigned value
TYPE_SHORT	02 <sub>H</sub>	Signed 16-bit value
TYPE_USHORT	03 <sub>H</sub>	Unsigned 16-bit value
TYPE_LONG	04 <sub>H</sub>	Signed 32-bit value
TYPE_ULONG	05 <sub>H</sub>	Unsigned 32-bit value
TYPE_STRING	06 <sub>H</sub>	NULL terminated string of CHAR
TYPE_OPTION	07 <sub>H</sub>	Selectable option.
TYPE_MENU	08 <sub>H</sub>	Menu type
TYPE_WEIGHT	09 <sub>H</sub>	Contains weight and status information
TYPE_BLOB	0A <sub>H</sub>	Untyped block of memory
TYPE_EXECUTE	0B <sub>H</sub>	Executable commands
TYPE_BITFIELD	0C <sub>H</sub>	Options combined into a compressed field

### 12.2. Commands

Command	Code	Description
CMD_NONE	00 <sub>H</sub>	
CMD_READ_TYPE	01 <sub>H</sub>	Read the type of a register
CMD_READ_RANGE_MIN	02 <sub>H</sub>	Read the minimum value allowed for this register
CMD_READ_RANGE_MAX	03 <sub>H</sub>	Read the maximum value allowed for this register
CMD_READ_RAW	04 <sub>H</sub>	Read internal raw value (typically for factory use only)
CMD_READ_LITERAL	05 <sub>H</sub>	Read literal value.
CMD_WRITE_RAW	06 <sub>H</sub>	Write internal raw value (typically for factory use only)
CMD_READ_DEFAULT	07 <sub>H</sub>	Read default value
CMD_READ_MENU_TEXT	09 <sub>H</sub>	Read Menu Text as used in the instrument menus
CMD_READ_ITEM	0D <sub>H</sub>	Read Item from Option list
CMD_READ_PERMISSION	0F <sub>H</sub>	Read register permission settings
CMD_EXECUTE	10 <sub>H</sub>	Execute a command on a TYPE_EXECUTE register
CMD_READ_FINAL	11 <sub>H</sub>	Read final register value
CMD_WRITE_FINAL	12 <sub>H</sub>	Write final register value

### 12.3. Error Codes

The error code returned when a command is not processed correctly is a hexadecimal value that is a combination of the following constants.

Error	Code	Description
REG_ERR_NONE	0000 <sub>H</sub>	
REG_ERR_ERROR	8000 <sub>H</sub>	Always set to show an error
REG_ERR_UNKNOWN	4000 <sub>H</sub>	Unknown error – internal use only
REG_ERR_NOT_IMPLEMENTED	2000 <sub>H</sub>	Feature not implemented on this device
REG_ERR_ACCESS_DENIED	1000 <sub>H</sub>	Action not permitted for the current access rights
REG_ERR_UNDER_RANGE	0800 <sub>H</sub>	Value less than RangeMin
REG_ERR_OVER_RANGE	0400 <sub>H</sub>	Value greater than RangeMax
REG_ERR_ILLEGAL_VALUE	0200 <sub>H</sub>	Value not compatible with data type
REG_ERR_ILLEGAL_OPERATION	0100 <sub>H</sub>	Operation not defined
REG_ERR_CANNOT_SAVE	0080 <sub>H</sub>	Write Operation failed
REG_ERR_BAD_PARAMETER	0040 <sub>H</sub>	Parameter not valid
REG_ERR_MENU_IN_USE	0020 <sub>H</sub>	Cannot modify register values while SETUP menus are active
REG_ERR_RESERVED_4	0010 <sub>H</sub>	
REG_ERR_RESERVED_3	0008 <sub>H</sub>	
REG_ERR_RESERVED_2	0004 <sub>H</sub>	
REG_ERR_RESERVED_1	0002 <sub>H</sub>	
REG_ERR_DATA_ERROR	0001 <sub>H</sub>	Internal data error

### 12.4. Register Identifiers

Register	Code	Type	Example	Description
REG_REGISTER_VERSION	0001 <sub>H</sub>	STRING	V1.0	Version of the protocol
REG_COPYRIGHT	0002 <sub>H</sub>	STRING	(C) Rinstrum 2003	Copyright message
REG_UNIT_MODEL	0003 <sub>H</sub>	STRING	R320	Model of the instrument
REG_SOFTWARE_VERSION	0004 <sub>H</sub>	STRING	V1.2	Software version
REG_UNIT_SERIAL_NO	0005 <sub>H</sub>	ULONG	3106432	Instrument Serial Number
REG_KEYBOARD	0008 <sub>H</sub>	USHORT	KEY_TARE	Write to simulate key presses
REG_DISPLAY_RAW	0009 <sub>H</sub>	BLOB	0100005B6D3F...	Contents of LCD display memory
REG_SAVE_SETTINGS	0010 <sub>H</sub>	EXECUTE		Save Settings command
REG_MENU_MAIN	0011 <sub>H</sub>	MENU		Start of menu definitions
REG_CAL_COUNT_OIML	0012 <sub>H</sub>	USHORT	00000033	OIML Calibration counter
REG_CAL_COUNT_NTEP	0013 <sub>H</sub>	USHORT	0000000D	OIML Calibration counter
REG_CFG_COUNT_NTEP	0014 <sub>H</sub>	USHORT	00000014	OIML Configuration counter
REG_ENTER_PASS_FULL	0019 <sub>H</sub>	ULONG	000004D2	Write to attempt Passcode Read is only allowed if correct Write 0 to lock instrument again
REG_ENTER_PASS_SAFE	001A <sub>H</sub>	ULONG	000009A4	
REG_ADC_SAMPLE_NUMBER	0020 <sub>H</sub>	ULONG	00169196	Counts each new reading

Register	Code	Type	Example	Description
REG_SYSTEM_STATUS	0021 <sub>H</sub>	ULONG	0000200	Instrument Status
REG_SYSTEM_ERROR	0022 <sub>H</sub>	ULONG	00000000	Instrument Error Status
REG_ABSOLUTE_MVV	0023 <sub>H</sub>	WEIGHT	00006187	Absolute signal in mV/V
REG_WEIGHT_DISPLAY	0024 <sub>H</sub>	WEIGHT	000005DC	Displayed weight reading
REG_WEIGHT_USER	0025 <sub>H</sub>	WEIGHT	000005DC	Gross or Net weight
REG_WEIGHT_GROSS	0026 <sub>H</sub>	WEIGHT	000005DC	Gross weight
REG_WEIGHT_NET	0027 <sub>H</sub>	WEIGHT	000001F4	Net weight
REG_WEIGHT_TARE	0028 <sub>H</sub>	WEIGHT	000003E8	Tare weight
REG_WEIGHT_PEAK	0029 <sub>H</sub>	WEIGHT	000009C4	Peak held weight
REG_WEIGHT_HOLD	002A <sub>H</sub>	WEIGHT	00000000	Manual held weight
REG_WEIGHT_TOTAL	002B <sub>H</sub>	WEIGHT	000009C4	Total weight reading
REG_WEIGHT_LIVESTOCK	002D <sub>H</sub>	WEIGHT	000001F4	Livestock weight
REG_WEIGHT_PT_TARE	002E <sub>H</sub>	WEIGHT	000003E8	Preset Tare weight
REG_FULLSCALE	002F <sub>H</sub>	LONG	00000BB8	Fullscale setting
REG_STREAM_DATA	0040 <sub>H</sub>	BLOB	0017ABC0000A...	Block of data selected by STREAM REGs
REG_STREAM_MODE	0041 <sub>H</sub>	OPTION		
REG_STREAM_REG1	0042 <sub>H</sub>	MENU	00000001	Index for first register data
REG_STREAM_REG2	0043 <sub>H</sub>	MENU	00000002	Index for second register data
REG_STREAM_REG3	0044 <sub>H</sub>	MENU	00000005	Index for third register data
REG_PASSCODE_FULL	00D0 <sub>H</sub>	ULONG	000004D2	Actual Full Passcode
REG_PASSCODE_SAFE	00D1 <sub>H</sub>	ULONG	000009A4	Actual Safe Passcode
REG_MENU_1 .. REG_MENU_10	00E0 <sub>H</sub> 00E9 <sub>H</sub>	MENU		Sub-menu items
REG_CAL_STAGE0	00F0 <sub>H</sub>	BLOB	3D570025000EF...	Data block for stage 0
REG_CAL_STAGE1	00F1 <sub>H</sub>	BLOB	0BA302000FFFF...	Data block for stage 1
REG_CAL_STAGE2	00F2 <sub>H</sub>	BLOB	08E000000000...	Data block for stage 2
REG_CAL_STAGE3	00F3 <sub>H</sub>	BLOB	00D8000D000E...	Data block for stage 3
REG_WEIGHT_CALIBRATION	0100 <sub>H</sub>	WEIGHT	000005DC	Weight used for calibration
REG_CALIBRATE_ZERO	0102 <sub>H</sub>	EXECUTE		Calibrate Zero command
REG_CALIBRATE_SPAN	0103 <sub>H</sub>	EXECUTE		Calibrate Span command
REG_CALIBRATE_LIN1 .. REG_CALIBRATE_LIN10	0104 <sub>H</sub> 010D <sub>H</sub>	EXECUTE		Linearisation commands
REG_ZERO_MVV	0111 <sub>H</sub>	WEIGHT	FFFFFFFF	Calibrated Zero mV/V
REG_SPAN_WEIGHT	0112 <sub>H</sub>	WEIGHT	000009C4	Calibrated Span Weight

Register	Code	Type	Example	Description
REG_SPAN_MVV	0113 <sub>H</sub>	WEIGHT	000061A8	Calibrated Span mV/V
REG_LIN1_WEIGHT .. REG_LIN10_WEIGHT	0114 <sub>H</sub> 011D <sub>H</sub>	WEIGHT	08000001	Weight at Linearisation points > 00100000 means no point
REG_RESOLUTION	0122 <sub>H</sub>	OPTION	00000000	Resolution setting
REG_DECIMAL_PLACES	0128 <sub>H</sub>	OPTION	00000000	Decimal Point position
REG_UNITS	0129 <sub>H</sub>	OPTION	00000000	Units selection
REG_CABLE_MODE	012A <sub>H</sub>	OPTION	00000000	4/6 wire operation
REG_HIRES_MODE	012B <sub>H</sub>	OPTION	00000000	High resolution (x10) mode
REG_TRADE_USE	0130 <sub>H</sub>	OPTION	00000000	Trade or Industrial operation
REG_FILTER	0131 <sub>H</sub>	OPTION	00000000	Filtering setting
REG_MOTION	0132 <sub>H</sub>	OPTION	00000000	Motion setting
REG_ZERO_RANGE	0133 <sub>H</sub>	OPTION	00000000	Zero range setting
REG_ZERO_TRACKING	0134 <sub>H</sub>	OPTION	00000000	Zero tracking setting
REG_ZERO_INIT	0135 <sub>H</sub>	OPTION	00000000	Initial zero operation
REG_ZERO_BAND	0136 <sub>H</sub>	LONG	00000000	Zero band setting
REG_AUTO_TARE_THRESH	0138 <sub>H</sub>	LONG	00000000	Automatic tare threshold
REG_SERIAL_TYPE	0140 <sub>H</sub>	OPTION	00000000	Type of serial output
REG_SERIAL_FORMAT	0141 <sub>H</sub>	OPTION	00000000	Format of serial output
REG_SERIAL_BAUD	0142 <sub>H</sub>	OPTION	00000000	Baud rate
REG_SERIAL_BITS	0143 <sub>H</sub>	BITFIELD	00000000	Parity and Stop bits
REG_SERIAL_ADDRESS	0144 <sub>H</sub>	BYTE	0000001F	Network Address
REG_PRINTER_SEQUENCE	0145 <sub>H</sub>	EXECUTE		Reset Printer Seq. command
REG_PROG_PRINT	0146 <sub>H</sub>	BLOB	00D8000D000E...	Programmable Printing Short
REG_PROG_PRINT_SUMMARY	0147 <sub>H</sub>	BLOB	00D8000D000E...	Programmable Printing Long
REG_CLOCK	0150 <sub>H</sub>	STRING	16/10/2003 10:32	Full Date/Time string
REG_CLOCK_FORMAT	0151 <sub>H</sub>	OPTION	00000000	Date format selection
REG_DATA_DD	0152 <sub>H</sub>	USHORT	00000011	Date
REG_DATA_MM	0153 <sub>H</sub>	USHORT	0000000A	Month
REG_DATE_YYYY	0154 <sub>H</sub>	USHORT	000007D3	Year
REG_TIME_HH	0155 <sub>H</sub>	USHORT	0000000A	Hour
REG_TIME_MM	0156 <sub>H</sub>	USHORT	00000020	Minute
REG_TIME_SS	0157 <sub>H</sub>	USHORT	00000015	Second
REG_KEY_LOCK	0160 <sub>H</sub>	BITFIELD	00000000	Key locking
REG_USER_KEY_FUNC	0161 <sub>H</sub>	OPTION	00000000	Special Function setting
REG_AUTO_OFF_TIME	0162 <sub>H</sub>	OPTION	00000000	Auto power off setting
REG_BACKLIGHT	0163 <sub>H</sub>	OPTION	00000000	Backlight options
REG_REMOTE_KEY_FUNC	0164 <sub>H</sub>	OPTION	00000000	Remote key function setting
REG_SETPT_TYPE_1	0170 <sub>H</sub>	OPTION	00000000	Setpoint 1 Type



Register	Code	Type	Example	Description
REG_SETPT_SRC_1	0171 <sub>H</sub>	OPTION	00000000	Data Source Setpoint 1
REG_SETPT_TARGET_1	0172 <sub>H</sub>	LONG	000003E8	Setpoint 1 Target
REG_SETPT_TYPE_2	0173 <sub>H</sub>	OPTION	00000000	Setpoint 2 Type
REG_SETPT_SRC_2	0174 <sub>H</sub>	OPTION	00000000	Data Source Setpoint 2
REG_SETPT_TARGET_2	0175 <sub>H</sub>	LONG	000003E8	Setpoint 2 Target
REG_COUNT_QTY	0180 <sub>H</sub>	ULONG	0000000A	Counting sample quantity
REG_OVERLOAD_COUNT	0181 <sub>H</sub>	ULONG	0000000D	Input Overload Count
REG_CLEAR_OVERLOAD	0182 <sub>H</sub>	EXECUTE		Reset Input Overload Count

12.5. Key Codes

Key Code	Code	Description
KEY_NONE	0000 <sub>H</sub>	No key pressed
KEY_SETUP_FULL	7001 <sub>H</sub>	Access to Full setup menu
KEY_SETUP_SAFE	7002 <sub>H</sub>	Access to Safe setup menu
KEY_ZERO	7201 <sub>H</sub>	Zero function
KEY_TARE	7202 <sub>H</sub>	Tare function
KEY_GROSS_NET	7203 <sub>H</sub>	Gross/Net function
KEY_PRINT	7204 <sub>H</sub>	Print function
KEY_USER_FN1	7205 <sub>H</sub>	User F1 function
KEY_POWER_ON	7301 <sub>H</sub>	Power key press
KEY_POWER_OFF	7302 <sub>H</sub>	Power Off function
KEY_PHYSICAL_1 .. KEY_PHYSICAL_20	8001 <sub>H</sub> 8014 <sub>H</sub>	Physical key codes. Eg. Key 1 = Power, Key 2 = Zero etc.
KEY_PHYSICAL_1 .. KEY_PHYSICAL_2	8081 <sub>H</sub> 8094 <sub>H</sub>	Long presses (> 2 seconds) of the Physical keys

12.6. Decimal, Binary and Hexadecimal Conversion

Decimal (radix 10)	Binary (radix 2)	Hexadecimal (radix 16)
0	0000 0000 <sub>b</sub>	00 <sub>H</sub>
1	0000 0001 <sub>b</sub>	01 <sub>H</sub>
2	0000 0010 <sub>b</sub>	02 <sub>H</sub>
3	0000 0011 <sub>b</sub>	03 <sub>H</sub>
4	0000 0100 <sub>b</sub>	04 <sub>H</sub>
5	0000 0101 <sub>b</sub>	05 <sub>H</sub>
6	0000 0110 <sub>b</sub>	06 <sub>H</sub>
7	0000 0111 <sub>b</sub>	07 <sub>H</sub>
8	0000 1000 <sub>b</sub>	08 <sub>H</sub>
9	0000 1001 <sub>b</sub>	09 <sub>H</sub>
10	0000 1010 <sub>b</sub>	0A <sub>H</sub>
11	0000 1011 <sub>b</sub>	0B <sub>H</sub>
12	0000 1100 <sub>b</sub>	0C <sub>H</sub>
13	0000 1101 <sub>b</sub>	0D <sub>H</sub>
14	0000 1110 <sub>b</sub>	0E <sub>H</sub>
15	0000 1111 <sub>b</sub>	0F <sub>H</sub>
16	0001 0000 <sub>b</sub>	10 <sub>H</sub>
17	0001 0001 <sub>b</sub>	11 <sub>H</sub>
18	0001 0010 <sub>b</sub>	12 <sub>H</sub>
...	...	...
254	1111 1110 <sub>b</sub>	FE <sub>H</sub>
255	1111 1111 <sub>b</sub>	FF <sub>H</sub>

Table 7: Decimal, Binary and Hexadecimal Conversion

## 12.7. Setup and Calibration Errors

These messages show status messages or errors that may occur during the instrument setup and calibration.

Error	Description	Resolution
(ENTRY) (DENIED)	The instrument may be in Safe Setup and an item that needs Full Setup has been selected for editing.	Access Full Setup to edit the item.
	When accessing setup, more than three attempts have been made with the incorrect passcode.	Turn the instrument off. When the instrument is turned back on, enter the correct passcode to access setup.
(LIN.PT) (LO)	An attempt has been made to place a linearisation point below zero.	Incorrect linearisation point entered (must be between zero and full scale).
(PT.TOO) (CLOSE)	An attempt has been made to place a calibration point too close to an existing calibration point.	Re-enter the calibration point. Points must be spaced by at least 2% of full scale from each other.
(RES) (LO)	The scale build is configured for less than 100 graduations.	Check the resolution (count-by) and capacity settings.
(RES) (HIGH)	The scale build is configured for more than 30,000 graduations.	Check the resolution (count-by) and capacity settings.
(SPAN) (LO)	The load cell signal range (span) is too small for these settings.	Incorrect span weight entered (must be between zero and full scale). Scale wiring incorrect. Wrong load cell capacity (too large). Wrong or no calibration weight added to scale.
(SPAN) (HI)	The load cell signal range (span) is too large for these settings.	Incorrect span weight entered (must be between zero and full scale). Scale wiring incorrect. Load cell capacity too small for application.
(ZERO) (LO)	An attempt has been made to calibrate zero below -2mV/V.	Scale wiring incorrect
(ZERO) (HI)	An attempt has been made to calibrate zero above +2mV/V.	Remove all weight from scale. Scale wiring incorrect.

**12.8. Glossary Terms**

<b>Term</b>	<b>Definition</b>
Calibration Parameter	An adjustable parameter that can affect measurement or performance accuracy and, due to its nature, needs to be updated on an ongoing basis to maintain device accuracy, eg., span adjustments, linearisation factors, and coarse zero adjustments
<b>COMM</b>	The communications protocol used to communicate with the R300 Series
Configuration Parameter	An adjustable or selectable parameter for a device feature that can affect the accuracy of a transaction or can significantly increase the potential for fraudulent use of the device and, due to its nature, needs to be updated only during device installation or upon replacement of a component, eg., division value (increment), sensor range, and units of measurement.
Count-by	The smallest change in weight units that the display can show. See also Resolution.
CRC	Cyclic Redundancy Check
Division	A single graduation.
EEPROM	Electrically Erasable Programmable Read-Only Memory
FIR	Finite Impulse Response
Full Scale	The maximum gross weight allowed on the scale. This is used to detect overload and underload conditions, etc.
Graduations	The maximum number of display steps between zero gross load and full capacity gross load. It is equal to the full scale divided by the resolution.
LED	Light Emitting Diode
NTEP	National Type Evaluation Program
OIML	International Organization of Legal Metrology
opto-LINK Cable	opto-isolated infrared communications link cable
PLC	Programmable Logic Controller
Range	Total change in weight between zero gross load and full capacity gross load (ie. the nominated total capacity of the scale). It is always given in displayed weight units.
Register	
Resolution	The smallest change in weight units that the display can show. See also Count-by.
Ring Network	A network of up to 31 Instruments connected to a central computer
RS-232	Standard for communications hardware layers.
Step-Response	The step-response is the time between placing a weight on the scale and the correct weight reading being displayed.
Transients	A temporary voltage oscillation or spike caused by a sudden change of load (or other external influence).
Units	The actual units of measurement (kilograms, tonnes, pounds, etc.).

**12.9. List of Figures**

Figure 1: Weight Indicator..... 4  
 Figure 2: RS-232 — One Instrument to PC using COM Port (DB9)..... 7  
 Figure 3: RS-232 – One Instrument to PC using COM Port (DB25)..... 7  
 Figure 4: RS-232 Short Cable Runs: Ring Network using COM Port (DB9) ..... 8  
 Figure 5: RS-232 Long Cable Runs: Ring Network using COM Port (DB9) ..... 9  
 Figure 6: Commonly used Registers and Commands..... 11  
 Figure 7: RS-232 Ring Network: Example with Two Instruments ..... 13  
 Figure 8: Streaming Registers Example..... 33  
 Figure 9: TYPE\_MENU Example ..... 36

**12.10. List of Tables**

Table 1: opto-LINK vs RS-232 port ..... 10  
 Table 2 COMM Command Format ..... 14

Table 3 COMM Response Format ..... 14  
Table 4 COMM Command Format with Ring Network Enhancement..... 16  
Table 5 COMM Response Format with Ring Network Enhancement ..... 16  
Table 6: Register REG\_SYSTEM\_STATUS Interpretation ..... 25  
Table 7: Decimal, Binary and Hexadecimal Conversion..... 42

## 13. Index

- Audience, 3
- Calibration, 28
- COMM, 10
- COMM Message Structure, 13
- COMM Protocol Summary, 10
- Communications Manual, 4
- Counters, Calibration and Configuration, 19
- Document Conventions, 4
- Error Codes, 24
- Error Handling, 16
- Example Ring Network, RS-232, 12
- Examples
  - Keypress, Remote, 11
  - Linearisation, 30
  - Reading Weight, 11
  - Save Settings, 30
  - Setting Values, 11
  - Span Calibration, 29
  - Streaming, 32
  - Zero Calibration, 28
- Execute
  - Save Settings, 30
- Execute Functions, 28
- Field
  - Address, 14
  - Command, 14
  - Optional Parameters, 15
  - Register Id, 15
- Glossary of Terms, 43
- GROSS/NET Key, 5
- Key-Codes, 26
- Keypress, Remote, 26
- Linearisation, 30
- Logical Keys, 27
- Message Structure, 13
- Operator Manual, 4
- opto-LINK, 5
- opto-LINK Activation, 5
- opto-LINK Communications Settings, 5
- Physical Codes, 26
- Printing
  - Counting Sample, 34
- Program Constants
  - Commands, 36
  - Decimal, Binary, Hexidecimal Conversion, 41
  - Error Codes, 37
  - Key Codes, 40
  - Register Identifiers, 37
  - Register Types, 36
  - Setup and Calibration Errors, 42
- Protocol Structure, 13
- Protocol Summary, 10
- Quick Start Manual, 4
- Reading Status, 24
- Reference Manual, 4
- Register
  - Execute, 22
  - Items, 23
  - List of Types, 17
  - Permissions, 18
  - Register Properties
    - Default Value, 22
    - Final Value, 22
    - Literal Value, 22
    - Menu Text, 20
    - Permission, 21
    - RangeMax, 21
    - RangeMin, 21
    - Type, 20
  - Remote Tare, 27
  - Return Value, 15
  - Ring Network Enhancement, 11, 15
  - Ring Network Example, RS232, 12
  - RS-232, 6, 10
  - RS-232 Communications Settings, 6
  - RS-232 Ring Network Example, 12
  - Save Settings, 30
  - Serial PC Link, 6, 7
  - Span, 29
  - Streaming, 31, 33, 34
  - Type Menu, 35
  - Viewer, 3
  - ViewR300, 10

Notes:

Notes:



Notes: