


SMART WEIGHING SOLUTIONS



rinstrum

400 Series

(K481)

**Summing Indicator
Reference Manual**

R400-623-150

Copyright

All Rights Reserved. No part of this document may be copied, reproduced, republished, uploaded, posted, transmitted, distributed, stored in or introduced into a retrieval system in any form, or by any means (electronic, mechanical, photocopying, recording or otherwise) whatsoever without prior written permission of Rinstrum Pty Ltd.

Disclaimer

Rinstrum Pty Ltd reserves the right to make changes to the products contained in this manual in order to improve design, performance or reliability.

The information in this manual is believed to be accurate in all respects at the time of publication but is subject to change without notice. Rinstrum Pty Ltd assumes no responsibility for any errors or omissions and disclaims responsibility for any consequences resulting from the use of the information provided herein.

Table of Contents

1.	INTRODUCTION	5
1.1.	Overview	5
1.2.	Document Conventions	6
2.	SPECIFICATIONS.....	7
3.	INSTALLATION	9
3.1.	Introduction	9
3.2.	General Warnings	9
3.3.	Electrical Safety.....	9
3.4.	Cleaning	9
3.5.	Panel Mount Template	9
3.6.	Cable Connections	10
3.7.	DC Power (DC PWR +, DC PWR –)	10
3.8.	Summing Slave Serial Connection	10
3.9.	Load Cell Connection	11
3.10.	Auxiliary Connections	11
3.10.1.	RS-232 Serial	11
3.10.2.	RS-485 Serial	12
3.11.	Optical Communications.....	12
3.12.	Connecting Shields.....	14
3.12.1.	Cable Shield Connection and Earthing	15
3.13.	Regulatory Sealing Requirements	15
3.14.	Accessory Module connection	15
4.	USING SETUP MENUS.....	17
4.1.	Accessing Setup Menus	17
4.1.1.	Setup Display Prompts	18
4.2.	Exiting Full or Safe Setup	18
4.3.	Menu Navigation	18
4.4.	Changing Data	19
4.5.	Numeric Entry.....	19
4.6.	Selections and Options.....	19
4.7.	Strings.....	20
4.7.1.	Normal String Editing.....	20
4.7.2.	Numerical String Editing	21
4.7.3.	ASCII String Editing.....	21
5.	BASIC OPERATION	22
5.1.	User Interface Display and Controls	22
5.1.1.	Overview	22
5.1.2.	Display	23
5.1.3.	Primary Annunciators	23
5.1.4.	Keypad	24
5.2.	Operation Keys.....	25
5.2.1.	Power Key	25
5.2.2.	Zero Key.....	26
5.2.3.	Tare Key.....	26
5.2.4.	Gross/Net Key	27
5.2.5.	Function Keys.....	27
5.2.6.	Up, Down, OK keys: Products	28
5.2.7.	Clock	30
5.2.8.	View	31
5.2.9.	Report	31
5.2.10.	Total	32
5.2.11.	User ID	32
5.2.12.	Target.....	33
5.2.13.	Lock.....	33
5.2.14.	Alibi	34
5.2.15.	Acc	34
5.2.16.	Stability Considerations	34

6.	CONFIGURATION	35
6.1.	General Setup Information.....	35
6.2.	Calibration Counter.....	35
6.3.	Passcodes.....	35
6.3.1.	Full Setup Passcode.....	35
6.3.2.	Safe Setup Passcode.....	35
6.3.3.	Operator Passcode.....	35
6.3.4.	Setup Lock-Out.....	36
7.	SUMMING SETUP	37
7.1.	Wiring Diagram.....	37
7.2.	Configuring the Slave R300 or R400 Indicators.....	37
7.2.1.	Slave Calibration.....	37
7.2.2.	R320 Slave Configuration.....	37
7.2.3.	R420 Slave Configuration.....	37
7.3.	Basic Configuration of the K481 Summing Indicator.....	38
7.4.	Slave Name Configuration of the K481 Summing Indicator.....	38
7.5.	Subtotal Configuration of the K481 Summing Indicator.....	38
8.	SETUP MENUS	39
8.1.	GEN.OPT (General options).....	39
8.1.1.	LANG (Operator language).....	39
8.1.2.	DATE.F (Date format).....	39
8.1.3.	PCODE (Security passcodes).....	39
8.1.4.	KEY.LOC (Key Function Access Control).....	40
8.1.5.	DISP (Display options).....	40
8.1.6.	ID.NAME (User Defined Strings).....	41
8.1.7.	POWER (Power options).....	41
8.1.8.	STR.EDT (String Edit Mode).....	41
8.1.9.	USR.DEF (Set all non-calibration settings to defaults).....	42
8.2.	H.WARE (Hardware Configuration & Test).....	42
8.2.1.	SER1.HW, SER2.HW.....	42
8.2.2.	IO.HW.....	43
8.2.3.	ANL.HW.....	43
8.2.4.	ETH.HW.....	44
8.2.5.	ETH.DEF (Set the M4221 Ethernet module to defaults).....	44
8.2.6.	DSD.HW.....	46
8.3.	SCALE (scale setup options).....	46
8.3.1.	OPTION (Scale options).....	46
8.3.2.	SUB.NUM (Number of subtotals).....	47
8.3.3.	S.TOT.x (Subtotal settings).....	47
8.4.	FUNC (Special functions).....	47
8.4.1.	NUM (Number of special functions).....	47
8.4.2.	SFn: TYPE (Function Types).....	48
8.4.3.	SFn: KEY (Function Key / Remote Input).....	48
8.4.4.	SFn: PRINT (Printing Functions).....	49
8.4.5.	SFn: SINGLE (Single Serial Output Functions).....	50
8.4.6.	SFn: BLANK (Blanking Functions).....	50
8.4.7.	SFn: PRD.SEL (Product Select).....	50
8.4.8.	SFn: THUMB (Thumbwheel Product Selection).....	52
8.4.9.	SFn: REM.KEY (Remote Key Functions).....	52
8.4.10.	SFn: REPORT (Report Printing Functions).....	52
8.4.11.	SFn: SC.EXIT (Scale Exit).....	53
8.4.12.	SFn: SLAVE (Display slave and subtotal weights).....	53
8.4.1.	SFn: A.TARE (Auto Tare).....	53
8.5.	SER.SUM (Serial summing configuration).....	54
8.5.1.	SERIAL (Summing serial port).....	54
8.5.2.	PROTO (Summing serial protocol).....	54
8.5.3.	SLAVES (Number of slaves to sum).....	54
8.5.4.	NAME (Naming for individual slaves).....	54
8.6.	SER.NET (Network communications).....	55
8.7.	SER.AUT (Automatic transmit).....	56
8.7.1.	NUM (Number of Automatic Transmissions).....	56

8.7.2.	AUTO.n (Automatic Output Configuration)	56
8.8.	PRINT (Printouts)	57
8.8.1.	NUM (Number of printouts)	57
8.8.2.	HEADER (Print header)	57
8.8.3.	FOOTER (Print footer)	57
8.8.4.	PAGE (Print page options)	57
8.8.5.	SPACE (Print blank space options)	58
8.8.6.	PRINT.n ... (Printout options)	59
8.9.	SETP (Setpoints)	60
8.9.1.	NUM (Number of setpoints)	60
8.9.2.	SETP1 ... SETP16 (Setpoint options)	60
8.10.	ANL.OUT (Analogue Output)	63
8.11.	End (Save and exit)	63
9.	NETWORK COMMUNICATIONS	64
9.1.	Introduction	64
9.2.	Network rinCMD	64
9.2.1.	Basic Message Format	64
9.2.2.	Termination	65
9.2.3.	Error Handling	66
9.2.4.	Ring Network Enhancement	66
9.3.	Network Protocol SIMPLE	67
9.4.	Network Protocol BARCODE	67
9.5.	rinCMD Examples	68
10.	AUTOMATIC WEIGHT OUTPUT	70
10.1.	Overview	70
10.2.	Auto Weight Format String	70
11.	PRINTING	72
11.1.	Overview	72
11.2.	Print ID	72
11.3.	Record printouts	72
11.4.	Docket printouts	72
11.5.	Report printouts	73
11.6.	Custom Printing	74
11.6.1.	Page Tokens	75
12.	SPECIAL FUNCTIONS	76
12.1.	Introduction	76
12.2.	Key Functions	76
12.2.1.	NONE	76
12.2.2.	PRINT	76
12.2.3.	SINGLE	77
12.2.4.	TEST	77
12.2.5.	PRD.SEL	78
12.2.6.	SLAVE	79
12.2.7.	SC.EXIT	79
12.2.8.	A.TARE	79
13.	SETPOINTS	80
13.1.	Overview	80
13.2.	Outputs	80
13.3.	Common Settings	80
13.4.	Weigh in (OVER) Setpoints and Weigh Out (UNDER) Setpoints	81
13.4.1.	Additional Settings	83
13.5.	Status Based Setpoint Types	83
13.6.	Logic Setpoint Types	84
13.7.	Scale Entry/Exit Setpoint Types	87
14.	ANALOGUE OUTPUT	88
14.1.	Overview	88
14.2.	Configuration of Hardware	88
14.2.1.	Configuration	88
14.2.2.	Calibration	88
14.2.3.	Testing	88

14.3.	Analogue Weight Transmission	88
15.	APPENDIX 1: DIMENSIONS	89
15.1.	Dimensions	89
15.2.	Legal Sealing Details	91
15.2.1.	Trade Label	91
15.2.2.	Lead Seals	92
15.2.3.	Destructible Sticker Seals	93
15.2.4.	Electronic Seal	93
16.	APPENDIX 2: PRINT AND AUTOMATIC TRANSMISSION TOKENS	94
16.1.	ASCII codes	94
16.2.	Use of Characters in the Extended ASCII table	94
16.3.	Tokens	95
16.3.1.	Non-paged generic tokens	95
16.3.2.	Page tokens	95
16.3.3.	Page 0, 1, 2, 3, 7 tokens: Weight Information	96
16.3.4.	Page 4, 5, 6 tokens: Product Information	97
16.3.5.	Page 8 tokens: Miscellaneous weight data	97
16.3.6.	Format tokens	98
16.3.7.	Page 9 Tokens: Summing Information	99
17.	APPENDIX 3: COMMUNICATIONS REGISTERS	100
18.	APPENDIX 4: SETUP MENU QUICK REFERENCE	106
19.	APPENDIX 5: ERROR MESSAGES	108
19.1.	Overview	108
19.2.	Weighing Errors	108
19.3.	Setup Errors	109
19.4.	Diagnostic Errors	110
20.	GLOSSARY	111
20.1.	Glossary of Terms	111
20.2.	List of Figures	112
20.3.	List of Tables	112
21.	INDEX	113

1. Introduction

1.1. Overview

This precision digital summing indicator can sum up to nine slave indicators from either the R300 or R400 range. These can be connected together on a multi-drop serial RS485 bus or RS232 ring network. The summing indicator polls each of the slave units summing all of the weight readings and displays the resulting total weight. The setpointing, printing facilities, and accessory modules are all driven from the total weight. The summing indicator will show an error message (-----) if any of the slave weights are negative or if there is a mix of gross and net weights, as defined by Technical Schedule S1/0/A. If all slave units are showing net weight, the summing indicator will show a net total. Facilities are provided to view and use individual slave weights and sub totals of a subset of the slave weights.

The setup of the instrument is digital, with a non-volatile security store for all setup parameters. It may be operated from either a DC power source (12VDC to 24VDC) or AC power (optional 110 – 240 VAC). There is a soft power on/off function that retains memory of its state. Once an instrument is turned on it will automatically start up again if the external power is interrupted.

Optical communications are fitted standard and allows for a temporary isolated communications link to be established with a PC. Software upgrades and the use of computerised setup can then be done using a PC. Refer to Optical Communications on page 12 for more information.



Figure 1: Weight Indicator

The instrument provides zero, tare and gross/net on the fixed function keys and supports special functions (e.g. Toggle slave weights and blanking), via three (3) user definable function keys and external inputs. Operator functions (clock, view, report etc) and editing functions are provided on the alpha/numeric key pad. It is equipped with an NVRAM store to ensure day-to-day operating settings (e.g. CLOCK) are retained when power is removed.

The RS-232 communications port is typically used for communicating with the slave indicators. It can also be used for printer driving, connection to a remote display or PC when an optional serial module is used for the slave communications. The transmit-only RS-485 communications port can be used for remote displays. There is a built-in clock for date-stamping printed outputs.

The instrument can support different software applications depending on the functionality required. This manual covers the K481 summing indicator. Please refer to the relevant manual for the slave indicators.

1.2. Document Conventions

The following document conventions (typographical) are used throughout this Reference Manual.

Bold Text	Bold text denotes words and phrases to note.
<Key>	<Key> denotes a Keypad key. Note: In the Specifications section the < symbol means less than and the > symbol means greater than .
^	This symbol denotes one space when describing serial output formats.
⊗	Items marked with ⊗ indicate that the setting is available only in Full Setup and is trade critical. When trade critical settings are changed, the calibration counter is incremented.

Table 1: Document Conventions

2. Specifications

Performance					
Operating Environment	Temperature: -10 to +50°C ambient Humidity: <90% non-condensing Storage: -20 to +50°C ambient IP55 when panel mounted or with rear boot (otherwise IP40)				
Case Materials	ABS, Silicon Rubber, Nylon, Acrylic (no halogen used)				
Packing Weights	Basic Indicator: 0.6kg				
Digital					
Display	LCD with 4 alpha-numeric displays and LED backlighting: <ul style="list-style-type: none"> • Primary display: 6 x 28.4mm high digits with units and annunciators • 2nd display: 9 x 17.6 mm digits with units • 3rd display: 8 x 6. 1mm digits • 4th display: 4 x 7.6 mm digits 				
Setup	Full digital with visual prompting in plain messages				
Power Input					
Standard Power	12 to 24VDC (15 VA max) - ON/OFF key with memory feature				
Variants	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; vertical-align: top;">AC M4101</td> <td>Input: 110/240VAC 50/60Hz Output: 12VDC 15VA</td> </tr> <tr> <td style="vertical-align: top;">Battery M4102</td> <td>Rechargeable NiMH battery, 12V, 2.5Ah</td> </tr> </table>	AC M4101	Input: 110/240VAC 50/60Hz Output: 12VDC 15VA	Battery M4102	Rechargeable NiMH battery, 12V, 2.5Ah
AC M4101	Input: 110/240VAC 50/60Hz Output: 12VDC 15VA				
Battery M4102	Rechargeable NiMH battery, 12V, 2.5Ah				
Features					
Optical Data Communications	Magnetically attached optical communications support. Optional conversion cable connects directly to a standard RS-232 or USB port.				
Serial Communications	RS-232 serial port for remote display, network or printer supports. RS-485 transmit only for remote display Transmission rate: 1200, 2400, 4800, 9600, 19200 or 57600 baud				
3 assignable function keys	Printing, slave weights, and totalising				
Battery Backed Clock Calendar	Battery life 10 years minimum				
Approvals	FCC, CE, C-tick Check trade approvals				

Software	V1	V2
Summing Slaves	9	9
Summing Subtotals	4	4
Input/Outputs	32	32
Setpoints	8	16
External Keys	8	8
Assignable Functions	8	8
Analogue Output	1	1
Communication 1xRS232 Duplex and 1xRS485 TX only	✓	✓
Additional Communications Modules	✓	✓
Products	10	250
Automatic Output	2	2
Automatic Output – Custom format	✓	✓
Single Automatic Output	✓	✓
Printouts	2	2
Custom Printouts	✓	✓
Report Printing	✓	✓

Table 2: Instrument specifications

3. Installation

3.1. Introduction

The following steps are required to set up the indicator.

- Inspect indicator to ensure good condition.
- Use connection diagrams to wire up slave indicator serial connections, power and auxiliary cables as required.
- Use the drill hole template provided for hole locations.
- Connect power to indicator and press **<POWER>** key to turn the instrument ON.
- Refer to the Setup section page 39 for information on configuring the instrument.
- To turn instrument OFF press and hold **<POWER>** key for three seconds (until display blanks).

3.2. General Warnings

- Indicator not to be subject to shock, excessive vibration, or extremes of temperature (before or after installation).
- Inputs are protected against electrical interference, but excessive levels of electro-magnetic radiation and RFI may affect the accuracy and stability.
- The instrument should be installed away from any sources of excessive electrical noise.
- For full EMC or for RFI immunity, termination of cable shields and correct earthing of the instrument is essential.

3.3. Electrical Safety

- For your protection all mains electrical hardware must be rated for environmental conditions of use.
- Pluggable equipment must be installed near an easily accessible power socket outlet.
- To avoid the possibility of electric shock or damage to the instrument, always switch off or isolate the instrument from the power supply before maintenance is carried out.

3.4. Cleaning

- To maintain the instrument, never use harsh abrasive cleaners or solvents. Wipe the instrument with a soft cloth **slightly** dampened with warm soapy water.

3.5. Panel Mount Template

The panel mount template is supplied with the instrument. It shows the location of the rectangular cut-out and the four mounting screws.

3.6. Cable Connections

All cable connections are made to the rear of the instrument using pluggable screw terminals. It is not necessary to tin the ends of the wires with solder or to add crimp ferrules to the wires, however, these techniques are compatible with the terminals.




Figure 2: Cable Connections


3.7. DC Power (DC PWR +, DC PWR -)

The DC supply need not be regulated, provided that it is free of excessive electrical noise and sudden transients. The instrument can be operated from a high-quality plug-pack as long as there is sufficient capacity to drive it.


3.8. Summing Slave Serial Connection

◆ Summing R420 Indicators using RS485

When summing using this configuration, a M4203 module is required for the master and each slave.



◆ Summing R320 Indicators using RS232 Ring Network



3.9. Load Cell Connection

As this is a summing indicator, the loadcell connection is not required and should not be connected.

3.10. Auxiliary Connections

This section provides diagrams to illustrate the communication connections.

3.10.1. RS-232 Serial

◆ Direct Personal Computer Link (RX, TX, GND)




Figure 3: RS-232 - Instrument to PC using COM Port (DB9)

◆ **Printer Connections (TX, DTR and GND)**




Figure 4: RS-232 – Instrument to Printer (DB25)

◆ **Remote Display (TXD, GND)**

Refer to documentation supplied with the Remote Display for connection details. Connect RX on the Remote Display with TX on the instrument and connect the RS232 GND signals together.

3.10.2. RS-485 Serial

◆ **Remote Display (TA, TB)**

RS485 is recommended for communicating over distances longer than a few metres. Connect TA to RA and TB to RB on the remote display.

3.11. Optical Communications

A temporary infrared communications link can be established between the instrument and a PC using an optional cable. This connection can be used to transfer setup information from a PC or to download software upgrades.

The PC end of the cable is a standard female DB9 RS232 connector or a USB connector. The instrument end of the cable attaches to the left side of the instrument display.

WARNING

The optical coupling head contains a strong magnet and should not be placed near any magnetic storage media (e.g. credit cards, floppy disks, etc.)



Figure 5: Optical Communications attachment

3.12. Connecting Shields

To obtain full EMC or for RFI immunity, cable shields **MUST** be connected and the earth lug on the rear of the instrument must be grounded.

Figure 6 illustrates an example of possible connections. Also shown are the connecting cables restrained using cable ties fastened by screws into the rear of the unit.




Figure 6: Cable Shield Connection

3.12.1. Cable Shield Connection and Earthing

- Care should be taken when connecting shields to maximise EMC or RFI immunity and minimise earth loops and cross-talk (interference) between instruments.
- For full EMC or for RFI immunity, termination of the cable shields to the connectors is very important. The earth lug of the instrument must be separately connected to ground potential via a reliable link.
- The AC power module directly connects the earth lug to the Earth Pin on the power supply. In installations where earth is available on the power cable, instrument earthing can be done with this connection.
- The instrument should only be connected to earth via a single reliable link to avoid earth loops.
- Where each instrument is separately earthed, interconnecting cable shields should be connected at one end only.

3.13. Regulatory Sealing Requirements

To comply with regulatory sealing requirements for each instrument, (i.e. to ensure instruments are not accidentally or deliberately tampered with), it is important that proper sealing procedures be adhered to. Refer to Legal Sealing page 91 for more information.

3.14. Accessory Module connection

Up to 4 accessory modules can be plugged into the rear of the instrument. There are many types of modules which can be used. These modules provide additional features such as:

- power supply options, e.g. mains power or batteries
- communications ports, e.g. RS485 networking
- analogue outputs, e.g. 4-20mA or 0-10V
- digital inputs and digital outputs, e.g. external buttons or setpoint outputs
- expanded memory, e.g. DSD functionality.


Caution: The instrument should be switched off before connecting or disconnecting accessory modules.

Each module will come with a manual which explains the features, installation and use of the module.

After connection, the module needs to be configured using the instrument setup menus. All hardware test functions and hardware options (such as serial baud rates or digital input debouncing) are in the H.WARE (hardware) menu described in section **Error! Reference source not found.** page **Error! Bookmark not defined.** Module resources (such as digital inputs or serial ports) are assigned in specific function menus. For example, the output used by a particular setpoint is set in the setpoint menu.

A summary of the module resource usage is available in the instrument setup menus. See **Error! Reference source not found.** described in section **Error! Reference source not found.** page **Error! Bookmark not defined.**

Note: Power supply options can only be connected in the left position. Other modules can be connected in any position.



4. Using Setup Menus

Throughout the setup menus different data entry methods are used. Each method is described below.

4.1. Accessing Setup Menus


There are two methods to access the Setup area:

- The **Full Setup** method provides access to all functions in Setup, including legal for trade settings. Changes in Full Setup mode may result in the calibration counter being incremented. If an attempt is made to enter Full Setup using the incorrect passcode, the instrument will respond with the message **ENTRY DENIED**. Refer to Passcodes page 35 for more information.

Full Setup

There are 2 methods of accessing full setup:

1. Press and hold the **<POWER>** and **<F3>** keys together for two seconds, or
2. Press the setup button on the rear of the instrument.




WARNING

All items in all menus will be enabled in **Full Setup**. Care should be taken to avoid inadvertently altering the legal for trade settings.

- **Safe Setup** restricts access to the Trade Critical settings. Changes made in this mode will not increment the calibration counter. In this manual, items marked with ⊗ indicate that the setting is trade critical. If an attempt is made to enter Safe Setup using the incorrect passcode, or if an attempt is made to alter a trade critical setting while in Safe Setup, the instrument will respond with the message **ENTRY DENIED**. Refer to Passcodes page 35 for more information.

Safe Setup

Press and hold both the **<POWER>** and **<ZERO>** keys together for two seconds.



4.1.1. Setup Display Prompts

When accessing **Full** or **Safe Setup** the instrument will beep twice and enter the Setup Menus. If a passcode has been configured, the **P.CODE** prompt will display and the correct passcode must be entered to continue. Refer to Passcodes page 35 for more information.

If access is granted the following is displayed:

FULL (SAFE) → SETUP → Software Version (e.g. V1.0) → Serial Number
→ Calibration Counter (e.g. C.00010).

(See Calibration Counter page 35 for more information)

4.2. Exiting Full or Safe Setup

To save settings, exit setup and return to the normal weighing mode use one of the following methods:

Method 1: Press and hold both the <POWER> and <F3> keys together for two seconds.
--

Method 2: Press and hold both the <POWER> and <ZERO> keys together for two seconds.
--

Method 3: Press the <ZERO> key repeatedly. When End displays press <TARE> .

Method 4: Press the <POWER> key.
--

The instrument will beep and then display the following:

Software Version (e.g. V1.0) → Calibration Counter (e.g. C.00010).

(See Calibration Counter page 35 for more information)


Warning: If the power is interrupted while in setup (i.e. by disconnecting the power cable), unsaved settings will be lost.

4.3. Menu Navigation

The setup menus are a normal menu tree structure. The current level is shown in the auxiliary display in the top right corner of the LCD.

Each level of the tree has its own key to step through the items in the menu. The 6 function keys correspond to the 6 menu levels with Zero for Level 1 through to F3 or level 6.

To access a lower level menu, use the key to the right of your current key. To return to the upper levels, use the keys to the left of your current key.



Code	Description
1	Parent Menu
2	Item Name
3	Menu Level
4	Item Data - If this is blank then the Item is a sub-menu.

4.4. Changing Data

Menu items containing data are shown along with their data (strings may show the first few characters only). This data can be changed by using the editing keys. When editing is finished, press the OK key to accept the new data. If the new data is unwanted, press the cancel key (Sometimes several presses are required). While editing, the type of data being edited is shown in the top right corner of the LCD.

4.5. Numeric Entry

Using the keypad, enter the desired number and press the OK key. Upper and lower limits are placed on some entries and an entry outside this range will cause the instrument to display dashes (i.e. - - - -).

Example: When in Setup follow the steps below to set Gen.Opt:PCode:Safe.PC.

Press <ZERO> repeatedly to display the GEN.OPT menu.
Press <TARE> repeatedly to display the PCODE menu.
Press <GROSS/NET> repeatedly to display the SAFE.PC item and the current setting (e.g. 0).
Enter the new safe passcode using the keypad.
Press <OK>

4.6. Selections and Options

A selection entry requires the choice of a single option from a list.

Using the up and down arrows, select the desired option and press the OK key.

Example: When in Setup follow the steps below to set Gen.Opt:Date.F.

Press <ZERO> repeatedly to display the GEN.OPT menu.
Press <TARE> repeatedly to display the DATE.F menu and the current setting (e.g. DD.MM.YY).
Use the ↑ and ↓ keys to select the desired option from the list.
Press <OK>

4.7. Strings

There are 3 different methods of editing strings:

- Normal string editing (auxiliary display: STR)
- Numerical string editing (auxiliary display: S.NUM)
- ASCII string with character position (auxiliary display: S.ASC)

Use the <+/-> key to cycle between these options.

4.7.1. Normal String Editing

Normal string editing is most useful where strings are small and contain no lowercase or unprintable characters. The available characters are printed in orange on the keypad.

Special keys are:

- <OK>: Accept changes and finish.
- <Long press of cancel>: Cancel and exit without changes
- <Cancel>: Delete character
- <Up>, <Down>: Move cursor
- <Long press of down>: Delete string after cursor
- <+/->: Switch editing modes

4.7.2. Numerical String Editing

Numerical string editing is useful where strings only contain numbers.

Special keys are:

- <OK>: Accept changes and finish.
- <Long press of cancel>: Cancel and exit without changes
- <Cancel>: Delete character
- <Up>, <Down>: Move cursor
- <Long press of down>: Delete string after cursor
- <+/->: Switch editing modes

4.7.3. ASCII String Editing

ASCII string editing is useful where tokens or other unprintable characters are required. ASCII codes are entered as numbers. Print tokens are entered in this mode.


Special keys are:

- <OK>: Accept ASCII code/Accept changes and finish.
- <Long press of cancel>: Cancel and exit without changes
- <0> to<9>: Enter a new code
- <Cancel>: Delete character
- <Up>, <Down>: Move cursor
- <Long press of down>: Delete string after cursor
- <+/->: Switch editing modes

5. Basic Operation


5.1. User Interface Display and Controls

5.1.1. Overview



Code	Description
1	Display
2	Numeric Keypad
3	Function Keys (user defined)
4	Function Keys (Fixed)
5	Power Key

5.1.2. Display




Code	Description
1	Primary Annunciators
2	Primary Display
3	Auxiliary Display
4	Primary Units
5	Secondary ID E.g. Product Name = CONCRETE in example above.
6	Miscellaneous Annunciators
7	Secondary Units
8	Secondary Display

5.1.3. Primary Annunciators

Symbol	Name	Description
HOLD	HOLD	Visible when the displayed reading is held.
NET	NET	Visible when the displayed reading represents Net weight.
→0←	ZERO	Visible when the gross reading is within $\pm \frac{1}{4}$ of a division of true zero.
~	MOTION	Visible when the displayed reading is not stable.
[]	ZERO BAND	Visible when the displayed weight is within the zero 'dead' band setting.
← →	RANGE	Indicates current range (for dual range/interval).






5.1.4. Keypad



Code	Description	
1	Numeric Button	0-9
2	White Characters	Hold 2 seconds
3	Orange Characters	(Alpha and Symbols)
	Cancel	Undo last command; step backwards (including in setup menus).
	Up	Move cursor backwards; previous option
	Down	Move cursor forwards; next option
	OK	Accept this choice
	Decimal Point	Place decimal point
	+/-	Change to negative or positive number; Change Editing VIEW (e.g. ASCII vs string)

5.2. Operation Keys


Legend:

	Press		Single beep
	Press and hold		Double beep
	Display flashing		

5.2.1. Power Key


◆ ON Instrument

(1) Short press <Power>.



◆ OFF Instrument

(1) Long press <Power>.




◆ Additional Information

Power Key Locked: If the power key is locked, the Instrument cannot be turned off from the front keypad.


Automatic Operation: Instrument will operate whenever external power is available and will not need to be manually turned on again if the power is interrupted.

5.2.2. Zero Key




When an empty scale has drifted away from a true zero reading, this key is used to perform a zero adjustment on the scale display. When pressed the summing indicator sends a command to each slave to force the zeroing to occur.

◆ **Short Press**



5.2.3. Tare Key




This key is used to temporarily set the scale to zero (such as cancelling the weight of a carton before performing a filling operation). The display will show the Net weight and the NET annunciator will be lit. When pressed the summing indicator sends a command to each slave to force the tare to occur.

The weight tared is deducted from the allowable range of the scale, reducing the maximum weight that can be displayed.

Preset Tare: As there is no way to properly distribute a preset tare among the slaves, the summing indicator does not have a preset tare function.

◆ **Short Press**




5.2.4. Gross/Net Key




This key toggles the weight display between the Gross weight and the Net weight (provided that a Tare has previously been acquired using the <TARE> key). When pressed the summing indicator sends a command to each slave to force the indicator to show either gross or net weight.

◆ **Short Press**



5.2.5. Function Keys




- Functions are set in the FUNC menu.
- Function key labels are attached below the key.
- See Special Functions section 12 for a description of operation.

5.2.6. Up, Down, OK keys: Products

These keys are used to control the products. A short press of <UP> and <DOWN> keys is used to select products. A long press of the <UP> key will add new products. A long press of the <DOWN> key will delete products. A long press of the <OK> key will edit the name of the current product.


◆ Short Press of Up and Down keys

A short press of these keys will allow the user to select the desired product from a list of the most recently used. The keypad can be used to enter the first letter of the product name. The <UP> and <DOWN> keys will then step through the list of products starting with the entered letter.



◆ **Long Press of the Up Key (Add)**

A long press of this key allows the user to create a new product. The name of the new product must be specified.




◆ **Long Press of the Down Key (Del)**

A long press of this key allows the user to delete a new product. Products can only be deleted if the total weight is 0. Product totals are cleared using a long press of the 4 key (Total).




◆ Long Press of the OK Key (Edit)

A long press of this key allows the user to change the name of a product.




5.2.7. Clock

A long press of the 1 key (Clock) allows the system time and date to be viewed and changed




5.2.8. View

A long press of the 2 key (View) allows the display function to be changed.




5.2.9. Report

A long press of the 3 key (Report) allows reports to be printed.




5.2.10. Total

A long press of the 4 key (Total) allows totals to be viewed and cleared.




5.2.11. User ID

A long press of the 5 key (ID) allows User IDs to be viewed and cleared. The Settable Consecutive Print ID can also be viewed and edited, refer also to 11.2 Print ID page 72.




5.2.12. Target

A long press of the 7 key (Target) allows setpoint targets to be viewed and changed.



5.2.13. Lock

A long press of the '.' key (Lock) allows instrument to be locked. The instrument can be unlocked by entering the operator passcode when prompted.




5.2.14. Alibi

Alibi mode is not present in the K481. A long press of the +/- key (Alibi) will display an error message and return to normal weighing.

5.2.15. Acc

A long press of the 0 key (Acc) is used to view information about the attached accessory modules.



When a M4221 Ethernet module is attached, the current IP (Internet Protocol) settings can be viewed from the Acc menu. The "." key allows the second half of longer IP addresses to be displayed. In this example the DNS 2 IP address is 192.168.100.10.



5.2.16. Stability Considerations

Some functions (e.g. Tare and Zero) require a stable weight. These functions will wait for up to 10 seconds for stable weight. If a stable weight is not available 'MOTION ERROR' is displayed and the function is cancelled.

6. Configuration

6.1. General Setup Information

Configuration and calibration can be performed entirely from the front panel, using the digital setup facility. When **Full Setup** is used, all menu items are accessible and care must be taken to ensure no accidental changes are made to trade settings. In addition, there is also **Safe Setup** that provides restricted access. This setup method ensures that only settings that are not calibration or trade sensitive can be changed.

Full and Safe Setup can be passcode protected to prevent unauthorised or accidental tampering.

6.2. Calibration Counter

Within Setup there are a number of critical steps that can affect the legal for trade performance of the instrument. If any of these steps are altered, the trade certification of the scale could be voided.

The instrument provides built-in calibration counter(s) to monitor the number of times the critical steps are altered. The value of a counter is stored within the instrument and can only be reset at the factory. Each time a critical step is altered, the counter will increase by one. Whenever the instrument is powered up, or setup mode is entered/exited, the current value in the counter is displayed briefly (e.g. C00010).

The value of the counter is written on the tamperproof trade label on the front of the indicator for trade-certified applications and functions as an electronic seal. If any legal for trade settings are changed on the instrument, the current value of the calibration counter will be different from the recorded value and the seal is broken. In this manual, items marked with ⊗ indicate that the setting is legal for trade critical settings.

6.3. Passcodes

The instrument has three levels of passcode to provide security for instrument functions, calibration and general configuration.

- Full Setup Passcode
- Safe Setup Passcode
- Operator Passcode

The Full Setup passcode can also be used to access Safe Setup and Operator functions.

Instrument settings that are accessed by the communications are protected by the same passcodes.

6.3.1. Full Setup Passcode

Setting a passcode for Full Setup restricts access to Full Setup.

6.3.2. Safe Setup Passcode

Setting a passcode for Safe Setup restricts access to Safe Setup functions. In addition, front panel functions can be configured to prompt for a Safe Setup passcode before operating. Refer to 8.1.4 KEY.LOC (Key Function Access Control) on page 40 for more information.

6.3.3. Operator Passcode

The operator passcode is used to protect access to instrument functions available from the front panel keypad. Refer to 8.1.4 KEY.LOC (Key Function Access Control) on page 40 for more information on how to add security to operator functions.

The operator generally needs to enter the Operator Passcode only once to gain access to multiple functions. To lock the instrument again press the '.' key for two seconds (LOCK function).

6.3.4. Setup Lock-Out

If an attempt is made to enter Full or Safe Setup using an incorrect passcode, the instrument will respond with the message **ENTRY DENIED** and then the user will be returned to normal operating mode.

No more than three failed attempts can be made to access Full/Safe Setup before the instrument blocks access completely. The instrument must be turned off and on again before further attempts can be made.

7. Summing Setup

7.1. Wiring Diagram

Please refer to Section 3.8 for the wiring between the summing indicator and the slaves.

7.2. Configuring the Slave R300 or R400 Indicators

The slave units must be configured to communicate correctly with summing indicator. The K481 can only sum one type of indicator. All slaves must be R300 or R400, not a mix. Each slave must be given a unique address between 1 and the number of slaves to be summed. The K481 can sum a maximum of 9 slaves.

7.2.1. Slave Calibration

Calibrate each slave as per the manuals for the indicator. Each slave must have the same units (e.g. all Kg). The decimal point position may vary among the slaves.

7.2.2. R320 Slave Configuration

R320 slaves must be running version 3.83 or greater. The following items must be configured in each R300 slave:

- Set SERIAL:TYPE to NET
- Set SERIAL:BAUD to the same baud rate as the summing indicator
- Set SERIAL:BITS to "N81-"
- Set SERIAL:ADDRESS to a unique address between 1 and the number of slaves configured in the summing indicator

7.2.3. R420 Slave Configuration

The slaves must be one of the following:

- K401 Version 1.41 or greater
- K402 Version 1.41 or greater
- K481 Version 1.10 or greater
- K491 Version 1.11 or greater

Summing of K411 indicators is not supported.

The following items must be configured in each R420 slave:

- Set H.WARE:SERx.HW:BAUD to the same baud rate as the summing indicator for the appropriate serial port
- Set H.WARE:SERx.HW:PARITY to NONE for the appropriate serial port
- Set H.WARE:SERx.HW:DATA to 8 for the appropriate serial port
- Set H.WARE:SERx.HW:STOP to 1 for the appropriate serial port
- Set H.WARE:SERx.HW:DTR to OFF for the appropriate serial port
- Set H.WARE:SERx.HW:TERM to ON for the last slave, and off for all other slaves, for the appropriate serial port
- Set SER.NET:TYPE to PROTOCOL.B
- Set SER.NET:SERIAL to the serial port the slave will communicate with the master on

- Set SER.NET:ADDRESS to a unique address between 1 and the number of slaves configured in the summing indicator

7.3. Basic Configuration of the K481 Summing Indicator

The following items must be configured in the K481 summing indicator:

- Set H.WARE:SERx.HW:BAUD to the same baud rate as all the slaves for the appropriate serial port
- Set H.WARE:SERx.HW:PARITY to NONE for the appropriate serial port
- Set H.WARE:SERx.HW:DATA to 8 for the appropriate serial port
- Set H.WARE:SERx.HW:STOP to 1 for the appropriate serial port
- Set H.WARE:SERx.HW:DTR to OFF for the appropriate serial port
- Set H.WARE:SERx.HW:TERM to ON for the appropriate serial port
- Set SER.SUM:SERIAL to the serial port the slave will communicate with the master on
- Set SER.SUM:PROTO to RING when summing R300 indicators via the RS232 ring network, or NORMAL when summing R400 indicators via the RS485 network.
- Set SER.SUM:SLAVES to the number of slaves to be summed.

7.4. Slave Name Configuration of the K481 Summing Indicator

Each slave can optionally be named. This name is used on the display when displaying slave weights, and can be used in printouts. The name can be set via the SER.SUM:SLAV.n:NAME menu item. If left blank, the text "SLAVE n" will be used.

7.5. Subtotal Configuration of the K481 Summing Indicator

The K481 provides the ability to calculate up to four subtotals from the slave weights. The number of subtotals is set by the SER.SUM:SUB.NUM menu item.

Each subtotal has a name, a list of slaves to add to it, and a list of slaves to subtract from it. The name is configured via SER.SUM:S.TOT.n:NAME menu item. If left blank, the text "S.TOT n" will be used. The SER.SUM:S.TOT.n:SLV.ADD menu item configures the slaves that should be added to the sub total. For example, setting it to 12 will add slaves 1 and 2 to the subtotal. The SER.SUM:S.TOT.n:SLV.SUB menu item configures the slaves that should be subtracted from the sub total. For example, setting it to 34 will subtract slaves 3 and 4 to the subtotal.

8. Setup Menus

8.1. GEN.OPT (General options)

8.1.1. LANG (Operator language)

Path	Description
GEN.OPT L LANG	Sets the operator language.
LANG Values <OPT>	NB: Setup menus are fixed in English.
<ul style="list-style-type: none"> • English (Default) • German • Dutch • French • Polish • Italian • Spanish • Czech 	

8.1.2. DATE.F (Date format)

Path	Description
GEN.OPT L DATE.F	Sets the date format.
DATE.F Values <OPT>	
<ul style="list-style-type: none"> • DD.MM.YY (Default) • DD.MM.YYYY • MM.DD.YY • MM.DD.YYYY • YY.MM.DD • YYYY.MM.DD 	

8.1.3. PCODE (Security passcodes)

Path	Description
GEN.OPT L PCODE L SAFE.PC L FULL.PC (*) L OP.PC	Sets the instrument passcodes. The 3 levels of passcode are:
(*) Available in FULL SETUP only	<ul style="list-style-type: none"> • Full passcode (FULL.PC): Controls access to full setup menus. All settings (including trade critical settings) can be altered from full setup. The full passcode will also give access to safe or operator functions. • Safe passcode (SAFE.PC): Controls access to safe setup menus. No trade critical settings can be altered from safe setup. The safe passcode will also give access to operator functions. • Operator passcode (OP.PC): Controls access to various operator functions.
PCODE Values <NUM>	
0 .. 999999 Default: 0	
NB: A passcode value of 0 deactivates the passcode.	

8.1.4. KEY.LOC (Key Function Access Control)

Path	Description
GEN.OPT L KEY.LOC L P(*) L ZERO L TARE L GR_NT L F1 L F2 L F3 L CLOCK L VIEW L REPORT L TOTAL L ID L TARGET L ACC L PR.MOD L PR.SEL L NUM.PAD L ALIBI	<p>Access to each of the operator functions can be configured separately.</p> <p>The options are: AVAIL: function always available OPER.PC: requires a valid Operator Passcode SAFE.PC: requires a valid Safe Passcode LOCKED: function never available</p> <p>Functions protected with a 'Safe' passcode prompt for the passcode every time.</p> <p>Entering the Operator Passcode unlocks all operator protected functions, so the operator is not continually prompted for the passcode. In order to lock the instrument again press the '.' key for two seconds (function 'Lock').</p>
KEY.LOC Values <OPT>	
<ul style="list-style-type: none"> • AVAIL (Default) • OPER.PC • SAFE.PC • LOCKED <p>(*) AVAIL & LOCKED only are available for POWER.</p>	

8.1.5. DISP (Display options)

Path	Description
GEN.OPT L DISP L B.LIGHT L FREQ L VIEW	<p>These settings control the operation of the display.</p> <p>B.LIGHT (Backlight operation) can be set on or off.</p> <p>FREQ sets the update frequency of the display.</p> <p>VIEW (Display Layout) selects the default VIEW when the instrument powers up. The operator can select alternative views by pressing the '2' key for 2 seconds (function 'View'). Options:</p> <p>PRODUCT: display product information TOP: only the primary display is shown. The secondary display is used to show operator prompts received from the comms. DUAL: Primary and Secondary displays are used for scale information.</p>
B.LIGHT Values <OPT>	
ON (Default), OFF	
FREQ Values <OPT>	
1Hz, 2Hz, 3.3Hz, 5Hz, 10Hz (Default)	
VIEW Values <OPT>	
PRODUCT (Default), TOP, DUAL	

8.1.6. ID.NAME (User Defined Strings)

Path	Description
GEN.OPT L ID.NAME L NAME.1 L NAME.2 L NAME.3 L NAME.4 L NAME.5	<p>There are five User Strings available to the operator when the '5' key is pressed for 2 seconds (function 'ID').</p> <p>NAME.1, NAME.2, NAME.3, NAME.4 and NAME.5 specify the actual prompts displayed for the operator. The values that the operator enters are used for printing and other application functions.</p>
Values <STR>	<p>(E.g. to allow the operator to enter a customer ID, NAME.1 could be set to 'CUST'.)</p> <p>To remove a User String from the operator menu give it an empty name.</p>
<i>Maximum 6 characters.</i>	

8.1.7. POWER (Power options)

Path	Description
GEN.OPT L POWER L AUT.OFF L START	<p>AUT.OFF (Auto-off delay)</p> <p>Sets the automatic power off setting. The instrument will switch off after set minutes of inactivity. NEVER disables the auto power off feature.</p>
AUT.OFF Values <OPT>	<p>START (Pause at Start-up)</p> <p>If USER, the START function forces the instrument to pause on power up and prompt the operator to continue. This ensures that restarting the instrument does not go unnoticed.</p>
<ul style="list-style-type: none"> • NEVER (Default) • 1 min • 5 min • 10 min • 60 min 	
START Values <OPT>	
NONE (Default), USER	

8.1.8. STR.EDT (String Edit Mode)

Path	Description
GEN.OPT L STR.EDT	<p>Sets the mode that the string editor will start in.</p>
STR.EDT Values <OPT>	
<ul style="list-style-type: none"> • STRING (Default) • NUM • AUTO 	

8.1.9. USR.DEF (Set all non-calibration settings to defaults)

Path	Description
GEN.OPT L USER.DEF	Sets all general instrument settings to defaults.
Values	
DEFAULT? <OK> CONFIRM? <OK>	

8.2. H.WARE (Hardware Configuration & Test)

8.2.1. SER1.HW, SER2.HW

Path	Description
H.WARE L SER1.HW L BAUD L PARITY L DATA L STOP L DTR L TERM L SER2.HW L BAUD L PARITY L DATA L STOP L DTR L TERM L RING	<p>BAUD (Baud Rate) Sets the baud rate for the port.</p> <p>PARITY Sets the parity for the port.</p> <p>DATA (Data bits) Sets the number of data bits for the port.</p> <p>STOP (Stop bits) Sets the number of stop bits for the port.</p> <p>DTR (DTR usage) Use the DTR line with RS232 printing.</p> <p>TERM (Termination Resistors) Use termination resistors with RS485.</p> <p>RING (Ring network) Enable ring network. Only available on SER2 and required M42xx software version 1.01+.</p>
BAUD Values <OPT>	
1200, _2400_, _4800_, _9600_ (Default), _19200_, _57600_	
PARITY Values <OPT>	
NONE (Default), EVEN, ODD	
DATA Values <OPT>	
8 (Default), _7_	
STOP Values <OPT>	
1 (Default), _2_	
DTR Values <OPT>	
OFF (Default), ON	
TERM Values <OPT>	
OFF (Default), ON	
RING Values <OPT>	
OFF (Default), ON	

8.2.2. IO.HW

Path	Description
H.WARE L IO.HW L FRC.OUT L TST.IN L DB.1.8 L DBNC.1 : L DBNC.8 L DB.9.16 L DBNC.9 : L DBNC.16 L DB.17.24 L DBNC.17 : L DBNC.24 L DB.25.32 L DBNC.25 : L DBNC.32	<p>FRC.OUT (Force Outputs)</p> <p>Use this when testing and fault finding to force the IO on and off. Use the UP and DOWN keys to select the output. Use the +/- key to switch the output on and off.</p> <p>TST.IN (Test Inputs)</p> <p>Use this when testing and fault finding to check the status of IO when used as inputs. Inputs are listed for each module in order of lowest to highest IO number. '1' means the input is active, '0' means the input is inactive. Use the UP and DOWN keys to select the module to view.</p> <p>DBNC (Debounce)</p> <p>This sets the amount of debouncing for inputs. It is set in milliseconds [ms].</p>
DBNC Values <NUM>	
1..250 ms <i>Default: 20 ms</i>	

8.2.3. ANL.HW

Path	Description
H.WARE L ANL.HW L TYPE L CLIP L FRC.OUT L ANL.CAL L ADJ.LO L ADJ.HI	<p>TYPE (Analogue Output Type)</p> <p>Sets the analogue output to current (4-20mA) or voltage (0-10V) mode.</p> <p>CLIP (Analogue Output Clip Enable)</p> <p>When clipping is on, the output is restricted to 4-20mA or 0-10V. When clipping is off, the output can go at least 3mA or 0.5V beyond these limits.</p>
TYPE Values <OPT>	FRC.OUT (Force Analogue Output)
Current ^(Default) , Volt	Sets the number of data bits for the port.
CLIP Values <OPT>	ADJ.LO (Calibrate Analogue Output)
NO ^(Default) , YES	Calibrate 4mA or 0V analogue output. Use the UP and DOWN keys to adjust the calibration.
	ADJ.HI (Calibrate Analogue Output)
	Adjust 20mA or 10V analogue output. Use the UP and DOWN keys to adjust the calibration.

8.2.4. ETH.HW

Path	Description
H.WARE └ ETH.HW └ DHCP └ IP └ NET.MSK └ G.WAY └ DNS.1 └ DNS.2	<p>DHCP (Dynamic Host Configuration Protocol)</p> <p>Enables or disables the use of DHCP to configure the IP settings of the M4221 Ethernet module. To use this option requires a DHCP server on the network.</p> <p>IP (Internet Protocol Address)</p> <p>Sets the IP address for the M4221 Ethernet module.</p> <p>NET.MSK (Network Mask)</p> <p>Sets the network mask the M4221. This defines the proportion of the IP address bits that reside on the M4221's subnet.</p> <p>G.WAY (Default Gateway)</p> <p>Sets the default gateway for the M4221. This is the server through which traffic destined for hosts beyond the M4221's subnet is routed.</p> <p>DNS.1 (Primary Domain Name Server)</p> <p>Sets the primary domain name server for the M4221. If not required use 0.0.0.0.</p> <p>DNS.2 (Secondary Domain Name Server)</p> <p>Sets the secondary domain name server for the M4221. If not required use 0.0.0.0.</p>
DHCP Values <OPT>	
ON (Default), OFF	
Note: IP, NET.MSK, G.WAY, DNS.1, DNS.2 settings are not available when DHCP is ON.	

8.2.5. ETH.DEF (Set the M4221 Ethernet module to defaults)

Path	Description
H.WARE └ ETH.HW └ ETH.DEF	<p>Sets all settings stored within the M4221 Ethernet module to defaults.</p> <p>This will not affect any instrument settings.</p>
Values	
DEFAULT? <OK> CONFIRM? <OK>	

8.2.6. DSD.HW

Path	Description
H.WARE L DSD.HW L AUTO.C L DSD.STR	AUTO.C (Auto Clear) Sets whether the DSD will automatically write over the oldest records when it becomes full.
AUTO.C Values <OPT>	DSD.STR (DSD String) Custom string to be stored along with the traceable data when the DSD is written. This accepts all print tokens.
OFF, ON (Default)	
DSD.STR Values <STR>	
Maximum 20 characters.	

8.3. SCALE (scale setup options)

8.3.1. OPTION (Scale options)

Path	Description
SCALE L OPTION L USE L Z.BAND [⊗]	USE (Trade Use): This setting affects the operation of trade functions. Options are: <ul style="list-style-type: none"> • INDUST: Industrial (no standard) • OIML: OIML trade mode • NTEP: NTEP trade mode
USE Values [⊗] <OPT>	Z.BAND (Zero Deadband): Sets the weight range around zero which will be considered zero for application purposes.
INDUST (Default), OIML, NTEP	
Z.BAND Values [⊗] <NUM>	
0 – fullscale <i>Default: 0</i>	[⊗] : This item is trade critical and will affect the calibration counter(s) if changed.

8.3.2. SUB.NUM (Number of subtotals)

Path	Description
SER.SUM L SUB.NUM	Sets the number of subtotals to be calculated.
Values <NUM>	
0 ^(Default) .. 4	

8.3.3. S.TOT.x (Subtotal settings)

Path	Description
SER.SUM L S.TOT.1..S.TOT.4 L NAME L SLV.ADD L SLV.SUB	<p>NAME: Provides a name for each subtotal to be displayed and printed. If left blank, "S.TOT n" will be used.</p> <p>SLV.ADD: Sets which slaves to add to the subtotal. E.g. 12 will add slave weights 1 & 2 to the subtotal.</p> <p>SLV.SUB: Sets which slaves to subtract from the subtotal. E.g. 34 will subtract slave weights 3 & 4 from the subtotal.</p>
NAME Values <STR>	
<i>Maximum 6 characters.</i>	
SLV.ADD Values <NUM>	
0..123456789 <i>Default: 0</i>	
SLV.SUB Values <NUM>	
0..123456789 <i>Default: 0</i>	

8.4. FUNC (Special functions)

The instrument supports up to eight special functions. Enter the number of special functions to use and configure each one according to the function type required. Most functions need only to be associated with a key or input to function, but some have additional configuration settings as detailed below.

8.4.1. NUM (Number of special functions)

Path	Description
FUNC L NUM	Sets the number of special functions.
NUM Values <OPT>	
-1 ^(Default) .. -8-	

8.4.2. SFn: TYPE (Function Types)

Path	Description
FUNC L SFn LTYPE	Sets the function type. Options are: <ul style="list-style-type: none"> • PRINT: Trigger a weight printout • SINGLE: Trigger a single serial weight transmission • TEST: Display test • PRD.SEL: Product Select • REM.KEY: Remote Key operation • BLANK: Blanking input • THUMB: Thumb-wheel Product Selection • REPORT: Print a report • SLAVE: Toggle through slave and subtotal weights on the lower display. • SC.EXIT: Trigger scale exit setpoint • A.TARE: Auto tare
TYPE Values <OPT>	
<ul style="list-style-type: none"> • NONE (Default) • PRINT • SINGLE • TEST • PRD.SEL • REM.KEY • BLANK • THUMB • REPORT • SLAVE • SC.EXIT • A.TARE 	

8.4.3. SFn: KEY (Function Key / Remote Input)

Path	Description
FUNC L SFn LKEY	Select front panel key or external input to trigger the special function. All functions that respond to input events have a KEY setting.
KEY Values <OPT>	
None (Default), F1 .. F3 IO1.. IO32	Functions like THUMB (Thumbwheel) require multiple inputs to function and have an equivalent setting to specify these inputs.

8.4.4. SFn: PRINT (Printing Functions)

Path	Description						
FUNC L SFn L TYPE: PRINT L KEY L LONG.PR L PRT.OUT L TOTAL L CLR.ASK L AUTO L IL.TYPE L I.LOCK	Configuration of the PRINT Special Function. KEY: Select PRINT key using front function key or external input. LONG.PR (LONG PRESS): Selects if long press functionality should be enabled. PRT.OUT (PRINT OUT): Selects the printout to print. Printouts are configured in the PRINT menu. TOTAL: Sets whether the print key affects the product totals.						
KEY Values <OPT>	Options are:						
None (Default), F1 .. F3, IO1.. IO32	<ul style="list-style-type: none"> • ADD: Add to totals • UNDO: Undo last add to totals • CLR.ALL: Clear all totals • CLR.SESS: Clear session total 						
LONG.PR Values <OPT>							
ENABLE ^(Default) , DISABLE							
PRT.OUT Values <OPT>	CLR.ASK (Prompt for Clear): Sets whether the operator is prompted to confirm the totals clear.						
None (Default), PRINT.1 .. PRINT.2	AUTO (Automatic printing): Sets whether printing occurs automatically.						
TOTAL Values <OPT>	IL.TYPE (Interlock Type): Sets the type of printing interlock to be used. Options are:						
<table border="1"> <tr> <td>NONE (Default)</td> <td>UNDO</td> </tr> <tr> <td>ADD</td> <td>CLR.ALL CLR.SESS</td> </tr> </table>	NONE (Default)	UNDO	ADD	CLR.ALL CLR.SESS	<ul style="list-style-type: none"> • MOTION: Printing is enabled every time the scale becomes stable. • I.LOCK: Printing is enabled when the weight is stable after a weight movement larger than the interlock weight. • RET.Z: Printing is enabled after the scale has returned to zero and is stable at a reading other than zero. 		
NONE (Default)	UNDO						
ADD	CLR.ALL CLR.SESS						
CLR.ASK Values <OPT>	I.LOCK (Interlock): Sets the interlock weight.						
NO (Default), YES							
AUTO Values <OPT>							
NO (Default), YES							
IL.TYPE Values <OPT>							
<table border="1"> <tr> <td>NONE (Default)</td> <td>MOTION</td> </tr> <tr> <td></td> <td>I.LOCK</td> </tr> <tr> <td></td> <td>RET.Z</td> </tr> </table>	NONE (Default)	MOTION		I.LOCK		RET.Z	
NONE (Default)	MOTION						
	I.LOCK						
	RET.Z						
I.LOCK Values <NUM>							
0 .. Fullscale							

8.4.5. SFn: SINGLE (Single Serial Output Functions)

Path	Description
FUNC L SFn L TYPE: SINGLE L KEY L AUT.OUT	Single serial outputs are similar to printing but do not support any interlocking or totalising functions. KEY: Function key or external input to use. AUT.OUT: Choose which Auto Output Serial service to trigger. The Auto Output TYPE should be set to SINGLE.
KEY Values <OPT>	
NONE (Default), F1 .. F3, IO1.. IO32	
AUT.OUT Values <OPT>	
AUTO.1(Default), AUTO.2	

8.4.6. SFn: BLANK (Blanking Functions)

Path	Description
FUNC L SFn L TYPE : BLANK L KEY L BLANK	Blanking functions enable the detection of external inputs to be used to block instrument operation by blanking the screen and blocking key functions. Typical applications are for tilt sensing. KEY: External input to use.
KEY Values <OPT>	BLANK: Set display blanking style. Options are:
None (Default), F1 .. F3, IO1 .. IO32	<ul style="list-style-type: none"> DASH: Fill instrument display with ‘-’ characters. BLANK: completely blank instrument display.
BLANK Values <OPT>	
DASH (Default), BLANK	

8.4.7. SFn: PRD.SEL (Product Select)

Path	Description
FUNC L SFn L TYPE : PRD.SEL L KEY	The product select key/input will cycle through the available totals information for the current product and allows the current product to be selected by number rather than name.
KEY Values <OPT>	KEY: Select key or external input to use.
None (Default), F1 .. F3, IO1 .. IO32	LONG.PR (LONG PRESS): Selects if long press functionality should be enabled.
LONG.PR Values	
ENABLE(Default) , DISABLE	

8.4.8. SFn: THUMB (Thumbwheel Product Selection)

Path	Description
FUNC L SF _n L TYPE : THUMB L IO.BAND	<p>The Thumbwheel function supports the use of an external thumbwheel to select the current product using the product number.</p> <p>A selection of '0' on the thumbwheel enables keyboard selection of the current product.</p>
IO.BAND Values <OPT>	IO.BAND: Select which four remote inputs are used for the thumbwheel function.
IO1-4(Default), IO5-8, IO9-12, IO13-16, IO17-20, IO21-24, IO25-28, IO29-32	

8.4.9. SFn: REM.KEY (Remote Key Functions)

Path	Description
FUNC L SF _n L TYPE : REM.KEY L KEY L FUNC	<p>Remote key functions allow external inputs to be used to trigger instrument key functions.</p> <p>The external 'keys' operate even if the instrument keys are locked and never require Operator or Setup passcodes to be entered.</p>
KEY Values <OPT>	KEY: External input to use. FUNC: Choose key function.
None(Default), IO1 .. IO32	
FUNC Values <OPT>	
NONE (Default), ZERO, TARE, GR/NET, 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, +/-, ., CANCEL, UP, DOWN, OK	

8.4.10. SFn: REPORT (Report Printing Functions)

Path	Description
FUNC L SF _n L TYPE: REPORT L KEY L PRT.OUT L CLR.TOT	<p>Configuration of the PRINT Special Function.</p> <p>KEY: Select PRINT key using front function key or external input.</p> <p>PRT.OUT (PRINT OUT): Selects the printout to print. Printouts are configured in the PRINT menu.</p> <p>CLR.TOTAL: Sets whether the print key affects the product totals.</p> <p>Options are:</p> <ul style="list-style-type: none"> • NO: Add to totals • ASK: Undo last add to totals • CLEAR: Clear all totals
KEY Values <OPT>	
None (Default), F1 .. F3, IO1 .. IO32	
PRT.OUT Values <OPT>	
None (Default), PRINT.1 .. PRINT.2	
CLR.TOTAL Values <OPT>	
NO (Default), ASK, CLEAR	

8.4.11. SFn: SC.EXIT (Scale Exit)

Path	Description
FUNC L SFn LTYPE : SC.EXIT L KEY	Key/input to trigger scale exit (SC.EXIT) setpoint. KEY: Select key or external input to use.
KEY Values <OPT>	
None (Default), F1 .. F3, IO1 .. IO32	

8.4.12. SFn: SLAVE (Display slave and subtotal weights)

Path	Description
FUNC L SFn LTYPE : SLAVE L KEY	Key/input to toggle through the slave and subtotal weights on the lower display. KEY: Select key or external input to use. LONG.PR (LONG PRESS): Selects if long press functionality should be enabled.
KEY Values <OPT>	
None (Default), F1 .. F3, IO1 .. IO32	
LONG.PR Values	
ENABLE(Default) , DISABLE	

8.4.1. SFn: A.TARE (Auto Tare)

Path	Description
FUNC L SFn LTYPE: A.TARE L KEY L THRESH L ZER.DLY	Key/input to set the preset tare to the current gross weight. KEY: Select key or external input to use. THRESH: Weight threshold to reach before automatically taring. ZER.DLY: Delay before returning to gross weight when inside the zero band.
KEY Values <OPT>	
None (Default), F1 .. F3, IO1 .. IO32	
TRESH Values <NUM>	
0(Default) .. Fullscale	
ZER.DLY Values <NUM>	
0.0 .. 10.0 s <i>Default: 5.0</i>	

8.5. SER.SUM (Serial summing configuration)

8.5.1. SERIAL (Summing serial port)

Path	Description
SER.SUM └ SERIAL	The serial port for the summing indicator to use when communicating with the slaves. Only bi-directional serial ports may be selected. This serial port cannot have other simultaneous uses and will generate a clash in the hardware allocation report described in section Error! Reference source not found.
Values <OPT>	
SER1A (Default), SER2A	

8.5.2. PROTO (Summing serial protocol)

Path	Description
SER.SUM └ PROTO	This setting controls the protocol used to communicate with the slaves. RING network uses a ring configuration where the transmitter of each device is connected to the receiver of next device. Refer to Section 3.8. NORMAL protocol requires a RS485 network where the summing indicator sends a command and expects a response from each slave before progressing to the next device. Refer to Section 3.8.
Values <OPT>	
RING (Default), NORMAL	

8.5.3. SLAVES (Number of slaves to sum)

Path	Description
SER.SUM └ SLAVES	Sets the number of slaves to sum. Each slave must be addressed uniquely from 1 to the number of slaves.
Values <NUM>	
1(Default).. 9	

8.5.4. NAME (Naming for individual slaves)

Path	Description
SER.SUM └ SLAV.1..SLAV.n └ NAME	Provides a name for each slave to be displayed and printed. If left blank, "SLAVE n" will be used.
Values <STR>	
<i>Maximum 6 characters.</i>	

8.6. SER.NET (Network communications)

Path	Description
SER.NET L ADDR L NUM L NET.n L TYPE L SERIAL L RESP L SOURCE	Configure the serial networking support. ADDR (Address): Address of instrument (1..31). NUM : sets the number of networks TYPE : Type of Network Protocol: <ul style="list-style-type: none"> • NONE: Disable networking • rinCMD: See Network Communications page 64. • Simple commands: See Network Communications page 64. • Barcode: See Network Communications page 64.
ADDR Values <NUM>	
1..31	
NUM Values <OPT>	
-1- (Default) .. -2-	SERIAL : Serial Port to use.
TYPE Values <OPT>	RESP : Respond with OK to simple commands.
NONE (Default), rinCMD, SIMPLE, BARCODE	SOURCE : Barcode protocol source, settable to product name (NAME), product barcode (B.CODE) or product ID (ID).
SERIAL Values <OPT>	
SER1A ^(Default) , SER2A, SER3A	
RESP Values <OPT>	
NONE ^(Default) , OK	
SOURCE Values <OPT>	
NAME ^(Default) , B.CODE, ID	

8.7. SER.AUT (Automatic transmit)

8.7.1. NUM (Number of Automatic Transmissions)

Path	Description
SER.AUT L NUM	Sets the number of special automatic outputs
Values <OPT>	
-1- (Default) .. -2-	

8.7.2. AUTO.n (Automatic Output Configuration)

Path	Description	
SER.AUT L AUTO.n L TYPE L SERIAL L FORMAT L EV.AUTO(*)	<p>These settings are the same for AUTO.1 and AUTO.2</p> <p>TYPE: Sets the transmission rate. Options are:</p> <ul style="list-style-type: none"> • SINGLE: A SINGLE function key is used to trigger a single transmission. Rate is determined by external input. • AUTO.LO: Transmit at 10Hz • AUTO.HI: Transmit at 25Hz frequency • AUTO.TRC: Sends a message for every traceable weight • 5 HZ: Transmit at 5Hz frequency <p>SERIAL: Select Serial port to use.</p> <p>FORMAT: Set data format. See Auto Weight Format String page 70.</p> <p>EV.AUTO: Token string to define data format for CUSTOM transmissions.</p>	
TYPE Values <OPT>		
NONE (Default) SINGLE		AUTO.LO AUTO.HI AUT.TRC 5 HZ
SERIAL Values <OPT>		
SER1A (Default), SER1B, SER2A, SER2B, SER3A, SER3B		
FORMAT Values <OPT>		
FMT.A (Default) FMT.B FMT.C FMT.D FMT.E		FMT.REG FMT.TRC CUSTOM FMT.F FMT.G
EV.AUTO Values <STR>		
Token String (*) Only used with CUSTOM format.		

8.8. PRINT (Printouts)

8.8.1. NUM (Number of printouts)

Path	Description
PRINT L NUM	Sets the number of printouts.
Values <OPT>	
1 (Default) .. _2_	

8.8.2. HEADER (Print header)

Path	Description
PRINT L HEADER	Sets the print docket header.
Values <STR>	
String	

8.8.3. FOOTER (Print footer)

Path	Description
PRINT L FOOTER	Sets the print docket footer.
Values <STR>	
String	

8.8.4. PAGE (Print page options)

Path	Description
PRINT L PAGE L WIDTH L HEIGHT L PG.END	<p>Page settings configure the height and width of the paper and what to do at the bottom of a page.</p> <p>WIDTH: Sets the page width. A setting of zero disables page width checking.</p> <p>HEIGHT: Sets the page height. A setting of zero disables page height checking.</p> <p>PG.END (Page End String): Sets the string to print at page end. This option allows a cut character, form feed, etc., to be added every page.</p>
WIDTH Values <NUM>	
0 .. 250 Default: 0	
HEIGHT Values <NUM>	
0 .. 250 Default: 0	
PG.END Values <STR>	
Token String	

8.8.5. SPACE (Print blank space options)

Path	Description
PRINT L SPACE L TOP L LEFT L BOTTOM	Space controls the amount of white space to leave around the printout. TOP: Sets the number of blank lines to add at the top of each page. LEFT: Sets the number of spaces to add at the beginning of each line.
Values <NUM>	BOTTOM: Sets the number of blank lines to add to the bottom of each page.
0 .. 10 <i>Default: 0</i>	

8.8.6. PRINT.n ... (Printout options)

Path	Description
PRINT L PRINT.n L TYPE L FORMAT L SERIAL L NAME L CUSTOM (*) L REC.PRN or L PRN.KEY L EV.D.NEW L EV.D.END L EV.P.NEW L EV.P.END or L REP.ST L REP.PR L REP.END	Each printout has its own format settings. TYPE: Sets the printout type. Options are: <ul style="list-style-type: none"> • NONE (default) • RECORD • DOCKET • REPORT FORMAT: Sets the printout format. SERIAL: Sets the serial port for this printout NAME (Printout Name): Report printouts are available by name to the operator. CUSTOM: For custom printing, each type of printout uses event strings as follows: RECORD: REC.PRN (Record Print): defines entire printout. DOCKET: PRN.KEY (Docket Print) controls the format of each transaction on the docket. EV.D.NEW (Event Docket New) defines the start of the docket. EV.D.END (Event Docket End) defines the end of the docket. EV.P.NEW (Event Product New) defines what is printed when a new product is selected. EV.P.END (Event Product End) defines what is printed just before a new product is made active. REPORT: REP.ST (Report Start) defines start of report. REP.PR (Report Product) controls the information printed for each product. REP.END (Report End) defines the end of the report.
TYPE Values <OPT>	
<ul style="list-style-type: none"> • NONE (Default) • RECORD • DOCKET • REPORT 	
FORMAT Values <OPT>	
FMT.A (Default), FMT.B CUSTOM	
SERIAL Values <OPT>	
SER1A (Default), SER2A, SER3A, SER1B, SER2B, SER3B	
NAME Values <STR>	
6-character String	
CUSTOM Values <STR>	
Token string	
(*) Active token strings depend on the TYPE setting	

8.9. SETP (Setpoints)

8.9.1. NUM (Number of setpoints)

Path	Description
SETP └─ NUM	Sets the number of special setpoints
Values <OPT>	
1 ... _16_ (Default)	

8.9.2. SETP1 ... SETP16 (Setpoint options)

Path	Description
SETP └─ SETP _n └─ TYPE └─ OUTPUT └─ LOGIC └─ ALARM └─ RDY.TIM ^(***) └─ SOURCE ^(****) └─ SCOPE ^(*) └─ HYS ^(*) └─ REG ^(****) └─ DELAY └─ ON └─ TIMING └─ MASK ^(**) └─ RESET └─ PLS.NUM └─ RST.LGC └─ NAME	Configure the operation of each setpoint. TYPE determines the function of the setpoint. Options are: <ul style="list-style-type: none"> • NONE: Always inactive • ON: Always active • OVER: active if weight over target • UNDER: active of weight under target • COZ: active if Centre of Zero • ZERO: active if weight is zero • NET: active if net weight selected • MOTION: active if weight unstable • ERROR: active if error conditions detected • LGC.AND: active if inputs match the bits set in the mask exactly • LGC.OR: active if any inputs match the bits set in the mask • LGC.XOR: active if only one input matches the bits set in the mask • SC.REDY: active when scale is stable and in the zero band for more than the time set in RDY.TIM • SC.EXIT: active when outside of zero band and a print has occurred, or can be triggered by SC.EXIT special function • BUZZER: active when the buzzer sounds.
TYPE Values <OPT>	
<ul style="list-style-type: none"> • NONE (Default) • ON • OVER • UNDER • COZ • ZERO • NET • MOTION • ERROR • LGC.AND • LGC.OR • LGC.XOR • SC.REDY • SC.EXIT • BUZZER 	
OUTPUT Values <OPT>	
<ul style="list-style-type: none"> • NONE, IO1 .. IO32 (Default) 	
LOGIC Values <OPT>	
HIGH (Default), LOW	OUTPUT specifies which IO to use or the setpoint output. LOGIC: Logic HIGH forces the output to follow the setpoint activity. Logic LOW forces the output to the reverse of the setpoint activity. ALARM: Alarms are triggered when the setpoint is active. Options are:

ALARM Values <OPT>		NONE: no alarm SINGLE: single BEEP DOUBLE: double BEEP FLASH: flash display
NONE (Default) SINGLE	DOUBLE FLASH	
RDY.TIM Values <NUM>		RDY.TIM: the time that the scale must be in the zero band and stable before the SC.REDY setpoint will become active
0.000 to 60.000 s Default: 0.000 (***) NB: Only for SC.REDY setpoints.		
SOURCE Values <OPT>		SOURCE: Select which weight values the setpoint checks against the target weight. Options are: GR.or.NT: Gross or Net depending on which one is displayed. IO: perform logic setpoints on the IO status. STATUS: perform logic setpoints on the current instrument status. SETP: perform logic setpoints on the setpoint status. REG: Register value.
<ul style="list-style-type: none"> • GR.or.NT(*) (Default) • IO(***) • STATUS(***) • SETP(***) • REG(*****) (*) NB: Only for OVER and UNDER setpoints. (**) NB: Only for LGC.AND, LGC.OR and LGC.XOR setpoints. (****) NB: Only for OVER, UNDER, LGC.AND, LGC.OR and LGC.XOR setpoints.		
SCOPE Values <OPT>		SCOPE: The setpoint target can be set to be identical for all products (GLOBAL) or different for each product (PROD). HYS: Hysteresis defines the amount of weight required for an active setpoint to become inactive again. A value of 0 still allows for 0.5 graduations of hysteresis.
<ul style="list-style-type: none"> • GLOBAL (Default) • PROD (*) NB: Only for OVER, and UNDER setpoints.		
HYS Values <NUM>		REG: select which register to use as the source for the setpoint, must be a number or a weight. Decimal values for the registers should be used. DELAY: Delay for TIMING set to PULSE before setpoint becomes active. ON: Duration of pulse when TIMING set to PULSE.
0 to 999999 Default: 0 (*) NB: Only for OVER, and UNDER setpoints.		
REG Values <NUM>		TIMING: Select the timing which is applied to the setpoint output. Options are: LEVEL: Setpoint follows the weight. EDGE: Setpoint is edge triggered. PULSE: Setpoint output is pulsed. LATCH: Setpoint output is latched.
0 to 65535 Default: 0 (****) NB: Only for OVER, UNDER, LGC.AND, LGC.OR and LGC.XOR setpoints when REG is selected in SOURCE.		
DELAY Values <NUM>		MASK: a 32-bit number that is used by the logic setpoints to match the setpoint source. RESET: Input to disable the setpoint. PLS.NUM: Number of pulses to output when TIMING is set to PULSE. RST.LGC: Logic HIGH resets the setpoint when the input value is high. Logic LOW resets the setpoint when the input value is low.
0.040 to 60.000s Default 0.040s		

<p>NB: Only for TIMING set to PULSE</p>	<p>NAME: give the setpoint a name, this will be shown when editing targets.</p>
<p>ON Values <NUM></p>	
<p>0.040 to 60.000s <i>Default 0.040s</i></p> <p>NB: Only for TIMING set to PULSE</p>	
<p>TIMING Values <OPT></p>	
<p>LEVEL^(Default), EDGE, PULSE, LATCH</p>	
<p>MASK Values <NUM></p>	
<p>0 to 16777215 <i>Default 0</i> (**NB: Only for LGC.AND, LGC.OR and LGC.XOR setpoints</p>	
<p>RESET Values <OPT></p>	
<p>NONE^(Default), IO1 .. IO32</p>	
<p>PLS.NUM Values <NUM></p>	
<p>1 to 20 Default: 1</p> <p>NB: Only for TIMING set to PULSE</p>	
<p>RST.LGC Values <OPT></p>	
<p>HIGH^(Default), LOW</p>	
<p>NAME Values <STR></p>	
<p>6 character String</p>	

8.10. ANL.OUT (Analogue Output)

Path	Description
ANL.OUT L ABS L RANGE L WGT.LO L WGT.HI	<p>Configures the operation of the analogue transmission.</p> <p>ABS (Absolute Weight): Transmit negative weight values the same as positive weight values.</p> <p>RANGE: Set the weight range. Options are: FULLSCALE: 0 to fullscale CUSTOM: Use WGT.LO and WGT.HI</p> <p>WGT.LO (Weight Low): Weight corresponding to the lower analogue limit. (e.g. 0 volts or 4 mA)</p> <p>WGT.HI (Weight High): Weight corresponding to the higher analogue limit. (e.g. 10Volts or 20 mA)</p>
ABS Values <OPT>	
NO ^(Default) , YES	
RANGE Values <OPT>	
FULLSCALE ^(Default) , CUSTOM	
WGT Values <NUM>	
-999999 .. 999999	

8.11. End (Save and exit)

9. Network Communications

9.1. Introduction

The RS-232, RS-485 and the optical communications can be used for networking.

Warning: The calibration counter is incremented when the calibration related settings are changed. This means that calibration via a serial port cannot be carried out without affecting the certification of a trade installation.

Serial communications parameters such as BAUD, PARITY, etc. for the RS232 or RS485 serial ports are setup in the HDWARE menu.

The Optical Communications port is fixed to operate at 9600 baud, no parity, 8 data bits and 1 stop bit. The optical communications cable must be used.

9.2. Network rinCMD

The rinCMD network protocol, formerly known as Protocol B, uses ASCII characters with a single master POLL / RESPONSE message structure. All information and services are provided by registers each of which has its own register address.

9.2.1. Basic Message Format

The basic message format is as follows:

ADDR	CMD	REG	:DATA	↵
-------------	------------	------------	--------------	---

ADDR

ADDR is a two-character hexadecimal field corresponding with the following:

ADDR	Field Name	Description
80 _H	Response	'0' for messages sent from the master (POLL). '1' for messages received from an instrument (RESPONSE)
40 _H	Error	Set to indicate that the data in this message is an error code and not a normal response.
20 _H	Reply Required	Set by the master to indicate that a reply to this message is required by any slave that it is addressed to. If not set, the slave should silently perform the command.
00 _H .. 1F _H	Indicator Address	Valid instrument addresses are 01 _H to 1F _H (1 .. 31). 00 _H is the broadcast address. All slaves must process broadcast commands. When replying to broadcasts, slaves reply with their own address in this field.

CMD is a two-character hexadecimal field:

CMD	Command	Description
05 _H	Read Literal	Read register contents in a 'human readable' format
11 _H	Read Final	Read register contents in a hexadecimal data format
16 _H	Read Final (Decimal)	Same as Read Final except numbers are decimal.
12 _H	Write Final	Write the DATA field to the register.
17 _H	Write Final (Decimal)	Same as Write Final except numbers are decimal.
10 _H	Execute	Execute function defined by the register using parameters supplied in the DATA field.

REG	is a four-character hexadecimal field that defines the address of the Register specified in the message. See Appendix 3: Communications Registers page 100 for a list of registers used by the instrument. The viewer software will show the register address for each setting in the menu structure when they are accessed.
: DATA	carries the information for the message. Some messages require no DATA (e.g. Read Commands) so the field is optional. When a DATA field is used a ':' (COLON) character is used to separate the header (ADDR CMD REG) and DATA information.
↵	is the message termination (CR LF or “;”).

Note: The hexadecimal codes are combined in the fields described above when multiple options are active at the same time. For example, an error response message from instrument address 5 would have an ADDR code of C5_H (80_H + 40_H + 05_H).

9.2.2. Termination

Message termination is possible in two ways.

- For normal communications that do not involve checksums use either a CRLF (ASCII 13, ASCII 10) as a terminator or a semicolon (; ASCII 59). There is no start-of-message delimiter.
- To use a checksum the message is framed as:

SOH <Message> CRC EOT

SOH	ASCII 01
CRC	a 4-character hexadecimal field comprising the 16 bit CRC checksum. The CRC uses the 16 bit CCITT polynomial calculation and includes only the contents of the <Message> section of the transmission.
EOT	ASCII 04

9.2.3. Error Handling

If a command cannot be processed, the indicator returns an error. The ERROR bit in the ADDR field is set and the DATA field contains the Error Code as follows:

Error	DATA	Description
Unknown Error	C000 _H	Error is of unknown type
Not Implemented Error	A000 _H	Feature not implemented on this device
Access Denied	9000 _H	Passcode required to access this register
Data Under Range	8800 _H	Data too low for this register
Data Over Range	8400 _H	Data too high for this register
Illegal Value	8200 _H	Data not compatible with this register
Illegal Operation	8100 _H	CMD field unknown
Bad parameter	8040 _H	Parameter not valid for this execute register
Menu in Use	8020 _H	Cannot modify register values while SETUP menus are active.
Viewer Mode required	8010 _H	Advanced operation chosen which requires the instrument to be in viewer mode.
Checksum required	8008 _H	A checksum is required for the chosen command.

Table 3: Network error codes

9.2.4. Ring Network Enhancement

Instruments with software revision V2.31+ can be configured in a Ring Network via a M42xx module (software revision 1.01+). This requires the central computer to send additional framing characters, 'Echo-On' (= <DC2> =ASCII 12 H) and 'Echo-Off' (= <DC4> =ASCII 14 H) around each command. Below is an example Ring Network command and response:

```
<DC2>20110150:<CR><LF>
<DC4>
```

```
<DC2>20110150:<CR><LF>
81110150:07/01/2030 17-29<CR><LF>
82110150:07/01/2030 17-30<CR><LF>
<DC4>
```

9.3. Network Protocol SIMPLE

The simple network protocol allows the indicator to respond to common simple ASCII key press commands and enable the indicator to be used in legacy systems.

The response setting (RESP) defines if there is any response sent to successful commands. A setting of OK will send OK<CR> on successful receipt of command or ??<CR> if the command is not understood.

Function	Simple commands
Zero Key	Z<CR>, %z, \FAh, KZERO<CR>, MZ<CR>, m<CR>, KZ00<CR>(*), @00CZER<CR>(*), @00MZ<CR>(*)
Tare Key	T<CR>, %t, \F4h, KTARE<CR>, MT<CR>, t<CR>, KT00<CR>(*), @00CTAR<CR>(*), @00MT<CR>(*)
Gross/Net Key	%s, \F3h, KGROSSNET<CR>, KG00<CR>(*)
To Gross	G<CR>, 0%s, KGROSS<CR>, MG<CR>, C<CR>, r, @00CGRS<CR>(*), @00MG<CR>(*)
To Net	N<CR>, 1%s, KNET<CR>, MN<CR>, n<CR>, @00CNET<CR>(*), @00MN<CR>(*)
Print Key	%p, \F0h, KPRINT<CR>, KP00<CR>(*)
Single	P<CR>, W<CR>, \05h, \95h, \96h, S<CR>, H<CR>, R<CR>, Q<CR>, RW<CR>, Kp00<CR>(*), @00RDSP<CR>(*), @00RW<CR>(*)
0..9 Keys	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, ., K0<CR>, K1<CR>, K2<CR>, K3<CR>, K4<CR>, K5<CR>, K6<CR>, K7<CR>, K8<CR>, K9<CR>, KDOT<CR>
OK Key	%e, \E5h, \0Dh, KENTER<CR>
Cancel Key	\1Bh

* 00 is the broadcast address, this can be changed to an individual instrument's address.

9.4. Network Protocol BARCODE

The barcode network protocol allows a barcode scanner to be connected to the instrument to select the product. The source setting allows the product to be selected based on its name, barcode, or ID number. To select the example product:

Name: abcdefghi
Barcode: 123456789abcd
ID: 200

With barcode protocol source set to NAME send:
abcdefghi <CR><LF>

With barcode protocol source set to BARCODE send:
123456789abcd<CR><LF>

With barcode protocol source set to ID send:
200<CR><LF>

9.5. rinCMD Examples

	Description
<p>Read Gross Weight (Read Final)</p> <p>COMMAND : 20110026↵</p> <p>RESPONSE : 81110026:00000064↵</p>	<p>COMMAND : Read Gross Weight (Register 0026): ADDR = 20H: Reply required from any instrument CMD = 11H: Read Final REG = 0026H: Gross Weight</p> <p>RESPONSE : Response is from instrument #1 which currently has a Gross weight of 64 H = 100 kg.</p>
<p>Read Gross Weight (Read Literal)</p> <p>COMMAND : 20050026↵</p> <p>RESPONSE : 81050026: 100 kg G↵</p>	<p>COMMAND : Read Gross Weight (Register 0026 H): ADDR = 20H: Reply required from any instrument CMD = 05H: Read Literal REG = 0026H: Gross Weight</p> <p>RESPONSE : Same response from instrument #1 but in literal format.</p>
<p>Set Print Header (Write Final, Execute)</p> <p>COMMAND A : 2112A381: Hello There↵</p> <p>RESPONSE A : C112A381:9000↵</p> <p>COMMAND B : 2112001A:4D2↵</p> <p>RESPONSE B : 8112001A:0000↵</p> <p>COMMAND C : 2112A381: Hello There↵</p> <p>RESPONSE C : 8112A381:0000↵</p> <p>COMMAND D : 21100010↵</p> <p>RESPONSE D : 81100010:0000↵</p>	<p>COMMAND A : Write Print Header String (Register A381 H) ADDR = 21H: Reply required from instrument #1 CMD = 12H: Write Final REG = A381H: Print Header String DATA = 'Hello There'</p> <p>RESPONSE A : Instrument #1 reports "ERROR: Access Denied". (Writing to this register requires a passcode)</p> <p>COMMAND B : Enter SAFE SETUP Passcode (Register 1A H) ADDR = 21H: Reply required from instrument #1 CMD = 12H: Write Final REG = 1AH: Enter SAFE PASSCODE DATA = 4D2H (passcode is 1234)</p> <p>RESPONSE B : Instrument #1 reports Passcode Accepted</p> <p>COMMAND C : resend COMMAND A) .</p> <p>RESPONSE C : Instrument #1 reports "Command Successful".</p> <p>COMMAND D : Save Settings (Register 10H) ADDR = 21H: Reply required from instrument #1 CMD = 10H: Execute REG = 10H: Save Settings</p> <p>RESPONSE D : Instrument #1 reports "Command Successful".</p>

Trigger Zero Button Press (Write Final)	Description
<p>COMMAND A: 21120008:0B↵</p> <p>RESPONSE A: 81120008:0000↵</p> <p>COMMAND B: 21120008:8E↵</p> <p>RESPONSE B: 81120008:0000↵</p>	<p>COMMAND A: Send down the Zero button key code.</p> <p>RESPONSE A: Instrument #1 reports "Command Successful".</p> <p>COMMAND B: Do a long press of the F1 key.</p> <p>RESPONSE B: Instrument #1 reports "Command Successful".</p>
<p>Streaming (Write Final, Read Final, Execute)</p> <p>COMMAND A: 21120042:06↵</p> <p>RESPONSE A: 81120042:0000↵</p> <p>COMMAND B: 21120043:11↵</p> <p>RESPONSE B: 81120043:0000↵</p> <p>COMMAND C: 21110040↵</p> <p>RESPONSE C: 81110040:000005DB0000009↵</p> <p>COMMAND D: 21120041:03↵</p> <p>RESPONSE D: 81120041:0000↵</p> <p>COMMAND E: 21100040:1↵</p> <p>RESPONSE E: 81100040:00000000↵ 81110040:000005DB0000009↵ 81110040:000005DB0000009↵</p> <p>COMMAND G: 21100040:0↵</p> <p>RESPONSE G: 81100040:00000000↵</p>	<p>COMMAND A: Setup to read the displayed weight.</p> <p>RESPONSE A: Instrument #1 reports "Command Successful".</p> <p>COMMAND B: Setup to read the IO status.</p> <p>RESPONSE B: Instrument #1 reports "Command Successful".</p> <p>COMMAND C: Read the combined data.</p> <p>RESPONSE C: Data is concatenated. It is 8 hexadecimal digits each.</p> <p>COMMAND D: Set streaming to 3Hz.</p> <p>RESPONSE D: Instrument #1 reports "Command Successful".</p> <p>COMMAND E: Start the automatic streaming.</p> <p>RESPONSE E: Instrument #1 reports "Command Successful" followed by streamed data at 3Hz.</p> <p>COMMAND G: Stop the automatic streaming.</p> <p>RESPONSE G: Instrument #1 reports "Command Successful".</p>

10. Automatic Weight Output

10.1. Overview

The automatic output is normally used to drive remote displays, a dedicated computer, or PLC communications. It is configured using the **SER.AUT** menu. The RS-232 or the RS-485 port can be used.

The rate of transmission is set by the TYPE setting. AUTO.LO and AUTO.HI send unsolicited messages at 10Hz and 25Hz respectively. SINGLE only sends messages when a SINGLE input is received from an external input. This enables external systems like PLCs to synchronise the AUTO output to their requirements. AUT.TRC sends a message for every traceable weight and is usually combined with FMT.TRC to provide a tally roll printer log.

10.2. Auto Weight Format String

The weight format string may be set to the following formats:

Format	Description
FMT.A	<STX> <SIGN> <WEIGHT(7)> <STATUS> <ETX>
FMT.B	<STX> <S0> <SIGN> <WEIGHT(7)> <UNITS(3)> <ETX>
FMT.C	<STX> <SIGN> <WEIGHT(7)> <S1> <S2> <S3> <S4> <UNITS(3)> <ETX>
FMT.D	<STX> <SIGN> <WEIGHT(7)> <ETX>
FMT.E	<STX> <SIGN> <WEIGHT(7)> <S5> <UNITS(3)> <MODE(4)> <ETX>
FMT.REG	ADDR CMD REG : DATA
FMT.TRC	CONSEC SP DATE SP TIME SP TRACE <CR><LF>
CUSTOM	As per contents of the EV.AUTO token string.
FMT.F	<STX> <SIGN> <WEIGHT(7)> <UNITS> <S1> <S2> <CR> <LF>
FMT.G	<STX> <SIGN> <WEIGHT(7)> <S1> <S2> <S3> <S4> <UNITS(3)> <ETX>

Where

- **STX**: Start of transmission character (ASCII 02).
- **ETX**: End of transmission character (ASCII 03).
- **SIGN**^(Except FMT.G): The sign of the weight reading (space (or plus (+) for FMT.F) for positive, dash (-) for negative).
- **SIGN**^(FMT.G):

Represents the sign of the weight string and serial traffic light control. Both the sign character and traffic lights can be displayed at the same time.

0x20 = No Sign or Traffic light	0x2D = '-' Sign
0x30 = RED	0x3D = Red and '-' Sign
0x60 = GREEN	0x6D = GREEN and '-' Sign
0x70 = RED + GREEN	0x7D = RED + GREEN and '-' Sign

Example:

0x60 will display a Green but no negative sign

0x6D will display both the Green and the negative sign represents the sign of the weight reading and serial traffic light control. Space 0x20 for positive, Dash (-) 0x2D for negative, 0x31 for RED light, 0x32 for GREEN light and 0x33 for RED + GREEN

- **WEIGHT(7)**: A seven-character string containing the current weight including the decimal point. If there is no decimal point, then the first character is a space. Leading zero blanking applies.
- **S0**: Provides information on the weight reading. The characters G/N/U/O/M/E represent Gross / Net / Underload / Overload / Motion / Error, respectively.
- **UNITS(3)**: A three character string, the first character being a space, followed by the actual units (e.g. ^kg or ^^t). If the weight reading is not stable, the unit string is sent as ^^^.
- **S1**: Displays G/N/U/O/E representing Gross / Net / Underload / Overload / Error, respectively.

- **S2:** Displays M/^ representing Motion / Stable, respectively.
- **S3:** Displays Z/^ representing centre of Zero / Non-Zero, respectively.
- **S4:** Displays - representing single range.
- **S5:** Displays “ / “m” / “c” representing Stable / Motion / Overload or Underload
- **Mode:** Displays “_g_” or “_n_” for gross or net weight.
- **‘ADDR CMD REG : DATA’:** This is the same format as the response from a READ FINAL network command.
- **SP:** Space character, “ “
- **CONSEC:** Consecutive print ID
- **DATE, TIME:** Date and time.
- **TRACE:** Traceable displayed weight.

11. Printing

11.1. Overview

The instrument can have up to two (2) printouts. There are three (3) types of printout:

- **RECORD:** Record printouts are essentially a single printout generated by a single print event.
- **DOCKET:** Docket printouts are comprised typically of the output of a number of print events. There is a start section that includes header information, followed by a number of transactions and finally the end of the docket including sub-total information etc.
- **REPORT:** Reports are used to print stored accumulation data for each product.

There are two different fixed formats for each printout type defined in the instrument. The format of these printouts is shown in the following sections.

For custom printing each print event has an associated token string which includes literal ASCII text along with special token characters that are expanded at the time of printing to fields like weight, time and date.

11.2. Print ID

A unique Consecutive Print ID appears on record printouts. It cannot be cleared and increments for every traceable weight reading. Additionally, a Settable Consecutive Print ID is available through custom printing. It can be viewed and edited through the operator interface User ID key (long press key 5).

11.3. Record printouts

Format	Example
FMT.A	001234 01/01/2003 11:30 100.4 kg G TOMATOES
FMT.B	Joe's Fruit & Veg 30 Yarmouth Pde Tamworth NSW 2040 01/01/2003 11:30 ID: 001234 TOMATOES T: 5.0 kg G: 100.4 kg N: 95.4 kg Thank You!
CUSTOM	Format defined by REC.PRN token string.

11.4. Docket printouts

Format	Example
FMT.A	Joe's Fruit & Veg 30 Yarmouth Pde Tamworth NSW 2040 13/03/03 11:09:27 Onions 4.06 kg, 5.04 kg, 3.15 kg, Apples 5.02 kg, 4.48 kg, 6.15 kg, Total 27.90 kg Thank You!
FMT.B	Joe's Fruit & Veg

	<p>30 Yarmouth Pde Tamworth NSW 2040 13/03/03 11:09:27</p> <p>Onions</p> <p style="padding-left: 100px;">4.06 kg 5.04 kg 3.15 kg</p> <p style="padding-left: 20px;">Sub 12.25 kg</p> <p>Apples</p> <p style="padding-left: 100px;">5.02 kg 4.48 kg 6.15 kg</p> <p style="padding-left: 20px;">Sub 15.65 kg</p> <p>Total 27.90 kg Thank You!</p>
CUSTOM	<p>EV.D.NEW (Event Docket New) controls the first part of the docket that is printed along with the first transaction.</p> <p>PRN.KEY (Event Print) controls the format of each transaction on the docket.</p> <p>EV.D.END (Event Docket End) controls the format of the end of the docket including printing sub-totals etc.</p> <p>EV.P.NEW (Event Product New) used when a new product is selected.</p> <p>EV.P.END (Event Product End) used when a product is no longer active.</p>

11.5. Report printouts

Format	Example
FMT.A	<p>13/03/2003 11:09:27 Grand Total Apples 5.65 kg Onions 2.25 kg Total 7.90 kg</p>
FMT.B	<p>13/03/2003 11:09:27 Grand Total Apples 5.65 kg, Onions 2.25 kg Total 7.90 kg</p>
CUSTOM	<p>REP.ST (Report Start) defines the start of the report.</p> <p>REP.PR (Report Product) defines what is printed for each product.</p> <p>REP.END (Report End) defines the end of the report.</p>

11.6. Custom Printing

A print docket is built up of multiple print passes. Each of the print passes is defined by a specific configuration string. Print passes are triggered by operator events – these include short and long press of the Print key and actions like changing products.

The content of the configuration string for each event includes direct text (the word “Weight” to be placed near the current weight for example) and control characters called ‘Tokens’. Tokens are used to specify where the instrument data fields are to be inserted.

Tokens are characters outside the normal printable range. Each token character is represented by a three-character escape sequence consisting of a ‘\’ followed by two hex characters or by a three-digit decimal ASCII number. When entering tokens via the instrument keys the decimal ASCII code is used. When entering tokens using the viewer software the escape sequence is used.

Examples of tokens:

\D7 (ASCII 215) = current displayed weight
 \BF (ASCII 191) = date
 \C0 (ASCII 192) = time

A simple custom format string might be:

‘Weight: \D7\C1’

To produce Weight: 30.0kg ^ when the print key is pressed.

Events are triggered by short and long press of the Print key and changing products as listed as listed in the tables for each type.

Below are some examples of dockets and reports and their associated custom print strings.

Docket Example Print Outs	Custom Print Strings
Joe's Nuts 13/03/03 11:09:27 Peanuts 4.06 kg, 5.04 kg, Almonds 5.02 kg, 4.48 kg, Total 18.60 kg Thank You!	EV.D.NEW: \C3\C6\C1\BF \C0 PRN.KEY: \BA\E9, EV.P.NEW: \C1\BA\D7 EV.P.END: EV.D.END: \B8\C1Total: \DD\C1\C7\C1\C4
Joe's Nuts 13/03/03 11:09:27 Peanuts 4.06 kg 5.04 kg Sub 9.10 kg Almonds 5.02 kg 4.48 kg Sub 9.50 kg	EV.D.NEW: \C3\C6\C1\BF \C0\C1 PRN.KEY: \BA \E9\C1 EV.P.NEW: \C1\BA\D7\C1 EV.P.END: \BA Sub \DD\EC\C1 EV.D.END: \B8\C1Total \DD\C1\C7\C1\C4

Total 18.60 kg Thank You!	
------------------------------	--

Report Example Print Outs	Custom Print Strings
13/03/2003 11:09:27 Grand Total Peanuts 5.65 kg Almonds 2.25 kg Total 7.90 kg	REP.ST: \C3\BF \C0\C1Grand Total\C1 REP.PR: \BA\D7 \D9\C1 REP.END: Total \B8\D9\C1\C4
13/03/2003 11:09:27 Grand Total Peanuts 5.65 kg, Almonds 2.25 kg Total 7.90 kg	REP.ST: \C3\BF \C0\C1Grand Total\C1 REP.PR: \BA\D7 \D9, REP.END: \C1Total \B8\D9\C1\C4

11.6.1. Page Tokens

The page number token must be used prior to the required token in the custom print string. For example, the token D7 is used in both Page 0 and Page 4 and has different meanings.

Custom Print String: \BE\D7

Code	Token	
190	(BE _H)	Page 0: Current Weight
215	(D7 _H)	Displayed reading (gross or net)

Custom Print String: \BA\D7

Code	Token	
186	(BA _H)	Page 4: Current Product
215	(D7 _H)	Product name

Refer to Page tokens on page 95 for the list of codes for the tables. The various tables are defined in sections 16.3.3, 16.3.4, 16.3.5, 16.3.6, and 16.3.7 on pages 96 ,97, 97, 98, and 99, respectively.

12. Special Functions

12.1. Introduction



The instrument has 3 special function keys on the front panel. The function of these keys can be configured to any of the key functions detailed below.



<FUNCTION> keys have no primary function pre-programmed. Each primary function has an associated overlay sticker (supplied) that should be applied to the function key to label the function. Ensure the keypad is clean and dry before affixing the sticker. Refer to Cleaning page 9 for more information.

12.2. Key Functions


12.2.1. NONE

When set to **NONE** the special function key is not used during normal operation. This is the default setting.

12.2.2. PRINT

A print key can be used to trigger any of the configured printouts. It can also add to totals or undo the last add. When docket printing, a long press ends the docket.

◆ Short press




Tomatoes		
	5.02	kg
	4.48	kg
	6.15	kg
Sub	15.65	kg
Total	27.90	

← Short Press

← Long Press


12.2.3. SINGLE

A single key is a manual trigger for the serial automatic transmit. A single automatic transmit string is sent when this key is pressed. This may be useful where a continual stream of serial data is not wanted.



12.2.4. TEST

A test key is used to start a display test.




12.2.5. PRD.SEL

A short press of the product select button will cycle the total display (for the current product) though the available totals information. A long press allows the current product to be selected by number rather than name.


◆ Short press

Cycles the display of totals information.




◆ Long press

Select product by number.



12.2.6. SLAVE

A short press of the slave key will cycle through each slave weight followed by each subtotal on the lower display. The name of the slave or subtotal will be shown in the lower right display.




12.2.7. SC.EXIT

A short press of the scale exit button will trigger the scale exit setpoint if the weight is outside of the zero band.

12.2.8. A.TARE

A short press of the auto tare button will enable or disable the auto tare feature, a capital A will be seen at the top left of the display when auto tare is enabled.



13. Setpoints

13.1. Overview

The K481 software supports up to 16 separate setpoints. Each setpoint is independently configured for a particular function and can be associated with a particular Output Driver. The setpoint can be configured to flash the instrument display or sound a buzzer as well as driving a physical output.

NOTE: As the summing indicator retrieves its weight data via serial communications, delays are introduced. Hence it is not advisable to drive process control from outputs from the K481 in situations where high speed control is required.

13.2. Outputs

The instrument supports 32 input/output control points. The application software uses these control points to decide what the control functions are, and the accessory modules respond according to their specific hardware.

Setpointing requires the use of outputs so it is important to select IO control points that have associated hardware output drivers that suit your application.

13.3. Common Settings

There are a number of settings that are common to all setpoint types. These are as follows:

- **OUTPUT:** Select which IO control point to use. Options are NONE, IO1..IO32. NONE is useful if the setpoint is only being used trigger an alarm.
- **LOGIC:** This setting determines whether the output is normally on or normally off. Logic HIGH means the output follows the activity of the setpoint and is on when the setpoint conditions are met. Logic LOW reverses the operation of the output.

For example: Consider a Centre-of-Zero status setpoint. This type of setpoint is active when the Centre-of-Zero annunciator is lit. With logic HIGH an output would turn on whenever the Centre-of-Zero annunciator was lit. With logic LOW the output would turn off when the Centre-of-Zero annunciator is lit and remain on otherwise.


Note that the outputs revert to the off state when the instrument SETUP menus are active.

- **ALARM:** Select what alarm response is triggered when the setpoint is active. SINGLE sounds a single beep every two seconds, DOUBLE sounds a double beep every two seconds and FLASH flashes the instrument display. Note that the Alarm conditions are not influenced by the LOGIC setting, i.e. they follow the activity of the setpoint regardless of the physical state of the output.
- **TIMING:** Select the output timing of the setpoint. The following examples are explained in the context of an OVER setpoint, however the timing options are available for all setpoint types. For further clarification see Figure 8: OVER setpoint timing options on page 82.

Options are:


- LEVEL: the setpoint is active whenever the weight has gone over the target, has not dropped below the hysteresis value and the reset input is not currently active.
- EDGE: The setpoint becomes active when the weight goes over the target. The setpoint becomes inactive when the weight goes below the hysteresis value or the reset input becomes active.
- PULSE: Once the weight goes over the target the setpoint will begin the delay time. Once that time has elapsed the output will become active for the on time. If the pulse number (PLS.NUM) has been set for more than one then the cycle will repeat for the set number of times. The reset input becoming active is the only reason the set number of cycles will not be completed; the weight is completely ignored once the cycle has started.
- LATCH: The setpoint becomes active when the weight goes over the target. The setpoint becomes inactive when the reset input becomes active.
- **RESET:** Select which IO is used as an input to disable the setpoint. Options are NONE, IO1..IO32.
- **RST.LGC:** This setting determines whether the input used to reset the setpoint is active when the value is LOW or HIGH.
- **DELAY:** If the timing has been set to PULSE this sets the delay before each pulse.
- **ON:** If the timing has been set to PULSE this sets the duration of each pulse.
- **PLS.NUM:** If the timing has been set to PULSE this sets the number of pulses to be output each time the setpoint is triggered.
- **NAME:** Name the setpoint. This will be shown when editing targets for OVER or UNDER type setpoints.

13.4. Weigh in (OVER) Setpoints and Weigh Out (UNDER) Setpoints



LOGIC	Point A	Point B
HIGH	ON	OFF
LOW	OFF	ON

Figure 7: OVER versus UNDER setpoints.



D = DELAY time
 O = ON time
 P = Number of pulses (PLS.NUM)

Figure 8: OVER setpoint timing options

13.4.1. Additional Settings

In addition to the common settings the following settings control the operation of the OVER and UNDER setpoints

- **SOURCE:** Select the weight source for the setpoint to use.

Options are:

- 'GR or NT' uses either gross or net depending on which is currently displayed.
- REG: uses a register value.
- **SCOPE:** GLOBAL means that the same targets are used for every product. PROD lets each product have its own target values for the setpoint.
- **Hysteresis (HYS):** This setting determines the change in weight required for an active setpoint to become inactive again. A value of zero still leaves 0.5 graduations of hysteresis.
- **REG:** If the source is set to register (REG) then this setting is used to set the register to use. The register must be a number or weight value.

13.5. Status Based Setpoint Types

The following setpoint types are all based on the status of the instrument.

- **NONE:** Setpoint is always inactive.
- **ON:** Setpoint is always active. This type of setpoint is useful to show that the instrument is running.
- **Centre of Zero (COZ):** Setpoint is active when COZ annunciator is lit.
- **ZERO:** Setpoint is active when the weight is within the Zero Band setting.
- **NET:** Setpoint is active when the NET annunciator is lit.
- **MOTION:** Setpoint is active when the MOTION annunciator is lit.
- **ERROR:** Setpoint is active when the instrument detects any error condition signified by the display of Exxxxx on the primary display.
- **BUZZER:** Setpoint is active when the buzzer beeps.

13.6. Logic Setpoint Types

The following setpoint types are all based on the status of the inputs and the mask.

- **AND (LGC.AND)**: Setpoint is active when all inputs in the mask are on.
- **OR (LGC.OR)**: Setpoint is active when any inputs in the mask are on.
- **XOR (LGC.XOR)**: Setpoint is active when only one input in the mask is on.

SOURCE: Select the source for the setpoint to use.

Options are:

- **IO** use the external IO
- **Status** use the instrument status
- **SETP** use the setpoint status
- **REG** use a register value

REG: If the source is set to register (REG) then this setting is used to set the register to use. The register must be a number or weight value. The decimal value of the register address should be used.

MASK: A 32-bit number that is used to match against the selected source. If the source is set to IO then IO1 is the least significant (first) bit and IO32 is the most significant (32nd) bit. If the source is set to setpoint (SETP) then setpoint 1 is the least significant (first) bit and setpoint 16 is the sixteenth bit. The instrument status is broken down in the following table. This number should be entered as a decimal value.

Status info	Bit
Unused	Bits 17-32
No errors	16
Overload	15
Underload	14
Error	13
Preset tare not active	12
Preset tare active	11
High range	10
Low range	9
Stable	8
Motion	7
Not centre-of-zero	6
Centre-of-zero	5
Not Zero	4
Zero	3
Gross	2
Net	1

Table 4 : Instrument Status for Logic Setpoints

SETP info	Bit
Not setpoint 16	32
Not setpoint 15	31
Not setpoint 14	30
Not setpoint 13	29
Not setpoint 12	28
Not setpoint 11	27
Not setpoint 10	26
Not setpoint 9	25
Not setpoint 8	24
Not setpoint 7	23
Not setpoint 6	22
Not setpoint 5	21
Not setpoint 4	20
Not setpoint 3	19
Not setpoint 2	18
Not setpoint 1	17
Setpoint 16	16
Setpoint 15	15
Setpoint 14	14
Setpoint 13	13
Setpoint 12	12
Setpoint 11	11
Setpoint 10	10
Setpoint 9	9
Setpoint 8	8
Setpoint 7	7
Setpoint 6	6
Setpoint 5	5
Setpoint 4	4
Setpoint 3	3
Setpoint 2	2
Setpoint 1	1

Table 5: Setpoint status for logic setpoints

13.7. Scale Entry/Exit Setpoint Types

The following setpoint types are all based on the status of the indicator.

- **Scale Ready (SC.REDY):** Setpoint is active when in the zero band and stable for longer than the time set in RDY.TIM.
- **Scale Exit (SC.EXIT):** Setpoint is active when outside of the zero band and either a print has occurred or the scale exit (SC.EXIT) special function has been triggered.

Ready Time (RDY.TIM): Time in seconds that the scale must be stable in the zero band before the scale is ready.

14. Analogue Output

14.1. Overview

The K481 software supports a single analogue output used for analogue weight transmission. Setting up a system is a two-stage process:

- First install the analogue output hardware and configure, calibrate and test the accessory module using the options in the H.WARE:ANL.HW menu.
- Second, configure the parameters of the information to be sent to the analogue output from the ANL.OUT menu.

14.2. Configuration of Hardware

14.2.1. Configuration

TYPE: Set the TYPE to VOLTAGE (0..10V) or CURRENT (4..20mA). The analogue accessory will light an LED to indicate which output type is active.

CLIP: The CLIP setting determines if the analogue output is allowed to extend past the nominal limits. If CLIP is ON, the output will not go below 0V or above 10V for voltage outputs. For current output the limits are 4mA and 20mA. If CLIP is OFF the voltage can extend an extra 0.5 Volts or so past the limits and the current can extend from 0mA to 24mA.

14.2.2. Calibration

Calibrate the lower and upper values of the analogue output using the CAL.LO and CAL.HI functions. Use the UP and DOWN arrows to adjust the output to the external system.

14.2.3. Testing

The analogue output can be driven to any value using the FRC.OUT function. Use the UP and DOWN arrows to move the output up and down to test that the values shown on the instrument display match the readings taken externally.

14.3. Analogue Weight Transmission

ABS (Absolute): This setting allows negative weight readings to be treated as positive values for the purposes of the analogue output transmission. This is especially useful when transmitting negative net readings in WEIGH-OUT applications.

WGT.LO (Weight Low) and **WGT.HI (Weight High)** settings specify the weight range that corresponds to the analogue output range. For example, it is possible to set the instrument up to send a 0..10V signal between 10.0 kg and 20.0 kg even though the scale is calibrated to measure weight from 0.0kg to 50.0kg. This effectively increases the resolution of the analogue output over the weight range of interest.

15. Appendix 1: Dimensions

15.1. Dimensions












Table 6: Dimensions

Stainless Steel Weight Indicator		Dimensions in mm (1 inch = 25.4 mm)	
<p>3D View</p> 	<p>Front View</p> 		
<p>Side View Recommended Maximum Installation Panel Thickness: 6mm</p> 	<p>Back View</p> 		
Stainless Steel Weight Indicator (With Rear Enclosure)		Dimensions in mm (1 inch = 25.4 mm)	
<p>3D View</p> 	<p>Front View</p> 		
<p>Side View</p> 	<p>Bottom View</p> 		

15.2. Legal Sealing Details

There are several methods of legally sealing the instrument. The method chosen will depend on local regulations.

15.2.1. Trade Label

A trade label showing scale and instrument information is usually required. This can be placed on the front of the instrument:




Figure 9: Trade label position.

15.2.2. Lead Seals

There are 2 methods of sealing the instrument with lead and wire seals:




Figure 10: Lead seal on rear of instrument.




Figure 11: Lead seal on boot.

15.2.3. Destructible Sticker Seals

There are 2 methods of sealing with destructible stickers:




Figure 12: Destructible sticker seal on rear of instrument.




Figure 13: Destructible sticker seal on boot.

15.2.4. Electronic Seal

The value of the calibration counter should be written on the scale certification/sealing sticker. See page 35 for as description of the calibration counter.

16. Appendix 2: Print and Automatic Transmission Tokens

16.1. ASCII codes

Code	Char	Code	Ch	Code	Ch	Code	Ch	Code	Ch
000 (*)	NULL	026 (1AH)	SUB	052 (34H)	'4'	078 (4EH)	'N'	104 (68H)	'h'
001 (01H)	SOH	027 (1BH)	ESC	053 (35H)	'5'	079(4FH)	'O'	105 (69H)	'i'
002 (02H)	STX	028 (1CH)	FS	054 (36H)	'6'	080 (50H)	'P'	106 (6AH)	'j'
003 (03H)	ETX	029 (1DH)	GS	055 (37H)	'7'	081 (51H)	'Q'	107 (6BH)	'k'
004 (04H)	EOT	030 (1EH)	RS	056 (38H)	'8'	082 (52H)	'R'	108 (6CH)	'l'
005 (05H)	ENQ	031 (1FH)	US	057 (39H)	'9'	083 (53H)	'S'	109 (6DH)	'm'
006 (06H)	ACK	032 (20H)	' '	058 (3AH)	':'	084 (54H)	'T'	110 (6EH)	'n'
007 (07H)	BEL	033 (21H)	'!	059 (3BH)	','	085 (55H)	'U'	111 (6FH)	'o'
008 (08H)	BS	034 (22H)	'"'	060 (3CH)	'<'	086 (56H)	'V'	112 (70H)	'p'
009 (09H)	HT	035 (23H)	'#'	061 (3DH)	'='	087 (57H)	'W'	113 (71H)	'q'
010 (0AH)	LF	036 (24H)	'\$'	062 (3EH)	'>'	088 (58H)	'X'	114 (72H)	'r'
011 (0BH)	VT	037 (25H)	'%'	063 (3FH)	'?'	089 (59H)	'Y'	115 (73H)	's'
012 (0CH)	FF	038 (26H)	'&'	064 (40H)	'@'	090 (5AH)	'Z'	116 (74H)	't'
013 (0DH)	CR	039 (27H)	'''	065 (41H)	'A'	091 (5BH)	'['	117 (75H)	'u'
014 (0EH)	SO	040 (28H)	'('	066 (42H)	'B'	092 (5CH)	'\'	118 (76H)	'v'
015 (0FH)	SI	041 (29H)	')'	067 (43H)	'C'	093 (5DH)	']'	119 (77H)	'w'
016 (10H)	DLE	042 (2AH)	'*'	068 (44H)	'D'	094 (5EH)	'^'	120 (78H)	'x'
017 (11H)	DC1	043 (2BH)	'+'	069 (45H)	'E'	095 (5FH)	'_'	121 (79H)	'y'
018 (12H)	DC2	044 (2CH)	','	070 (46H)	'F'	096 (60H)	''	122 (7AH)	'z'
019 (13H)	DC3	045 (2DH)	'-'	071 (47H)	'G'	097 (61H)	'a'	123 (7BH)	'{'
020 (14H)	DC4	046 (2EH)	'.'	072 (48H)	'H'	098 (62H)	'b'	124 (7CH)	' '
021 (15H)	NAK	047 (2FH)	','	073 (49H)	'I'	099 (63H)	'c'	125 (7DH)	'}'
022 (16H)	SYN	048 (30H)	'0'	074 (4AH)	'J'	100 (64H)	'd'	126 (7EH)	'~'
023 (17H)	ETB	049 (31H)	'1'	075 (4BH)	'K'	101 (65H)	'e'	127 (7FH)	DEL
024 (18H)	CAN	050 (32H)	'2'	076 (4CH)	'L'	102 (66H)	'f'		
025 (19H)	EM	051 (33H)	'3'	077 (4DH)	'M'	103 (67H)	'g'		

Table 7: ASCII Table

(*) Use ASCII 128 to implement a literal NULL character in a custom string. ASCII 0 is used to define the end of the string.

16.2. Use of Characters in the Extended ASCII table

To use characters in the extended ASCII table, 026 (1AH) should be used - it will allow the next character in a custom print string to be sent directly.

Example:

\1A\84 would be ä

16.3. Tokens

Tokens are special ASCII characters outside the normal printing range. These characters are used to specify where instrument data fields like 'Current Weight' are to be inserted into custom format strings.

16.3.1. Non-paged generic tokens

Code	Token
128 (80 _H)	ASCII NULL (send an ASCII 00H character)
191 (BF _H)	Date
192 (C0 _H)	Time
193 (C1 _H)	Newline
194 (C2 _H)	Left spaces
195 (C3 _H)	Top blank lines
196 (C4 _H)	Bottom blank lines
197 (C5 _H)	Unique consecutive print ID
198 (C6 _H)	Header
199 (C7 _H)	Footer
200 (C8 _H)	Page end string
201 (C9 _H)	User String Data 1
202 (CA _H)	User String Data 2
203 (CB _H)	User String Data 3
206 (CE _H)	User String Name 1
207 (CF _H)	User String Name 2
208 (D0 _H)	User String Name 3
213 (D5 _H)	Settable consecutive print ID
214 (D6 _H)	Reset to 1 the settable consecutive print ID

Table 8: Print tokens: generic

16.3.2. Page tokens

As there is too much data to represent as individual tokens, the tokens are divided into pages. A page token is used to define the page for all subsequent tokens.

Code	Token
190 (BE _H)	Page 0: Current Weight
189 (BD _H)	Page 1: Held Weight
188 (BC _H)	Page 2: Held or Current Weight
187 (BB _H)	Page 3: Traceable Weight
186 (BA _H)	Page 4: Current Product
185 (B9 _H)	Page 5: Session Total
184 (B8 _H)	Page 6: Grand Total
183 (B7 _H)	Page 7: Register Data
182 (B6 _H)	Page 8: Miscellaneous Data
181 (B5 _H)	Page 9: Summing Data

Table 9: Print tokens: pages

16.3.3. Page 0, 1, 2, 3, 7 tokens: Weight Information

These pages hold weight information. The same codes are used for each page.

Code	Token	
215 (D7 _H)	Displayed reading (gross or net)	
216 (D8 _H)	Gross reading	
217 (D9 _H)	Net reading	
218 (DA _H)	Piece reading	
219 (DB _H)	Alternative displayed reading (gross or net)	
220 (DC _H)	Alternative gross reading	
221 (DD _H)	Alternative net reading	
222 (DE _H)	mV/V value	
223 (DF _H)	Absolute gross peak reading	
224 (E0 _H)	Preset tare value	
225 (E1 _H)	Tare value (tare or preset tare)	
226 (E2 _H)	Tare label (T or PT)	
227 (E3 _H)	Unit ID	page 0 only
	Register Header	Page 7 only
228 (E4 _H)	Ticket end	page 0 only
	Register Footer	Page 7 only
229 (E5 _H)	Status 0: Error, Overload, Underload, Motion, Net, Gross (Uses last weight sent)	page 0 only
230 (E6 _H)	Status 1: Error, Overload, Underload, Net, Gross (Uses last weight sent)	page 0 only
231 (E7 _H)	Status 2: Motion , ‘ ‘	page 0 only
232 (E8 _H)	Status 3: Centre of Zero , ‘ ‘	page 0 only
233 (E9 _H)	Status 4: - , Range 1 , Range 2 (Uses last weight sent)	page 0 only
234 (EA _H)	Status 5: C , Motion , ‘ ‘	page 0 only
235 (EB _H)	Status 6: N Net , G Gross (Uses last weight sent)	page 0 only
236 (EC _H)	Status 7: Error, Overload, Underload, Motion, Net, Gross (Uses automatic transmission reading)	page 0 only
237 (ED _H)	Automatic transmit reading	page 0 only
238 (EE _H)	Automatic transmit start characters	page 0 only
239 (EF _H)	Automatic transmit end characters	page 0 only
240 (F0 _H)	Weight units	page 0 only
241 (F1 _H)	Displayed string (primary display)	page 0 only
242 (F2 _H)	Displayed unit (primary display)	page 0 only
243 (F3 _H)	Auto Transmit FMT.REG header	page 0 only
244 (F4 _H)	Auto Transmit FMT.REG weight	page 0 only
245 (F5 _H)	Auto Transmit FMT.REG status	page 0 only
246 (F6 _H)	Auto Transmit FMT.REG footer	page 0 only
247 (F7 _H)	Alternative Tare value	page 0 only
248 (F8 _H)	Status 8: Overload, Underload, In range	page 0 only
249 (F9 _H)	Status 9: Motion, Stable	page 0 only
250 (FA _H)	Status 10: OL over/underload, US unstable, ST stable	page 0 only
251 (FB _H)	Status 11: Gross, Net	page 0 only
252 (FC _H)	IO status	page 0 only
253 (FD _H)	Setpoint status	page 0 only

Table 10: Print tokens: weight information

16.3.4. Page 4, 5, 6 tokens: Product Information

These pages hold product information where:

Code	Token
215 (D7 _H)	Product name
216 (D8 _H)	Barcode
217 (D9 _H)	Total weight
218 (DA _H)	Total alternative weight
219 (DB _H)	Total pieces
220 (DC _H)	Number of adds
221 (DD _H)	Total docket weight
222 (DE _H)	Total docket alternative weight
223 (DF _H)	Total docket pieces
224 (E0 _H)	Number of docket adds
225 (E1 _H)	Preset tare
226 (E2 _H)	Counting sample weight
227 (E3 _H)	Counting sample pieces
228 (E4 _H)	Counting piece weight
229 (E5 _H)	Alternative weight conversion
233 (E9 _H)	Last weight added
234 (EA _H)	Last alternative weight added
235 (EB _H)	Last pieces added
236 (EC _H)	Clear docket totals
237 (ED _H)	Reset last product add
238 (EE _H)	Clear totals on all products

Table 11: Print tokens: product information

16.3.5. Page 8 tokens: Miscellaneous weight data

These tokens hold weight/alternate weight information depending on which is being displayed.

Code	Token
215 (D7 _H)	Displayed reading (gross or net)
216 (D8 _H)	Gross reading
217 (D9 _H)	Net reading
218 (DA _H)	Tare value (tare or preset tare)
219 (DB _H)	Status 12: weight units: Kg, Lb , ‘ ‘
220 (DC _H)	Status 13: Gross, Net
221 (DD _H)	Status 14: Overload/underload, Motion , ‘ ‘
222 (DE _H)	Piece reading
223 (DF _H)	Counting piece weight

Table 12: Print tokens: weight information

16.3.6. Format tokens

Format tokens define the behaviour of all subsequent tokens in a string.

Code	Format Tokens
149 (95 _H)	5-character weight string, decrementing to 3 with wrapping (5,4,3,5...)
150 (96 _H)	6 character weight string
151 (97 _H)	7 character weight string
152 (98 _H)	8 character weight string
153 (99 _H)	9 character weight string
154 (9A _H)	10 character weight string
155 (9B _H)	No sign characters
156 (9C _H)	Sign is ' ' for positive and '-' for negative
157 (9D _H)	Sign is '0' for positive and '-' for negative
158 (9E _H)	Sign is '+' for positive and '-' for negative
159 (9F _H)	No decimal point
160 (A0 _H)	Decimal point is '.'
161 (A1 _H)	Decimal point is ','
162 (A2 _H)	Weight sent without leading characters
163 (A3 _H)	Weight sent with ' ' for leading characters
164 (A4 _H)	Weight sent with '0' for leading characters
165 (A5 _H)	Show weight on error
166 (A6 _H)	Show dashes instead of weight on error
167 (A7 _H)	Show spaces instead of weight on error
168 (A8 _H)	Use uppercase status characters
169 (A9 _H)	Use lowercase status characters
170 (AA _H)	Hide units
171 (AB _H)	Show decimal point even if it is at the end of a number
172 (AC _H)	Turn page and line tracking off
173 (AD _H)	Toggle space between weight and units
174 (AE _H)	Increment the length or print IDs with wrapping from 6 to 9
175 (AF _H)	Don't show weight

Table 13: Print tokens: formatting

Printouts have default format tokens of line and page tracking are enabled and:

Weight	Time
<ul style="list-style-type: none"> • 8-character weight string • Decimal point symbol is '.' • Leading characters are spaces • Weight is sent on error • Positive sign is space, negative sign is '-' • Weights are displayed with units • Status characters are uppercase 	<ul style="list-style-type: none"> • Date separator is '/' • Time separator is ':' • Date format is the format configured in the setup menu • Time is 24-hour

The Format token must be used before the token that requires the formatting. For example, where the current weight is 10kg and a formatted with no units is needed:

`\BE\AA\D7` would be 10

Whereas if the AA is used after the D7 it has no effect.

`\BE\D7\AA` would be 10kg

16.3.7. Page 9 Tokens: Summing Information

These pages hold summing information where:

Code	Token
215 (D7 _H)	Slave 1 Weight
216 (D8 _H)	Slave 2 Weight
217 (D9 _H)	Slave 3 Weight
218 (DA _H)	Slave 4 Weight
219 (DB _H)	Slave 5 Weight
220 (DC _H)	Slave 6 Weight
221 (DD _H)	Slave 7 Weight
222 (DE _H)	Slave 8 Weight
223 (DF _H)	Slave 9 Weight
224 (E0 _H)	Sub Total 1 Weight
225 (E1 _H)	Sub Total 2 Weight
226 (E2 _H)	Sub Total 3 Weight
227 (E3 _H)	Sub Total 4 Weight
228 (E4 _H)	Slave 1 Name
229 (E5 _H)	Slave 2 Name
230 (E6 _H)	Slave 3 Name
231 (E7 _H)	Slave 4 Name
232 (E8 _H)	Slave 5 Name
233 (E9 _H)	Slave 6 Name
234 (EA _H)	Slave 7 Name
235 (EB _H)	Slave 8 Name
236 (EC _H)	Slave 9 Name
237 (ED _H)	Sub Total 1 Name
238 (EE _H)	Sub Total 2 Name
239 (EF _H)	Sub Total 3 Name
240 (F0 _H)	Sub Total 4 Name

Table 14: Print Tokens: Summing Information

17. Appendix 3: Communications Registers

Name	Address	Type	Description																														
Software Model	0003 _H 3 _d	String	Returns software loaded (e.g. K402)																														
Software Version	0004 _H 4 _d	String	Returns software version (e.g. V1.0)																														
Serial Number	0005 _H 5 _d	Number	Returns instrument serial number																														
Key buffer entry	0008 _H 8 _d	Number	<p>Adds a key to the key buffer. The short press key codes are shown below. For long presses, set the most significant bit to 1.</p> <p>Key codes are:</p> <table style="width: 100%; border: none;"> <tr> <td>00_H: 0</td> <td>0E_H: F1</td> <td>15_H: DOWN</td> </tr> <tr> <td>:</td> <td>0F_H: F2</td> <td>16_H: OK</td> </tr> <tr> <td>09_H: 9</td> <td>10_H: F3</td> <td>17_H: SETUP</td> </tr> <tr> <td>0A_H:</td> <td>11_H: +/-</td> <td>20_H: IO1</td> </tr> <tr> <td>Power</td> <td>12_H: DP</td> <td>:</td> </tr> <tr> <td>0B_H:</td> <td>13_H: CANCEL</td> <td>3F_H: IO32</td> </tr> <tr> <td>Zero</td> <td>14_H: UP</td> <td></td> </tr> <tr> <td>0C_H:</td> <td></td> <td></td> </tr> <tr> <td>Tare</td> <td></td> <td></td> </tr> <tr> <td>0D_H: G/N</td> <td></td> <td></td> </tr> </table>	00 _H : 0	0E _H : F1	15 _H : DOWN	:	0F _H : F2	16 _H : OK	09 _H : 9	10 _H : F3	17 _H : SETUP	0A _H :	11 _H : +/-	20 _H : IO1	Power	12 _H : DP	:	0B _H :	13 _H : CANCEL	3F _H : IO32	Zero	14 _H : UP		0C _H :			Tare			0D _H : G/N		
00 _H : 0	0E _H : F1	15 _H : DOWN																															
:	0F _H : F2	16 _H : OK																															
09 _H : 9	10 _H : F3	17 _H : SETUP																															
0A _H :	11 _H : +/-	20 _H : IO1																															
Power	12 _H : DP	:																															
0B _H :	13 _H : CANCEL	3F _H : IO32																															
Zero	14 _H : UP																																
0C _H :																																	
Tare																																	
0D _H : G/N																																	
Secondary Display Left	000E _H 14 _d	String	Write to this register to display data on left side of Secondary Display. Note: The display must be in Top mode.																														
Secondary Display Right	000F _H 15 _d	String	Write to this register to display data on left side of Secondary Display. Note: The display must be in Top mode.																														
Save Settings	0010 _H 16 _d	Execute	Execute function with no parameters saves any FULL or SAFE setup changes. Operator changes are saved automatically																														
Enter Full Passcode	0019 _H 25 _d	Number	<p>Write a Passcode to this register to unlock settings protected by a FULL Passcode</p> <p>If a full passcode has been set, this must be done before any registers (which require a full passcode) are accessed.</p> <p>Example: Sent (passcode 1):20120019; Response: 81120019:0000</p>																														
Enter Safe Passcode	001A _H 26 _d	Number	Write a Passcode to this register to unlock settings protected by a SAFE Passcode																														
ADC Sample Number	0020 _H 32 _d	Number	Read current sample number since last power on. (32 bit)																														
System Status *	0021 _H 33 _d	Number	<p>This register can be read to obtain the status of the instrument.</p> <p>32 status bits sent as 8 hex chars, where:</p> <p>00020000_H: Overload 00010000_H: Underload 00008000_H: Error (see System Error) 00004000_H: SETUP menus active 00002000_H: Calibration in progress 00001000_H: Motion 00000800_H: Centre of Zero 00000400_H: Zero</p>																														

Name	Address	Type	Description
			00000200 _H : Net For calibration, bit 13 (00002000 _H) is high when a calibration is taking place. Example: Send (status):20110021; Response (not calibrating): 81110021:00008400 Or Response (calibrating): 81110021:0000A400
System Error	0022 _H 34 _d	Number	Diagnostic Errors
Absolute mV/V	0023 _H 35 _d	Number	Absolute mV/V reading where 10000 = 1.0mV/V
Unused	0024 _H 36 _d	Number	
Gross/Net Weight	0025 _H 37 _d	Number	These registers return weight data.
Gross Weight	0026 _H 38 _d	Number	Read Final: 8-character Hexadecimal number. Example: 00000064 for 100 kg
Net Weight	0027 _H 39 _d	Number	Read Literal: Formatted string including decimal point units and Gross/Net indication. Example:“ 10.0 kg N”
Tare Weight	0028 _H 40 _d	Number	
Peak Hold	0029 _H 41 _d	Number	
Manual Hold	002A _H 42 _d	Number	
Grand Total	002B _H 43 _d	Number	
Alternate Units Gross	002C _H 44 _d	Number	
Raw ADC counts	002D _H 45 _d	Number	2,560,000 = 1.0mV/V
Alternate Units Net	002E _H 46 _d	Number	as above
System Fullscale	002F _H 47 _d	Number	Fullscale weight of the instrument.
Traceable weight available flag	0030 _H 48 _d	Number	0: No traceable weights since start up 1: Traceable weight data is valid
Traceable ID	0031 _H 49 _d	Number	The unique ID for the traceable weight.
Traceable weight	0032 _H 50 _d	Number	Traceable weight in primary units
Traceable weight (alt)	0033 _H 51 _d	Number	Traceable weight in alternate units
Traceable weight (p)	0034 _H 52 _d	Number	Traceable weight in pieces
Traceable tare weight	0035 _H 53 _d	Number	Tare weight valid during traceable weight.
Traceable PT flag	0036 _H 54 _d	Number	0: no preset tare 1: preset tare
Traceable date: year	0037 _H 55 _d	Number	Date and time that the traceable was acquired.

Name	Address	Type	Description
Traceable date: month	0038 _H 56 _d	Number	
Traceable date: day	0039 _H 57 _d	Number	
Traceable date: hour	003A _H 58 _d	Number	
Traceable date: minute	003B _H 59 _d	Number	
Traceable date: second	003C _H 60 _d	Number	
Stream Data	0040 _H 64 _d	Block	Returns a block of data which is selected in Stream Register 1 .. 5. Use a read command to read a single set of data. Use an execute command (with a parameter of 1) to switch on automatic transmission
Stream Mode	0041 _H 65 _d	Option	0: Manual - read 'Stream Data' register 1: Auto sync - Data is sent whenever new readings are available. 2: Auto 10Hz – Data is sent at 10Hz 3: Auto 3Hz – Data is sent at 3Hz 4: Auto 1Hz – Data is sent at 1Hz
Stream Register 1..5	0042 _H 66 _d .. 0046 _H 70 _d	Option	1..16 selects registers from ADC Sample (0020 _H) to System Fullscale (002F _H). 17 is IO Status (0051 _H)
Print Token String	004C _H 76 _d	String	Sends a string to the configured printer port. The string can contain print tokens.
Reply Token String	004D _H 77 _d	String	Same as 004C _H except that the completed string is returned to the sender.
Reply registers	004E _H 78 _d	String	Get the value of multiple number registers in a single read. The register IDs are listed in hexadecimal. All numbers are returned as 32 bit. Example: To get the net and tare weights, send "2012004E:00270028;".
Reply Stream ID	004F _H 79 _d		Same as register 004E _H except that stream IDs are used. Example: To get the first 3 items of stream data, send "2012004F:010203;".
IO Status	0051 _H 81 _d	Number	32 bits of IO status sent as 8 hex chars
Piece Weight	0053 _H 83 _d	Number	The current weight in pieces
Settable Consecutive Print ID	007A _H 122 _d	Number	The settable consecutive print ID.
User ID strings 1 .. 5	0090 _H 144 _d ..	String	These strings are also accessed via the ID function on the keypad.

Name	Address	Type	Description
	0094 _H 148 _d		
Current Time/Date	0150 _H 336 _d	String	Read this register to get instrument date/time settings (e.g. 10/12/2005 18:30:10). (Can be SAFE Passcode protected)
Date Format	0151 _H 337 _d	Option	Write 0 for MMDDYYYY or 1 for DDMMYYYY
Day	0152 _H 338 _d	Number	Read/Write current day (1..31)
Month	0153 _H 339 _d	Number	Read/Write current month (1..12)
Year	0154 _H 340 _d	Number	Read/Write current year (2000..2099)
Hour	0155 _H 341 _d	Number	Read/Write current hour (0..23)
Minute	0156 _H 342 _d	Number	Read/Write current minute (0..59)
Second	0157 _H 343 _d	Number	Read/Write current second (0..59)
Session Total Weight Session Total Alt Wgt Session Total Pieces Session Total Num	0210 _H 528 _d	Number	Session total information
Grand Total Weight Grand Total Alt Wgt Grand Total Pieces Grand Total Num	0211 _H 529 _d	Number	Grand total information
The following registers relate to the DSD.			
Auto clear DSD	8290 _H 33424 _d	Option	Auto write over oldest records when full (0..1)
Read DSD Record	8291 _H 33425 _d	Execute	Reads requested DSD record
Read Next DSD Record	8292 _H 33426 _d	Execute	Reads next DSD record
Read Prev. DSD Record	8293 _H 33427 _d	Execute	Reads Previous DSD record
Read Oldest Record	8294 _H 33428 _d	Execute	Reads Oldest DSD record
Read Newest Record	8295 _H 33429 _d	Execute	Reads Newest DSD record
Clear DSD	8296 _H 33430 _d	Execute	Clears all records on DSD
Summing Serial Port	A600 _H 42496 _d	Option	The serial port used to communicate with the slaves
Summing Protocol	A601 _H 42497 _d	Option	RS232 ring or normal RS485 network
Number of slaves	A602 _H 42498 _d	Number	The number of slaves to sum (1..9)
Number of subtotals	A603 _H 42499 _d	Number	The number of subtotals to calculate (0..4)
Slave name	A610 _H 42512 _d	String	6-character name for each slave

Name	Address	Type	Description
	A618 _H 42520 _d		
Sub total name	A620 _H 42528 _d A628 _H 42536 _d A630 _H 42544 _d A638 _H 42552 _d	String	6-character name for each subtotal
Subtotal add slaves	A621 _H 42529 _d A629 _H 42537 _d A631 _H 42545 _d A639 _H 42553 _d	Number	Number containing the slaves to add to the subtotal (e.g. 12 will add slave weights 1 & 2 to the sub total)
Subtotal subtract slaves	A622 _H 42530 _d A62A _H 42538 _d A632 _H 42546 _d A63A _H 42554 _d	Number	Number containing the slaves to subtract from the subtotal (e.g. 34 will subtract slave weights 3 & 4 to the sub total)
Slave weights	A650 _H 42576 _d .. A658 _H 42584 _d	Number	The individual slave weights
Subtotal weights	A660 _H 42592 _d .. A663 _H 42595 _d	Number	The individual subtotal weights
The Active Product is the product shown on the instrument display. It is the product which is currently active in the instrument.			
Change Active Product using Product number	B000 _H 45056 _d	Number	Write number to change the active product. Read to find out active product number.
Clear all Totals	B002 _H 45058 _d	Execute	Execute to clear All Totals
Clear Session Totals	B003 _H 45059 _d	Execute	Execute to clear Session Totals only
Clear Docket Totals	B004 _H 45060 _d	Execute	Execute to clear printing Docket Totals only
Change Active Product using Product Name	B006 _H 45062 _d	String	Write name to change the active product. Read to find out name of active product.
All changes to product information are made to the selected product. This product is selected via the comms and is used for network commands only. It may be different to the active product in the instrument.			
Select product by name	B00F _H 45071 _d	String	Write name to select product, read to find out selected product name.
Select product by number	B010 _H 45072 _d	Number	Write number to select product, read to find out selected product number.

Name	Address	Type	Description
The following registers all work with the Selected Product.			
Delete	B011 _H 45073 _d	Execute	Execute with no parameters to delete the selected product. This can be done only if the product total is zero.
Re-name	B012 _H 45074 _d	String	Write to change name of selected product.
Name	B013 _H 45075 _d	String	Read selected product name.
Preset Tare	B015 _H 45077 _d	Number	Read/Write Preset Tare
Sample Size	B016 _H 45078 _d	Number	Read/Write Sample Size
Sample Weight	B017 _H 45079 _d	Number	Read/Write Sample Weight
Piece Weight	B018 _H 45080 _d	Number	Read/Write Piece Weight
Alternate Unit Conversion Factor	B019 _H 45081 _d	Number	Read/Write Conversion Factor. 1000000 = 1.0
Target 1 .. Target 8	B080 _H 45184 _d .. B087 _H 45191 _d	Number	Setpoint targets for the Selected Product
Total Weight Total Alternate Wgt Total Pieces Total Num	B102 _H 45314 _d .. B105 _H 45317 _d	Number	Product total information
Total Docket Weight Total Docket Alt Wgt Total Docket Pieces Total Docket Num	B180 _H 45440 _d .. B183 _H 45443 _d	Number	Product docket total information

Note: The viewer software will show the register address for each setting in the menu structure when they are accessed. Note that register addresses are not guaranteed to remain the same between software types and versions.

18. Appendix 4: Setup Menu Quick Reference

Note: ⊗ Read-only Safe Setup. Changing this setting **will increment** the Calibration Counter.
 1 Read-only Safe Setup. Changing this setting **will not increment** the Calibration Counter.

L1	L2	L3	L4	Item
GEN.OPT	LANG			Operator language
	DATE.F			Date Format
	P.CODE	SAFE.PC		Safe setup passcode
		FULL.PC		Full setup passcode
		OP.PC		Operator passcode
	KEY.LOC	P		Power key lock
		ZERO, TARE, GR.NET		Fixed Function Keys
		F1,F2,F3		Programmable Function Keys
		CLOCK, DISP etc		Operator Functions
	DISP	B.LIGHT		Backlight operation
		FREQ		Display update frequency
		VIEW		Default View
	ID.NAME	NAME.1 .. NAME.5		Names for the five User ID strings
	POWER	AUT.OFF		Auto-off
START		Pause on Start-Up		
STR.EDT			String editor mode	
USR.DEF			User defaults (all items except scale menu items)	
H.WARE	SER1.HW, SER2.HW	BAUD, PARITY, etc		Settings for serial port 1 (SER1.HW) and the optional serial port 2 (SER2.HW).
		ETH.HW	DHCP, IP, G.WAY, etc	
	ETH.DEF		Reset the M4221 Ethernet module to defaults	
	IO.HW	FRC.OUT		Force outputs test
		TST.IN		Check inputs test
		DB.1.8 - DB.25.32	DBNC.1 – DBNC.32	Debounce settings for inputs
	ANL.HW	TYPE		Voltage or current selection
		CLIP		Output clip enable
		FRC.OUT		Force analogue output test
		ANL.CAL	ADJ.LO	Adjust lo output (4mA or 0V)
	DSD.HW	ADJ.HI		Adjust hi output (20mA or 10V)
		AUTO.C		Automatically overwrite the oldest records when DSD full
DSD.STR		Custom string to store with DSD records		
SCALE	OPTION	USE		Trade use
		Z.BAND		Band of Zero
FUNC	NUM			Number of special functions
	SF1 – SF8	TYPE		Type
		KEY		Key assignment (Not for Thumbwheel)
		LONG.PR		Long Press
		PRT.OUT		Print: printout
		TOTAL		Print: totalising
		CLR.ASK		Print: Confirm clear
		AUTO		Print: Automatic
		IL.TYPE		Print: Interlock type
		I.LOCK		Print: Interlock
		AUT.OUT		Single: Auto Output to use
		BLANK		Blank: Blanking function
		IO.BAND		Thumb: Inputs connected to thumbwheel
		FUNC		Remote Key: Function to trigger
		CLR.TOT		Report print clear totals
		THRESH		Auto-tare: Weight threshold before taring
ZER.DLY		Auto-tare: Delay before switching to gross in zero band		
SER.SUM	SERIAL			Serial port for summing
	PROTO			Network protocol for summing
	SLAVES			Number of slaves to sum
	SLAV.1.. SLAV.9	NAME		Name of each slave
	SUB.NUM			Number of sub totals
	S.TOT.1.. S.TOT.4	NAME		Name of subtotal
		SLV.ADD		Slaves to add to subtotal
	SLV.SUB		Slaves to subtract from subtotal	
SER.NET	ADDR			Network address
	NUM			Number of networks
	NET.1 – NET.n	TYPE		Protocol type
		SERIAL		Serial port
		RESP		Respond with OK for simple protocol commands

L1	L2	L3	L4	Item		
		SOURCE		Source for barcode protocol		
SER.AUT	NUM			Number of Serial outputs		
	AUTO.1.. AUTO.2	TYPE		Frequency		
		SERIAL		Serial port		
		FORMAT		Format		
		EV.AUTO		Custom format string		
PRINT	NUM			Number of printouts		
	HEADER			Header		
	FOOTER			Footer		
	PAGE	WIDTH			Page width	
		HEIGHT			Page Height	
		PG.END			Page End String	
	SPACE	TOP			Blank lines at the top	
		LEFT			Blank characters on the left	
		BOTTOM			Blank lines at the bottom	
	PRINT.1 – PRINT.n	TYPE			Printout type	
		FORMAT			Format	
		SERIAL			Serial port to print to	
		NAME			Printout Name	
		CUSTOM	REC.PRN			Custom string for record printout
			PRN.KEY			Custom string for docket printout
			EV.D.NEW			Custom string for new docket
			EV.D.END			Custom string for end of docket
			EV.P.NEW			Custom string for new product
			EV.P.END			Custom string for end of product
	REP.ST				Custom string for start of report	
REP.PR			Custom string for each product in a report			
REP.END			Custom string for end of report			
SETP	NUM			Number of Setpoints		
	SETP1 .. SETP16	TYPE		Type of setpoint		
		OUTPUT		Output to use		
		LOGIC		Active High or Active Low logic control		
		ALARM		Setpoint Alarm		
		RDY.TIM		Scale ready setpoint wait time		
		SOURCE		Target value source		
		SCOPE		Product or global targets		
		HYS		Hysteresis		
		REG		Register to use as source		
		DELAY		Pulse timing delay		
		ON		Pulse timing duration		
		TIMING		Setpoint Timing Option		
		MASK		Logic setpoint mask		
		RESET		Input to use for reset		
		PLS.NUM		Number of pulses for pulse timing		
RST.LGC		Active high or active low for reset input				
NAME			Name of the setpoint			
ANL.OUT	ABS			Use absolute weight		
	RANGE			Weight range		
	WGT.LO			Weight for low transmission		
	WGT.HI			Weight for high transmission		
End	End			Save and Close		

Table 15: Menus

19. Appendix 5: Error Messages

19.1. Overview

A number of error messages may be displayed to warn of operation outside of the acceptable limits. These messages may appear on either the primary or the secondary display. Short messages (XXXXXX) will appear as a single message. Longer messages (XXXXXX) (YYYYYY) will appear on the display in two parts, first the (XXXXXX) part, then the (YYYYYY) part.

19.2. Weighing Errors

These messages show status messages or errors that may occur during normal weighing operation.

Error	Description	Resolution
(U.LOAD)	The weight is below the minimum allowable weight reading.	Increase the weight or decrease the minimum allowable weight reading.
(O.LOAD)	The weight is above the maximum allowable weight reading. Warning - overloading may damage mechanical scale elements.	Check the condition of load cell connections. Check for damaged load cell.
(-----)	The summed weight could not be calculated.	Check that all units are displaying positive weight, and all are displaying either gross or net (not a mismatch). If an error code is displayed on the bottom display, refer to the table below.

Table 16: Errors: Weighing

If the top display is blanked, an error may be displayed on the bottom display. This table describes each error.

Error	Description
No Resp	One or more slaves are not responding. Slave will be shown in the bottom right display.
Hdr Adr	The address in the command header is bad (i.e. can't be parsed)
Hdr Cmd	The command in the command header is bad (i.e. can't be parsed)
Hdr Reg	The register in the command header is bad (i.e. can't be parsed)
Hdr Dlm	The delimiter in the command header is bad (i.e. can't be parsed)
Bad Adr	The address in the command header is incorrect (i.e. different to what was requested)
Bad Rply	The reply was not the expected reply
Not Rply	The response was not a reply
Err Rply	The slave replied with an error
Bad Cmd	The command in the command header is incorrect (i.e. different to what was requested)
Bad Reg	The register in the command header is incorrect (i.e. different to what was requested)
Bad Data	The payload could not be parsed
Data Rng	The data in the payload was outside the allowable range
No Slaves	No slaves replied on the ring network
Bad Setup	The summing indicator setup is bad (i.e. bad number of slaves or subtotals)
Setup Chg	The setup of one of the slaves has changed
Reg Error	One of the slaves is reporting an error when reading a register
Unit.Match	There is a mismatch in the units reported by the slaves (for example mix of kg and t)
Model Err	There is a mix of R300 and R400 indicators on the bus (only the same type of unit can be summed)

Table 17: Errors: Summing

19.3. Setup Errors

These messages show status messages or errors that may occur during the instrument setup.

Error	Description	Resolution
(ENTRY) (DENIED)	When accessing setup, more than three attempts have been made with the incorrect passcode.	Turn the instrument off. When the instrument is turned back on, enter the correct passcode to access setup.
(WR DENIED) (RD DENIED)	The instrument may be in Safe Setup and an item that needs Full Setup has been selected for editing.	Access Full Setup to access this item.

Table 18: Errors: Setup

19.4. Diagnostic Errors

The instrument continually monitors the condition of the internal circuits. Any faults or out-of-tolerance conditions are shown on the display as an **E** type error message.

In the table below the following terms are used:

- **Check:** This item can be checked on site by service personnel.
- **Return for Service:** The instrument must be returned for factory service.

Error	Description	Resolution
(E0001)	The power supply voltage is too low.	Check supply
(E0002)	The power supply voltage is too high.	Check scale / cables
(E0010)	Temperature is outside of allowable limits	Check location
(E0020)	Module Error	Replace Module
(E0200)	The calibration information has been lost.	Re-calibrate
(E0400)	The factory information has been lost.	Return for Service
(E0800)	Application settings have been set to defaults.	Check and re-enter application settings
(E4000)	The runtime information has been lost.	Check Zero and tare settings.

Table 19: Errors: Diagnostic

The **E** type error messages are additive. For example, if the instrument is running off batteries and the temperature drops, the battery voltage may be too low. The resulting error messages will be **E 0011** (0001 + 0010). The numbers add in hexadecimal as follows:

1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - A - B - C - D - E - F
 (For example, 2 + 4 = 6, or 4 + 8 = C)

20. Glossary

20.1. Glossary of Terms

Term	Definition
Count-by	The smallest change in weight units that the display can show. See also Resolution.
Division	A single graduation.
EEPROM	Electrically Erasable Programmable Read-Only Memory
EMC	Electro-Magnetic Compatibility Regulation
FIR	Finite Impulse Response
Full Scale	The maximum gross weight allowed on the scale. This is used to detect overload and underload conditions, etc.
Graduations	The maximum number of display steps between zero gross load and full capacity gross load. It is equal to the full scale divided by the resolution.
LED	Light Emitting Diode
NTEP	National Type Evaluation Program
OIML	International Organization of Legal Metrology
PLC	Programmable Logic Controller
Range	Total change in weight between zero gross load and full capacity gross load (i.e. the nominated total capacity of the scale). It is always given in displayed weight units.
Resolution	The smallest change in weight units that the display can show. See also Count-by.
RFI	Radio Frequency Interference
Optical Communications Cable	Opto-isolated infrared communications cable which uses a magnetically coupled head to attach to the front of the instrument
RS-232	Standard for communications hardware layers.
Step-Response	The step-response is the time between placing a weight on the scale and the correct weight reading being displayed.
Transients	A temporary voltage oscillation or spike caused by a sudden change of load (or other external influence).
Units	The actual units of measurement (kilograms, tonnes, pounds, etc.).

20.2. List of Figures

Figure 1: Weight Indicator	5
Figure 2: Cable Connections	10
Figure 3: RS-232 - Instrument to PC using COM Port (DB9)	11
Figure 4: RS-232 – Instrument to Printer (DB25)	12
Figure 5: Optical Communications attachment	13
Figure 6: Cable Shield Connection	14
Figure 7: OVER versus UNDER setpoints	82
Figure 8: OVER setpoint timing options	82
Figure 9: Trade label position	91
Figure 10: Lead seal on rear of instrument	92
Figure 11: Lead seal on boot.	92
Figure 12: Destructible sticker seal on rear of instrument	93
Figure 13: Destructible sticker seal on boot	93

20.3. List of Tables

Table 1: Document Conventions	6
Table 2: Instrument specifications	8
Table 3: Network error codes	66
Table 4 : Instrument Status for Logic Setpoints	85
Table 5: Setpoint status for logic setpoints	86
Table 6: Dimensions	90
Table 7: ASCII Table	94
Table 8: Print tokens: generic	95
Table 9: Print tokens: pages	95
Table 10: Print tokens: weight information	96
Table 11: Print tokens: product information	97
Table 12: Print tokens: weight information	97
Table 13: Print tokens: formatting	98
Table 14: Print Tokens: Summing Information	99
Table 15: Menus	107
Table 16: Errors: Weighing	108
Table 17: Errors: Summing	109
Table 18: Errors: Setup	109
Table 19: Errors: Diagnostic	110

21. Index

- A**
 Automatic Weight
 Output, 68
 Auxiliary
 Connection, 11
- C**
 Cable Connections,
 10
 Calibration Counter,
 35
 Connecting Shields,
 14
- D**
 Data Entry, 17
 Numeric Entry, 19
 Selections and
 Options, 19
 DC Power Supply,
 10
 Diagnostic Errors,
 108
 Document
 Conventions, 6
- E**
 Earthing, 15
 Electrical Safety, 9
 EMC Immunity, 9
 Error Messages, 106
 Exiting Full or Safe
 Setup, 18
- F**
 Front Panel
 Special Function
 Key, 74
 Full Setup
 Passcode, 35
 FUNCTION Key, 74
- G**
 General Setup
 Information, 35
 Glossary of Terms,
 109
- K**
 Key Functions, 74
- N**
 NONE, 74
- NVRAM, 5
- O**
 Optical
 Communications,
 12
- P**
 Passcode, 35
 Printing, 70
- R**
 RFI, 109
 RS-232 Serial, 11
- S**
 Safe Setup
 Passcode, 35
 Sealing Details, 89
 Sealing
 Requirements, 15
 Serial PC Link, 10,
 11
 Serial Printer
 Connections, 12
 Serial Remote
 Display, 12
 Setup Display
 Prompts, 18
 Setup Errors, 107
 Setup Menu Quick
 Reference, 104
 Special Functions,
 74
 Specifications, 6, 7
 Stability
 Considerations,
 34
- T**
 TARE Key, 26
 TEST, 75
- W**
 Weighing Errors,
 106
- Z**
 ZERO Key, 26