


# Rinstrum R420 ABS Indicators Panel Mount and Full Housing

The R400 series of indicators is designed with both the installer and operator in mind and covers a wide range of applications. The indicators are engineered and built to last with reliability being foremost. The modular design allows for the installation to be commissioned with only the components required, saving time and money.

### Features

- AC and DC options
- LCD with 4 alpha-numeric displays and LED backlighting
- OIML, NMI and NTEP trade approved
- Built-in RS232/RS485
- IP65-rated ABS housing
- Ethernet support (optional)
- Robust precise analogue output module
- Versatile application software



## Superior diagnostics and support

- Range of diagnostic tools and features
- Hardware configuration report: summarizes how the indicator hardware is set up, providing a record for maintenance purposes or fault finding
- Force Output and Test Input functions: allow the installer to specifically test I/O to assist in site setup
- Ability to swap modules in and out without recalibration of the indicator

## View400 Fast Efficient Indicator setup via a PC


View400 displays the complete menu structure of the indicator on the PC with convenient drop-down menus for setting selection.


- Enter custom print strings using the PC
- Set up the indicator and save the configuration and calibration for maintenance purposes or load the RIS file onto multiple indicators
- Create a real-time graph from the log that is ideal for diagnostics

### Save400 - Reading and writing Indicator setup

Save400 is a software tool that reads and writes R400 indicator setup and configuration. It allows for a setup to be exported for update and then be reimported.

inLIB-K400 version	rinLIB-K400: API fo	or programming the M4223 in Lua				
	Copyright © 2013-2016 Rinstrum.					
Search	This reference is correct for library version 2.5.2 only.					
Modules	If you do not know where to begin, please start with the introduction.					
rinApp	Modules					
rinLibrary.Device.Analog	rinApp	Module manager for L401				
rinLibrary.Device.Axle	rinLibrary.Device.Analog	Analogue Functions.				
rinLibrary.Device.Batch rinLibrary.Device.Buzz rinLibrary.Device.Commar rinLibrary.Device.Commar rinLibrary.Device.FSM rinLibrary.Device.LCD	rinLibrary.Device.Axle	Axle scle functions.				
	rinLibrary.Device.Batch	Batching scale functions.				
	rinLibrary.Device.Buzz	Buzzer Handling.				
	rinLibrary.Device.Command	Library for High level command support.				
	rinLibrary.Device.Dialog	Dialog Control.				
	rinLibrary.Device.FSM	Finite State Machine Infrastructure.				
rinLibrary.Device.Menu	rinLibrary.Device.Keys	Key Handling.				
rinLibrary.Device.Passcod	rinLibrary.Device.LCD	LCD Services.				






## Lua Programmability



- Embedded Lua scripting with accessory module
- Enhance functionality by installing a range of application packages
- Open-source library and comprehensive API enable you to write your own applications or engage Rinstrum to write them for you through our Lua MAX programme
- Use the embeded web server to create browser-based user interfaces



## Rugged Load Cell Input


Designed to take 16x350 ohm load cells @0.25uV/D; providing flexibility and reducing the need for summing hardware, simplifying the installation and saving money. The load cell input is protected with onboard transorbs to limit damage from external voltage surges.

## rinLINK for establishing a temporary connection to a PC

The rinLINK provides an isolated optical serial connection directly on the front of the indicator. It is magnetically coupled for easy access in situ for updates/setup of the indicator, saving the installer time and effort. The rinLINK can be used to download new firmware or to provide the connection to the PC running Viewer for indicator configuration.



RS232/ RS232 Module	RS232/RS485 Module	RS485/RS485 Module	AC Module	Lua Module	I/O Module	Button Module	Analogue Output	Data Storage Device Module
• Electrically isolated RS232 serial communication	<ul> <li>Electrically isolated serial communication</li> </ul>	<ul> <li>Electrically isolated RS485 networking</li> </ul>	• 110-240 VAC in	• Lua programmability	<ul> <li>8 I/O Configure as input or output</li> </ul>	<ul> <li>4 voltage free inputs</li> </ul>	<ul> <li>4-20mA or 0-10V analogue output</li> </ul>	<ul> <li>Nonvolatile alibi memory storage (6M bytes)</li> </ul>
Status LEDs	• Status LEDs	• Status LEDs	• 12 VDC out	<ul> <li>Ethernet Port</li> <li>USB Host Port</li> <li>Telnet/SSH remote access</li> </ul>	<ul> <li>Electrically isolated</li> <li>Status LEDs</li> <li>Outputs - high current DC</li> <li>Active high I/O</li> </ul>		<ul> <li>Electrically isolated</li> <li>Fast 400Hz update</li> <li>2 digital I/O</li> </ul>	<ul> <li>Compatible with later versions of software</li> </ul>





### AUSTRALIA

Rinstrum Pty Ltd Unit 4/31 Henry Stree Loganholme QLD 4129 Australia

Ph: +61 7 3216 7166 Email: sales.au@rinstrum.com

#### USA

Rinstrum Inc 1349 Piedmont Drive Troy, Michigan 48083 United States

Toll Free 1 877 829 9152 Ph: +1 248 680 0320 Fax: +1 248 499 1331 Email: sales.us@rinstrum.com

#### www.rinstrum.com

#### EUROPE

Rinstrum Europe GmbH Hans-Böckler-Straße 42 D-40764 Langenfeld Germany

Ph: +49 (0)2173 16562-10 Fax: +49 (0)2173 16562-29 Email: sales.eu@rinstrum.com